

amazon basics B0C8H8B4WM Wireless Keyboard and Mouse Combo Instruction Manual

Home » amazon basics » amazon basics B0C8H8B4WM Wireless Keyboard and Mouse Combo Instruction

Manual

Contents

- 1 amazon basics B0C8H8B4WM Wireless Keyboard and Mouse Combo
- **2 PACKING LISTS**
- **3 INSTRUCTIONS FOR USE**
- **4 FCC STATEMENT**
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**




amazon basics B0C8H8B4WM Wireless Keyboard and Mouse Combo





PACKING LISTS



INSTRUCTIONS FOR USE

- 1. Take out the keyboard and mouse from the box, and take out the receiver from the mouse battery compartment;
- 2. Insert a 1.5V AAA dry battery into the keyboard with the correct polarity;
- 3. Insert a 1.5V AA dry battery into the mouse with the correct polarity;
- 4. Insert the receiver into the USB port of the computer;
- 5. Wait for the computer to automatically install the driver and start using it.

KEY COMBINATION FUNCTION

FN+F1	FN+F2	FN+F3	FN+F4	FN+F5	FN+F6
Multimedia player	Volume Down	Volume Up	Mute	Previous song	Next song
FN+F7	FN+F8	FN+F9	FN+F10	FN+F11	FN+F12
Play/Pause	Stop	Home	IICIMI	My Computer	Favorites

Features:

- 1. The mouse and keyboard share a common receive, and the receiver is in the battery compartment at the bottom of the mouse
- 2. Adjustable mouse DPI levels: 800-1200-1600 (default setting is 1200)
- 3. It has automatic Sleep mode and Wake up mode. When the mouse hasn't been used for 10 min, it will enter sleep mode, press any button to wake up the mouse.

CONNECTION ERROR SOLUTION keyboard:

- 1. Remove the battery from the keyboard and the receiver on the computer.
- 2. Reinsert the battery into the keyboard and reinsert the receiver into the computer jack.
- 3. At a distance of 20 cm from the receiver, press the ESC+Q keys on the keyboard for 3-5 seconds to match the

code.

Mouse:

- 1. Remove the battery in the mouse and the receiver on the computer.
- 2. Reinsert the battery into the mouse and reinsert the receiver into the computer jack.
- 3. At a distance of 20 cm from the receiver, press the right mouse button and the scroll wheel button simultaneously for 3 to 5 seconds to match the code. After successful pairing, it can be used normally.

The keyboard/mouse response is delayed and works abnormally, how to solve it?

- 1. The battery may be low, please replace the battery for the keyboard/mouse.
- 2. It may be caused by the computer freezing, please restart the computer and try again.
- 3. The maximum use distance of this product is 10M, please keep it within 10M. And there should be no metal obstacles between the keyboard/mouse and the receiver.

CORRECT DISPOSAL OF THIS PRODUCT



- Waste Electrical & Electronic Equipment) This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
- Household user should contact either the retailer where they purchased this product, or their local government
 office, for details of where and how they can take this item for environmentally safe recycling. Business users
 should contact their supplier and check the terms and conditions of the purchase contact.
- This product should not be mixed with other commercial wastes for disposal.

FCC STATEMENT

 Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Documents / Resources

amazon basics B0C8H8B4WM Wireless Keyboard and Mouse Combo [pdf] Instruction Man

B0C8H8B4WM Wireless Keyboard and Mouse Combo, B0C8H8B4WM, Wireless Keyboard and Mouse Combo, Keyboard and Mouse Combo, Mouse Combo, Combo

References

• User Manual

Manuals+,