




## amazon basics C1399-1 Smart Tire Inflator Portable Air User Manual

[Home](#) » [amazon basics](#) » amazon basics C1399-1 Smart Tire Inflator Portable Air User Manual 

amazon basics C1399-1 Smart Tire Inflator Portable Air User Manual




## Contents

- 1 Notes
- 2 **PRODUCT OVERVIEW**
- 3 PARTS LIST
- 4 Screen Key Introduction
- 5 Measure pressure value
- 6 Using steps
- 7 **SPECIFICATIONS**
- 8 Determining the right pressure value
- 9 Types of failures and treatment methods
- 10 Activate your warranty
- 11 Documents / Resources
- 12 Related Posts


## Notes

- Please read the instructions carefully before use. Incorrect usage may damage the product.
- Please pay attention to electricity safety when using.
- Check the preset pressure value before use. The preset pressure value should match the object to be inflated.
- Please do not use this product in the rain or where there are any liquids.
- Contains small accessories which are a choking hazard for young children.
- Keep out of reach of children, if there are children nearby make sure they are properly supervised.
- Keep the device away from fire, corrosive gases, liquids, and strong magnetic fields.
- Do not aim the nozzle at people or any part of a human body.
- Risk of electric shock, do not use air compressor if it is damaged or if the wires are exposed.
- Avoid extended and continuous use. Please use less than 20 minutes for a single use.
- When not in use, disconnect the air compressor from all power sources. The air compressor may get hot during continuous use, please be careful during the use.
- Do not store the air compressor in high-temperatures or in a humid environment. Do not use it on a 24V car power.
- Suitable for SUVs, cars, motorcycles, bicycles, decorative balloons and other objects that need to be inflated, etc. Not suitable for RVs, trucks and other large size objects.
- Do not use chemical reagents to clean the air compressor.
- The air pump should be used in a clean, dry, well-ventilated place, please keep the air compressor away from fire, heat, and corrosive liquid.

## PRODUCT OVERVIEW




## PARTS LIST




## Screen Key Introduction


Press the 'R' button to switch units (4 options: PSI, BAR, KPA, KG/CM<sup>2</sup>).



Press the '+' and '-' buttons to set the desired pressure.




Press “1” to start inflating; During the working, press “o” to suspend inflatable;



### Measure pressure value

- After turn on the air pump, make sure the air nozzle is connected the bicycle/motorcycle/car, the display will detect the current pressure value.
- The air compressor shuts off automatically when the pre-set pressure value is reached



### Using steps

1. Connect the power cord to the DC 12V Power interface, the air pump will turn on automatically; (once the air pump is powered on, the light will stay on until the air pump is powered off)
2. Connect the air pump firmly to the air outlet of the inflatable object;
3. Press R to switch units (4 options: PSI BAR KPA kg/cm<sup>2</sup>), you can adjust pressure value by pressing the +/- button, after the number on the screen flashes 3 times, Press" | " to start working:
4. When the pressure value you need is reached, the air pump will stop working automatically, you can disconnect the power cord to turn off the air pump;


## SPECIFICATIONS

Name	Tire Inflator
Model	C1399-1
DC 12V cigarette lighterpower cord Dimensions	Length 300CM
Inflation Pressure Range	3-150psi/0.2-10.3bar
Operating Temperature	Charging:0°C-60C,Discharging:-20°C-60°C
Storage Temperature	-20°C-60°C
Sensor Accuracy	t1 PSI
Continuous working time	<20 min


## Determining the right pressure value

The tres of automobiles, bicycles and motorcycles can withstand the pressure range The enclosure is marked on the sidewall of the tire. Guide pressure gauge for automobile tires

**Note:** near the inner wall of the driver's door. Inflation pressure It s related to the load weight. For more detailed air pressure suggestions, please check Read the vehicle manual.



The inflation pressure of football, basketball, volleyball and other balls is at the air nozzle Inflation pressure shall be marked around.



Inflation pressure value		
	12,14,16 inch bicycle tire	30-50psi
	20, 22, 24 inch bicycle tire	40-50psi
Bike	26,27.5,29 inch mountain bike tire	45-65psi
	700c road bike open tire	100-130 psi
	700c road bike tube	120-145psi
Motorbike	Motorcycle, electric motorbike tire	26-45psi
Car	Sedan car tire	26-50psi
Ball	Volleyball	5-6psi
	Basketball	7-9 psi
	Rugby	12-14psi
	Football	8-16psi

The recommended inflation pressure is for reference only. please refer to the requirements of the instruction manual of the inflated product.

## Types of failures and treatment methods

Malfunction	Method of exclusion
Slow inflation	1. Check whether the air pipe is leaking.2. Check whether the inflated object is leaking.3. Check whether the car is full of heavy objects. If so, please use a jack to jack up the car before inflating it.4. Check whether the connecting part of the air pipe is tightened.
Can't inflate after turning on	1. Make sure the inflation hose and tire valve are well connected.2• Check whether the power supply is connected in place3. Check whether the current tire pressure value is higher than the preset value.
Cannot adjust preset pressure	Check whether it is in the incorrect inflation mode, select the free mode to adjust the preset value within the range of 3-150psi.
Normal inflation but the pressure shows zero	Low-pressure inflation products such as balloons are not within the measurable range of the device.
The air pump does not work, and the lamp also Not working, in cigarette lighter The fuse is blown Has	The air pump is equipped with a spare fuse to unscrew the cigarette lighter, Replace with a new fuse.
Other than the above, No reaction in operation	Long press the ON key to turn off the machine and turn it on again.

## Activate your warranty

You will receive free 48 months warranty by scanning below QR code. Or you can send your order ID to [after-sales@carsun.com](mailto:after-sales@carsun.com)

If you have any problems with our product, please feel free to contact us.

[after-sales@carsun.com](mailto:after-sales@carsun.com)














[after-sales@carsun.com](mailto:after-sales@carsun.com)

# CARSUN

 The image shows the front cover of a Carson C1399-1 Smart Tire Inflator Portable Air User Manual. The cover is white with a black border. At the top left, the Carson logo is visible. In the center, there is a line drawing of the tire inflator device, which is a rectangular unit with a digital display and various ports. Below the drawing, the text "SMART TIRE INFLATOR" and "USER MANUAL" are printed. At the bottom, there is a small number "A1.4".	<p><a href="#">amazon basics C1399-1 Smart Tire Inflator Portable Air</a> [pdf] User Manual</p> <p>C1399-1 Smart Tire Inflator Portable Air, C1399-1, Smart Tire Inflator Portable Air, Tire Inflator Portable Air, Inflator Portable Air, Portable Air, Air</p>
--	--