



[Home](#) » [amazon basics](#) » **amazon basics Closet Storage Organizer with Bins Instruction Manual**



Contents [[hide](#)]

- [1 amazon Basics Closet Storage Organizer with Bins](#)
- [2 Specifications](#)
- [3 IMPORTANT SAFEGUARDS](#)
- [4 Before First Use](#)
- [5 Cleaning, Storage, and Maintenance](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

amazon basics

amazon Basics Closet Storage Organizer with Bins



Specifications

Maximum Load	US Standard	Metric
Fabric shelf:	10 lbs	4.5 kg
Drawer:	5 lbs	2.3 kg

IMPORTANT SAFEGUARDS

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included. When using the product, basic safety precautions should always be followed to reduce the risk of injury, including the following.g

- For domestic use only.
- This product must be assembled by an adult.
- Keep children and pets away while assembling the product.
- Do not let children climb on or play with the product.
- Do not use this product if any parts are missing, damaged, or worn.
- To avoid scratching the floor, assemble the product on a soft surface, such as a carpet.
- Regularly examine the product for wear and tear. Stop using the product at first sign of damage or if parts become detached.
- Do not hang anything on the product. Be aware of dynamic loading! Sudden load movement may briefly create excess load, causing product failure.
- Use the product on a flat, level, and hard surface capable of supporting the shelving and any items placed on it. Remember to only use the product on level ground with evenly distributed weight.
- Do not overload the shelves and evenly distribute the weight on each shelf or drawer. Keep the heaviest load on the bottom drawer. The maximum load of one shelf is 10 lbs (4.5 kg). The maximum load of one drawer is 5 lbs (2.3 kg).

WARNING: Risk of injuryYour unassembled state contains small parts, sharp edges and sharp points.

- Do not climb or use the product as a step ladder. The unstable weight may cause the

product to tip over.

- Do not stand on, step on, or alter the product for anything outside the designed function of storage.

Before First Use

- Remove all the packing materials.
- Remove and review all components before assembly.
- Check the product for transport damage.

DANGER Risk of suffocation

Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.

Cleaning, Storage, and Maintenance

Cleaning

- To clean the product, wipe with a soft, slightly damp cloth.
- Wipe the product dry after cleaning.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal, or sharp utensils to clean the product.

Storage

- Make sure the product is clean and dry.
- Wrap the product in protective material, such as moving blankets, bubble wrap, or furniture pads. This will prevent scratches and other damage during storage. Store the product in a dry, cool place, such as a climate-controlled storage unit or a dry basement. Avoid storing the furniture in areas that are damp, humid, or prone to temperature fluctuations.
- Cover the product with a breathable cover, such as a cotton sheet, to protect it from dust and moisture. Avoid using plastic covers, as they can trap moisture and cause mold and mildew to develop.
- Avoid stacking heavy items on top of each other, as this can cause damage. Instead,

place heavy items on the bottom and lighter items on top.

- If the product can be disassembled, take it apart before storing it. This will make it easier to store and transport, and will also reduce the risk of damage during storage. Be sure to label each piece to know how to reassemble it later.
- If possible, store the product upright to save space. Place larger items, such as sofas and mattresses, against the walls. Stack chairs and smaller items on top of each other.
- Check the product regularly during storage to ensure that it is in good condition. This will help to identify any problems early and prevent them from getting worse.
- Store the product in a safe place that is out of reach of children and pets. Make sure the storage area is clean, dry, and free from any potential hazards.

Maintenance

- Check the components regularly to make sure all screws are fastened.


Importer Information

	For EU	
Postal:	Amazon EU S.à r.l., 38 avenue John F. Kennedy, L-1855 Luxembourg	
Business Reg.:	134248	
Maximum Load	US Standard	Metric
Fabric shelf:	10 lbs	4.5 kg
Drawer:	5 lbs	2.3 kg

Feedback and Help

We would love to hear your feedback. Please consider leaving a rating and review through your purchase orders. If you need help with your product, log in to your account and navigate to the customer service / contact us page.

Documents / Resources



amazon basics Closet Storage Organizer with Bins [pdf] Instruction Manual

Closet Storage Organizer with Bins, Storage Organizer with Bins, Organizer with Bins

References

- [User Manual](#)

amazon basics

Amazon Basics, Closet Storage Organizer with Bins, Organizer with Bins, Storage Organizer with Bins

—Previous Post

amazon basics Nicotine Polacrilex Lozenge User Guide

Next Post—

amazon basics Touch Screen Electronic Lever + RFID User Guide

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.