



amazon basics Dry Erase Mobile Presentation Easel User Guide

[Home](#) » [amazon basics](#) » amazon basics Dry Erase Mobile Presentation Easel User Guide 

Contents


- [1 amazon basics Dry Erase Mobile Presentation Easel](#)
- [2 IMPORTANT SAFEGUARDS](#)
- [3 Cleaning and Maintenance](#)
- [4 pacifications](#)
 - [4.1 FEEDBACK AND HELP](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)








amazon basics Dry Erase Mobile Presentation Easel




Dry Erase Mobile Presentation Easel, Magnetic, Black






Adjust Tilt Angle



Attach Flipchart Pad / Bloc-Papier / Flipchart-Block



IMPORTANT SAFEGUARDS

- Read product these is passed instructions to a third carefully party, and then retain these them for instructions future must use. be If this included.

When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

- Use only with non-permanent markers.
- Place the product on a flat, stable surface.
- To avoid tripping, place the product away from areas where people pass by frequently.

Before First Use

- Risk of suffocation!

- Keep any packaging materials away from children -these materials are a potential source of danger, e.g. suffocation.
- Check for transport damages

Cleaning and Maintenance

Cleaning

- To erase whiteboard marker, use whiteboard eraser or whiteboard cleaner (not included).
- Clean only when erased.
- To clean, wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

Maintenance

Check the components regularly to make sure all screws and bolts are tightened.

- Store in a cool and dry place away from children and pets, ideally in original packaging
- Avoid any vibrations and shocks.

specifications

- Whiteboard size (W x H): approx. 29 x 42 in (73.7 x 106.7 cm)
- Weight: 20.33 lbs (9.22 kg)


Love it? Hate it? Let us know with a customer review.

Amazon Basics is committed to delivering customer -driven products that live up to your high standards. We encourage you to write a review sharing your experiences with the product.

FEEDBACK AND HELP

- US: [amazon.com/review/review-your-purchases#](https://www.amazon.com/review/review-your-purchases#)
- UK: [amazon.co.uk/review/review-your-purchases#](https://www.amazon.co.uk/review/review-your-purchases#)
- US: [amazon.com/gp/help/customer/contact-us](https://www.amazon.com/gp/help/customer/contact-us)
- UK: [amazon.co.uk/gp/help/customer/contact-us](https://www.amazon.co.uk/gp/help/customer/contact-us)
- Contact Customer Service at +1-866-216-1072

Documents / Resources



[amazon basics Dry Erase Mobile Presentation Easel](#) [pdf] User Guide
 Dry Erase Mobile Presentation Easel, Dry Erase Mobile, Presentation Easel, Easel Dry Erase,
 Dry Erase, Mobile Dry Erase