



Amazon Echo Dot (4th Generation) User Guide

[Home](#) » [Amazon](#) » **Amazon Echo Dot (4th Generation) User Guide** 

Contents [[hide](#)]


- [1 Amazon Echo Dot \(4th Generation\)](#)
- [2 Getting to know your Echo Dot](#)
- [3 Alexa is designed to protect your privacy](#)
- [4 Things to try with your Echo Dot](#)
- [5 Give us your feedback](#)
- [6 DOWNLOAD](#)
- [7 Related Posts](#)

Amazon Echo Dot (4th Generation)



USER GUIDE

Getting to know your Echo Dot



Alexa is designed to protect your privacy



Wake word and indicators

Alexa doesn't begin listening until your Echo device detects the wake word (for example, "Alexa"). A blue light lets you know when audio is being sent to Amazon's secure cloud.



Microphone controls

You can electronically disconnect the microphones with one press of a button.



Voice History

Want to know exactly what Alexa heard? You can view and delete your voice recordings in the Alexa app at any time.

These are just a few of the ways that you have transparency and control over your Alexa experience. Explore more at amazon.com/alexaprivacy or amazon.ca/alexaprivacy.

1. Download the Amazon Alexa app




On your phone or tablet, download and install the latest version of the Alexa app from the app store.

Note: Before setting up your device, have your wifi network name and password ready.

2. Plug in your Echo Dot

Plug your Echo Dot into an outlet using the included power adapter. A blue light ring will spin around the bottom. In about a minute, Alexa will greet you and let you know to complete setup in the Alexa app.



Use the power adapter included in the original packaging for best performance.

3. Set up your Echo Dot in the Alexa app

Open the Alexa app to set up your Echo Dot. Log in with an existing Amazon account username and password, or create a new account. If you aren't prompted to set up your device after opening the Alexa app, tap the More icon to add your device manually.

The app helps you get more out of your Echo Dot. It's where you set up calling and messaging, and manage music, lists, settings, and news.

For help and troubleshooting, go to Help & Feedback in the Alexa app or visit www.amazon.com/devicesupport.

Things to try with your Echo Dot

Enjoy music and audiobooks

Alexa, play today's hits on Amazon Music.

Alexa, play my book.

Get answers to your questions

Alexa, how many kilometers are in a mile?

Alexa, what can you do?

Get news, podcasts, weather, and sports

Alexa, play the news.

Alexa, what's the weather this weekend?

Voice control your smart home

Alexa, turn off the lamp.

Alexa, turn up the thermostat.

Stay connected

Alexa, call Mom.

Alexa, announce "dinner is ready."

Stay organized and manage your home

Alexa, reorder paper towels.

Alexa, set an egg timer for 6 minutes.

Some features may require customization in the Alexa app, a separate subscription, or an additional compatible smart home device.

You can find more examples and tips in the Alexa app.

Give us your feedback

Alexa is always getting smarter and adding new skills. To send us feedback about your experiences with Alexa, use the Alexa app, visit www.amazon.com/devicesupport, or simply say, "Alexa, I have feedback."

DOWNLOAD

Amazon Echo Dot (4th Generation) User Guide – [[Download PDF](#)]
