



amazon B07WV5WN7B Wireless Keyboard User Guide

[Home](#) » [Amazon](#) » amazon B07WV5WN7B Wireless Keyboard User Guide 

Contents

- [1 amazon B07WV5WN7B Wireless Keyboard](#)
- [2 IMPORTANT SAFEGUARDS](#)
- [3 Product Description](#)
- [4 Installation](#)
 - [4.1 LED Indicator](#)
- [5 Cleaning and Maintenance](#)
 - [5.1 FCC Compliance Statement](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



amazon B07WV5WN7B Wireless Keyboard



IMPORTANT SAFEGUARDS

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

- Never use this product if damaged.
- Do not insert any foreign objects into the inside of the casing.
- Protect the product from extreme temperatures, hot surfaces, open flames, direct sunlight, water, high humidity, moisture, strong jolts, flammable gases, vapours and solvents.
- Keep this product and its packaging out of the reach of children and pets.


Battery Safety Advice

- Keep batteries out of the reach of children.
- Do not mix old and new batteries or batteries of different types or brands.
- Do not dispose of batteries in fire.
- Store unused batteries in their original packaging away from metal objects. If already unpacked, do not mix or jumble batteries.
- Remove batteries from product if it is not to be used for an extended period of time unless it is for emergency purposes. Exhausted batteries should be immediately removed from product and properly disposed.
- If the battery leaks avoid contact with skin and eyes. Rinse affected areas immediately with plenty of clean water, then consult a doctor.

Intended Use

- This product is a wireless computer peripheral intended for interacting with your desktop/laptop.

Product Description




1. To turn on the Media player program.
2. To decrease volume
3. To increase volume
4. To mute the sound
5. Previous track
6. Next track
7. To play/pause media playback
8. To stop media playback
9. To start the default Web browser and load the home page
10. To start the default e-mail client
11. To open up the folder 'My Computer'
12. * To open 'My favorite' when inside the browser
13. LED indicator Caps Lock on
14. LED indicator Number Lock on
15. **LED indicator** Low battery and pairing indicator
16. To enable the second function of the Function keys
17. CONNECT button To establish pairing with the nano receiver
18. Battery cover
19. Nano receiver

NOTICE: Press Fn + any function key (1 through 12) to trigger the secondary function of each key.

Installation

Installing the Batteries



1. Remove the battery cover.
2. Insert the batteries correctly with regard to polarity (+ and -) marked on the battery and the product.
3. Place the cover back over the battery compartment.
 - **Pairing:** Plug the nano receiver into a USB port of your computer. The connection between keyboard and nano receiver should occur automatically.


If the connection between keyboard and the receiver fails or is interrupted, proceed as follows:

1. Remove the nano receiver from the USB port and plug it back in.
2. Press the CONNECT button of the keyboard.

NOTICE: The LED indicator on the keyboard blinks when it is in pairing mode and stops blinking when it is successfully paired with the receiver.

LED Indicator

LED is on for 10 sec. Power ON.



LED blinking

During pairing (The LED goes off when pairing is successful or if it keeps failing for longer than 10 seconds.)

LED blinks for 10 sec. Low battery warning.

Cleaning and Maintenance

NOTICE: Switch the product off before cleaning.

NOTICE: During cleaning do not immerse the electrical parts of the product in water or other liquids. Never hold the product under running water.

Cleaning

- To clean the product, wipe with a soft, slightly moist cloth.
- Dry the product after cleaning.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

Storage

Store the product in its original packaging in a dry area. Keep away from children and pets.

FCC Compliance Statement

1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 1. this device may not cause harmful interference, and
 2. this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

- This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence exempt RSS(s). Operation is subject to the following two conditions:
 1. this device may not cause interference, and
 2. this device must accept any interference, including interference that may cause undesired operation of the device.
- This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.
- This Class B digital apparatus complies with Canadian CAN ICES-3(B) I NMB-3(B) standard.

Simplified EU Declaration of Conformity

- Hereby, Amazon EU Sari declares that the radio equipment type B07WV5WN7B, B0787HH4L4, B0787KRDLQ, B0787HV36B, B0787KN8YX, B0787KRF9W is in compliance with Directive 2014/53/EU.
- The full text of the EU declaration of conformity is available at the following internet address:

Disposal

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimise the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Battery Disposal

Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.

Feedback and Help

Love it? Hate it? Let us know with a customer review.

AmazonBasics is committed to delivering customer driven products that live up to your high standards. We encourage you to write a review sharing your experiences with the product.

US: amazon.com/review/review-your-purchases#



UK: amazon.co.uk/review/review-your-purchases#

US: amazon.com/gp/help/customer/contact-us

UK: amazon.co.uk/gp/help/customer/contact-us



Documents / Resources

  <small>Wireless Keyboard - Quiet and Compact Clavier Sans Fil - Silencieux et Compact Cableless Keyboard - Quiet and Compact Teclado Inalámbrico - Silencioso y Compacto Wireless Keyboard - Quiet and Compact ワイヤレスキーボード 静かコンパクト B07WV5WN7B, B0787HH4L4, B0787KRLDQ, B0787HV36B, B0787KN8YX, B0787KRF9W, W ireless Keyboard</small>	amazon B07WV5WN7B Wireless Keyboard [pdf] User Guide B07WV5WN7B, B0787HH4L4, B0787KRLDQ, B0787HV36B, B0787KN8YX, B0787KRF9W, W ireless Keyboard
--	---