


amazon Fire TV Cube Hands-Free Streaming Device **Instructions**

Home » Amazon » amazon Fire TV Cube Hands-Free Streaming Device Instructions

amazon Fire TV Cube Hands-Free Streaming **Device Instructions**

POSITION YOUR FIRE TV CUBE



PLACE FIRE TV CUBE 1FT AWAY FROM ANY SPEAKERS,

with the ports facing away from you.

IT SHOULD NOT BE PLACED IN A CLOSED CABINET.


Fire TV Cube needs to hear your commands.

To control components that are in a closed cabinet, use an IR extender (sold separately).

Contents

- 1 MEET YOUR FIRE TV CUBE
- 2 CONNECT YOUR FIRE TV CUBE
- **3 LEARN ABOUT THE BUTTONS**
- 4 FIRE TV ALEXA VOICE
- **REMOTE**
- **5 POWER UP YOUR REMOTE**
- **6 WATCH WITH ALEXA**
- 7 DO EVEN MORE WITH ALEXA
- **8 ENHANCE YOUR EXPERIENCE**
- 9 PRIVACY CONTROL
- **10 ACCESSIBILITY**
- 11 Documents / Resources
 - 11.1 References

MEET YOUR FIRE TV CUBE



*Important: High-speed HDMI Cable is not included in box.

Also included: remote, power adaptor, AAA batteries

CONNECT YOUR FIRE TV CUBE



Tip: Using the included remote control, go to the Settings menu in Fire TV Cube, and select your network from the list displayed. If your network is hidden, enter your network name.

Tip: If you see a lock icon, your Wi-Fi network requires a password, so make sure you have it available before setup. This password is not your Amazon account password.

For more troubleshoot ing and information, go to www.amazon.com/devicesupport.

LEARN ABOUT THE BUTTONS



ACTION

Multi-function button used to wake Alexa.



MICROPHONE ON/OFF

Press the microphone on/off button to mute.



VOLUME

Control the internal speaker of Fire TV Cube.

FIRE TV ALEXA VOICE REMOTE



POWER UP YOUR REMOTE



1. INSERT BATTERIES POWER UP YOUR REMOTE

Use your thumbs to slide open the back of remote, then insert included batteries.

Tip: If remote battery compartment will not open, clean backing with a moist cloth and dry thoroughly.

2. REMOTE

The remote can now control Fire TV Cube. To control other devices, follow the on-screen steps.

Tip: If remote isn't discovered, press and hold Home @ button until the LED flashes amber.

WATCH WITH ALEXA

Alexa makes it easy to find, launch and control content. Simply say "Alexa" to Fire TV Cube or press the voice button on your remote.



DO EVEN MORE WITH ALEXA

Alexa can help you unwind, control your smart home devices, and keep you better informed, organized and connected.



ENHANCE YOUR EXPERIENCE

ETHERNET CABLE

If you prefer a wired Ethernet connection instead of Wi-Fi, please connect the Ethernet cable (not included) to the network port.

IR EXTENDER

If you are using an IR extender (sold separately) to control devices in a closed cabinet, place the IR extender on the same shelf as the devices you want to control.

CABLE/SATELLITE BOXES

You can connect your Cable/Satellite set top box, Gaming console or DVD/Blu-Ray player to the HDMI input port to easily switch input using Alexa and view content from these devices.

ALEXA HOME THEATRE

For an immersive audio experience, wirelessly pair your Fire TV Cube with compatible Echo devices. To learn more, go to: www.amazon.ca/help/firetv/alexa-home-theater

VIDEO CALLING

Connect a compatible USB webcam to make two-way video calls. To learn more, go to www.amazon.ca/help/firetv/twowaycalling/qsg

PRIVACY CONTROL

PRIVACY CONTROL

- Turn the mis off by pressing the microphone on/off button.
- See when Alexa is recording and sending your request to Amazon's secure cloud via the blue indicator light.

MANAGE YOUR VOICE HISTORY

You can view, hear and delete the recordings associated with your account in the Alexa app at any time. To delete your voice recordings, say "Alexa, delete what I just said." "Alexa, delete everything I've ever said."

ACCESSIBILITY



www.amazon.com/help/firetv/accessibility

If you need accessibility help, go to: www.amazon.ca/help/firetv/accessibility

Documents / Resources



<u>amazon Fire TV Cube Hands-Free Streaming Device</u> [pdf] Instructions Gen3, Fire TV Cube Hands-Free Streaming Device, TV Cube Hands-Free Streaming Device, Hands-Free Streaming Device, Streaming Device

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.