



# Amico 48FT LED Single Filament String Lights User Manual

[Home](#) » [Amico](#) » Amico 48FT LED Single Filament String Lights User Manual 

## Contents


- [1 Amico 48FT LED Single Filament String Lights](#)
- [2 PACKAGE CONTENTS](#)
- [3 SPECIFICATION](#)
- [4 OPERATION INSTRUCTION](#)
- [5 NOTE](#)
- [6 REPLACEMENT](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



## Amico 48FT LED Single Filament String Lights



## PACKAGE CONTENTS



string  
lights \* 1




adapter with  
control \* 1



remote  
control \* 1



spare  
bulbs \* 3



manual \* 1


- string lights \* 1
- adapter with control \* 1
- remote control \* 1
- spare bulbs \* 3
- manual \* 1

## SPECIFICATION

- Item Data
- **Total** Length 48ft
- **Power** Max 15W total
- **Input** 100-240V ~ 50/60Hz
- **Number of Bulbs** 15 bulbs + 3 spare bulbs
- **Bulb type** S14, E26, single filament bulb
- **Battery type of remote** controller CR2025
- **Remote Control** Distance Up to 40ft
- **Warranty** 1 year

## OPERATION INSTRUCTION

**How to use by controller** You can press the button to turn on/off the lights,also you can choose the color mode by the button. Note, you can not adjust the brightness and speed by the controller.



### How to use by remote control



## NOTE


1. Please cut off the power supply before installation;
2. Please make sure each bulb is firmly screwed into the socket during installation;
3. This product can only be used with the adapter included in the package, otherwise, it may cause product failure;
4. Only the string lights are waterproof, the remote controller is not,
5. The remote control panel must be kept clean, otherwise, the keys may not be sensitive;
6. Do not use detergent or other solvents to clean the light, keep the lamp away from fire, heat.

## REPLACEMENT

The replacement method is as follows: (please turn off the power first, and then replace the LED bulb, we supply 3 spare bulbs)

1. Unscrew the bulb.
2. Remove the old LED bulb and replace it with a new one.
3. Tighten the bulb.
4. Complete the replacement

## Documents / Resources

	<p><a href="#">Amico 48FT LED Single Filament String Lights</a> [pdf] User Manual 48FT, LED Single Filament String Lights, 48FT LED Single Filament String Lights</p>
---	---