


amstrad
GC-256 Handheld
Game Console



amstrad GC-256 Handheld Game Console Instruction Manual

[Home](#) » [Amstrad](#) » amstrad GC-256 Handheld Game Console Instruction Manual 

Contents

- [1 amstrad GC-256 Handheld Game Console](#)
- [2 Overview](#)
- [3 Specifications](#)
- [4 Instructions for Built-in Batteries](#)
- [5 Product Overview](#)
- [6 Class III Equipment](#)
- [7 Starting the Device](#)
- [8 FAQs](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)




amstrad GC-256 Handheld Game Console



Overview

The GameBox GB-256 by Amstrad is a handheld gaming device featuring a 2.8-inch screen and comes with 256 built-in games. It is powered by a 300mAh battery.

ACCESSORIES




Specifications

Feature	Details
Screen Size	2.8 inch – 7 cm
Battery Capacity	300 mAh
Autonomy	150 min
TV Autonomy	300 min

Instructions for Built-in Batteries

- Avoid exposing batteries to excessive heat, such as sunlight or fire.
- Do not open the product.
- Stay close to earphones while charging.
- Interrupt charging immediately if overheating occurs.

Product Overview



SAFETY INSTRUCTIONS

Please read this manual carefully, as it contains important information on installation and use of the unit.

- Ensure that the mains voltage is suitable for this device and does not exceed the supply voltage indicated on the device nameplate.
- To avoid risk of fire or electric shock, do not expose this unit to rain or moisture, or moisture. Make sure that no flammable objects are in the vicinity of the appliance during operation.
- Do not place naked flames on the unit.

- The unit is intended for use in temperate climates. The ambient temperature must not exceed 40°C. Do not operate the unit at higher temperatures.
- In the event of a malfunction, switch off the unit immediately. Never attempt to repair the unit yourself. Improper repairs may result in damage or malfunction. Contact an authorized service center.
- Supervise children to ensure that they do not play with the device.

FEATURES

- Screen 2.8 inch – 7cm
- Input power 5V – 1A
- Autonomy 150 min
- TV autonomy 300 min
- Battery capacity 300 mAh

INSTRUCTIONS FOR BUILT-IN BATTERIES

- Batteries must not be exposed to excessive heat, such as sunshine, fire, or similar sources. Risk of explosion, fire or fire hazard!
- Do not open the product
- Stay close to the earphones when recharging. In the event of extreme heat, interrupt the process immediately and contact your dealer.

CLASS III EQUIPMENT

Safety extra-low voltage (SELV) or protective low voltage (PLV) power supply, ungrounded masses, safe power supply (safety transformer).

NOTE

1. Before connecting to a TV, make sure that your TV and the unit are turned off.
2. Switch the channel on the TV to the audio/video channel.



Class III Equipment

Safety extra-low voltage (SELV) or protective low voltage (PLV) power supply, ungrounded masses, safe power supply (safety transformer).

START

Push the «ON/OFF» button, select the game, and press the «Start» button.

RESET

Each time you press the «Reset» button, the selection screen reappears. If the game freezes, press the « Reset» button to restart it.

Waste Disposal

- Do not dispose of electronic devices with household waste.
- Recycle electronic products and packaging at designated collection points.
- Contact local authorities for disposal information.

Connecting to a TV

1. Ensure the TV and unit are turned off before connecting.
2. Switch the TV to the audio/video channel.

Starting the Device

1. Press the **ON/OFF** button, select a game, and press the Start button.

Resetting the Device

If the game freezes, press the Reset button to restart.

Compliance Declaration

The GameBox GB-256 complies with the directive 2014/30/UE. A full compliance statement is available at <https://www.churchill.world/telechargement>.

Contact Information

For assistance, contact amstrad@churchill.world.

A full compliance statement is available by download or email at: direction@churchill.world
<https://www.churchill.world/telechargement>


SAS CHURCHILL
20 RUE SAINT GILLES
75003 PARIS - FRANCE
FR0581521394 / RCS Paris 811 221 894
Email : direction@churchill.world
Fait à Paris (France), le 17/07/2024

Download instructions for use

Gebruikershandleidingen downloaden

<https://churchill.world/telechargements>



ASSISTANCE

amstrad@churchill.world

FAQs

- **How long does the battery last?**

The battery lasts up to 150 minutes for regular use and 300 minutes when connected to a TV.

- **Can I replace the battery?**

No, the battery is built-in and should not be replaced by the user.

- **Where can I find the user manual?**

The user manual can be downloaded from <https://churchill.world/telechargements>.

Certify and declare responsibility only for the following products:


Brand: AMSTRAD

Type or model : GAMEBOX-GB256

Type model using | Factory model number : GC-26

Designation : Console de jeux

Documents / Resources

	<p>amstrad GC-256 Handheld Game Console [pdf] Instruction Manual</p> <p>GC-256 Handheld Game Console, GC-256, Handheld Game Console, Game Console, Console</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.