



AMTAST AMT210 Electronic Timer Instruction Manual

[Home](#) » [AMTAST](#) » AMTAST AMT210 Electronic Timer Instruction Manual 

AMTAST

AMT210 Electronic Timer Operation Manual

Contents

- [1 Functional Features](#)
- [2 Operation method](#)
- [3 Caution](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Functional Features

1. Forward/backward timer and clock function
2. Maximum timing range 99 minutes 59 seconds
3. 12/24 hour clock
4. Can be magnetically or vertically positioned
5. Ultra-low power consumption, operating voltage 1.5V (AG13) × 1 pc

Operation method

1. Open the battery cover, take out the battery, distinguish the positive and negative pole (positive pole facing up) and put back the battery and battery cover, the machine is ready to use.
2. When the clock state, press START/STOP key to switch to the countdown function, and press M/S\START/STOP to return to the clock state.

3. To set the clock, press S in the clock state to switch between 12/24 hours.
- Press and hold M for about 2 seconds to enter the hour setting, then press S to adjust the hour position, press S to speed up the value, press M again to enter the minute setting, then press S again to adjust the minute position, press S to speed up the value, press M again to exit when finished.
4. Countdown setting, press S to set seconds in the countdown state, press and hold to speed up the value to adjust. Press M to set the minutes, and press and hold to speed up the value. After setting, press START/STOP to start the timer, press again to pause, the timer will sound about 60 seconds when it reaches the time you set, press START/STOP again to pause the timer or stop the sound, clear the set timer time and press M\S to clear back to zero.
5. Press START/STOP to start the timer in the timer mode. 6.
6. Note: In the timing state, it will automatically return to the clock state after 5 minutes of inactivity.

Caution

- 1*If the machine has a bad stop, please take out the battery for about 2 seconds and reinstall it.
- 2*After the battery is used, please put it back to the place designated by the government.

AMTAST

Documents / Resources

<div><div>AMT210 Electronic Timer</div><div>Operation Manual</div><div><div>1. Product Features</div><div>1.1 Precise timing accuracy and stable function</div><div>1.2 Convenient setting and easy to use</div><div>1.3 Low power consumption</div><div>1.4 Wide temperature range, up to 60°C</div><div>1.5 High reliability, up to 100,000 cycles</div><div>1.6 Low cost, suitable for mass production</div><div>2. Operation Method</div><div>2.1 Power On/Off</div><div>2.2 Setting Method</div><div>2.3 Timing Method</div><div>2.4 Countdown Method</div><div>2.5 Alarm Method</div><div>2.6 Sound Method</div><div>2.7 Sleep Method</div><div>2.8 Reset Method</div><div>2.9 Clear Method</div><div>2.10 Backlight Method</div><div>3. Maintenance</div><div>3.1 Battery Replacement</div><div>3.2 Cleaning</div><div>3.3 Storage</div><div>3.4 Disposal</div><div>4. Safety</div><div>4.1 Precautions</div><div>4.2 Warnings</div><div>4.3 Prohibitions</div><div>4.4 Notes</div><div>5. Appendix</div><div>5.1 Glossary</div><div>5.2 Index</div><div>5.3 About This Manual</div><div>5.4 Copyright</div><div>5.5 Revision History</div></div></div>	<div><div>AMTAST AMT210 Electronic Timer [pdf] Instruction Manual</div><div>AMT210 Electronic Timer, AMT210, Electronic Timer, Timer</div></div>
--	--

References

- [User Manual](#)