



Anc China ANCBS949R sound logic xt Bluetooth Speaker Instruction Manual

[Home](#) » [Anc China](#) » Anc China ANCBS949R sound logic xt Bluetooth Speaker Instruction Manual 

Contents

- 1 Anc China ANCBS949R sound logic xt Bluetooth Speaker Instruction Manual
- 2 Getting Started
- 3 Package Contents
- 4 Key Features
- 5 Safety Instructions
- 6 Description of parts
- 7 LED Display
- 8 INSTRUCTIONS FOR USE
 - 8.1 Charging the Karaoke Bluetooth Speaker
- 9 Listening to Wireless Music
- 10 Listening to Music using USB/ Micro SD (TF) Card Slot
- 11 Listening to Music using AUX-In
- 12 Listening FM radio
- 13 Color Changing LED lights in front of speaker
- 14 Using the Microphone
- 15 Do's and Don'ts
- 16 Care and maintenance
- 17 Product Specifications:
- 18 FCC Instructions
- 19 Documents / Resources
- 20 Related Posts

SOUNDLOGICTM XT



Getting Started

- Remove the product from the box.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list

Package Contents

- Bluetooth Speaker
- AUX/USB rechargeable cable
- Wired Microphone
- Instruction Manual

Key Features


- Portable Multi-function Bluetooth Speaker with LED lights
- Connect & stream wireless music anytime, anywhere
- Delivers rich sound with bass
- Built-in 2×4 inch speaker drivers delivers superior sound with bass
- Wireless range up to 10 Meters
- Multi-function: Bluetooth, FM radio, USB slot, Micro-SD card slot & AUX jack
- Built-in USB rechargeable battery (1500mAh) supports non-stop play back of up to over 2 hours
- Built-in microphone input AUX/USB cable included
- Wired Microphone included

Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician.
- Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This unit is not a toy.

Description of parts



LED Display



Number	Item	Function
1	MIC IN	Microphone input
2	ON/OFF SWITCH	Turn the speaker On or Off
3	PREVIOUS TRACK/STATION	Bluetooth/USB/SD card mode: Skip to previous track FM radio mode: Skip to the previous already saved radio station
4	PLAY/PAUSE/SCAN	PLAY/PAUSE, scan FM radio stations (only in FM radio mode)
5	Micro SD (TF) slot	Micro SD (TF) card input
6	NEXT TRACK/STATION	Skip to the next track in Bluetooth/USD/SD card mode/Skip to the next radio station in FM radio
7	MODE/LIGHT button	Short press to change the mode between Bluetooth /USB-Micro SD (TF)/AUX-In/FM radio Long press to turn on/off the color changing LED lights

INSTRUCTIONS FOR USE

Charging the Karaoke Bluetooth Speaker

For best results, fully charge the unit before use.

1. Plug the Micro USB end of the included ALUX/US8 charging cable into the charging port of the speaker. Plug the other end into a US8 port on your computer or USB power source with 1A Output.
2. Red charging indicator near the charging port will on while charging, and turns off when fully charged

Note: Before using the unit for the first time, please charge it for around 4-5 hours or until the red charging indicator turns off.

Turn On/off the Speaker

Slide the ON/OFF SWITCH to ON position to turn on the unit with color changing LED lights, or OFF position to turn off the unit.

Pairing your device with the Speaker

Your Bluetooth Speaker can stream wireless audio from any Bluetooth enabled device within the range of up to 10m. Simply follow the below steps.

1. Rotate the volume knob to your favorite sound level.
2. Turn ON the speaker
3. LED display will show 'HIF' and then 'bLUE' and indication tone would be heard. The speaker now n pairing
moc0
4. Turn on the Bluetooth on your Mobile Phone are Tablet or Computer
5. It will search for available Bluetooth devices.

- Bluetooth Speaker would appear as "SL SUPER-BASS ", in the its of searched devices. Select it from the available list of devices
- If required, enter the passwords '0000' to confirm pairing
- Once paired successfully, another indication tone would be heard.
- If you fail to pair it within a few seconds o you want to pair it with a new device, please repeat above steps.

Play your favor item song un the Bluetooth source device and music would now stream through he speaker.

Listening to Wireless Music

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the speaker to stream wireless music. Once it is paired, play music from your device.

Function	Operation	Button
Increase / Decrease Volume	Playing music	Turn VOLUME KNOB to adjust the volume to your desired level, or Adjust volume from the source device (in Bluetooth mode only).
Pause	Playing music	Short press PLAY/PAUSE/SCAN button once to pause music
Play	Pause	Short press PLAY/PAUSE/SCAN button once to resume music
Previous track	Playing music	Short press the PREVIOUS TRACK/STATION button to the previous track
Next track	Playing music	Short press the NEXT TRACK/STATION button to the next track

Listening to Music using USB/ Micro SD (TF) Card Slot

- Rotate the volume knob to your favorite sound level.
- Turn on the speaker.
- Insert USB flash drive into the USB slot or Micro SD (TF) card into the Micro SD (TF) card slot accordingly. An indication tone would be heard, LED display will show 'USb' or 'tF' and then MP3 with music would play automatically with LED display showing track number & then music time.
- Short press the NEXT TRACK/STATION button or PREVIOUS TRACK/STATION button to move forward or backward on your playlist.
- Short press PLAY/PAUSE/SCAN button to Play or Pause a track.

Listening to Music using AUX-In

- Rotate the volume knob to your favorite sound level.
- Turn on the speaker.

3. Insert the Micro USB end of the included AUX/USB rechargeable cable into the . Aux in. Plug the AUX to the audio device (such as phone/ MP3 Player/ computer / tablet / etc...).
4. Short press the MODE button each time until it reaches Aux-in mode, LED display will show AUR, and an indication tone would be heard. s.
5. Select your favorite song at the source device to play (**Note:** While using AUX-In function, except volume function, all functions such as playing next/previous track can be controlled only through your source device).

Listening FM radio

1. Rotate the volume knob to your favorite sound level.
2. Turn on the speaker.
3. Short press the MODE button each time until it reaches FM radio mode, LED display will show a FM radio frequency with sound.
4. Press and hold the PLAYWPAUSE/SCAN button 2 seconds for searching and recording all radio stations within frequency range 87.5-108MHz.
5. Short press the NEXT TRACK/STATION button or PREVIOUS TRACK/STATION button for listening next or previous already saved radio station.

Tips

1. Short press the MODE button to switch different functions of the speaker. The functions are -Bluetooth /USB-Micro SD (TE)/ AUX/ FM radio.
2. When the speaker is not in use, turn OFF the device to save the battery power.
3. Do not overcharge the speaker.

Color Changing LED lights in front of speaker

1. Turn on the speaker.
2. Long press the LIGHT button can turn on/off the color changing LED lights.

Using the Microphone

1. Turn on the speaker.
2. Insert the plug of the Microphone (included) into the MIC INPUT of the speaker.
3. Turn on the Microphone, and speak for microphone operation or sing for Karaoke operation.
4. Turn VOLUME KNOB to adjust the desired level.

Do's and Don'ts

- Do not play music at excessive levels as damage to hearing and/or equipment may result.
- Do not use outdoors in wet or in damp surrounding.

Care and maintenance

Clean the unit with a soft, dry cloth. Never use chemicals or hard abrasives. Keep this unit away from wet or damp surroundings.

Product Specifications:

- Bluetooth version 5.0
- Unit size :Dia. 160mm x 385mm H
- Unit weight . 1.19kg
- Power input : DC 5V
- Charging time: 4-5 hours
- Play time :L.5 to 2.5 hours (maximum volume)
- Bluetooth range: 10m
- FM frequency range : 87.5-108MHz
- Built-In Rechargeable Lithium Battery: 3.7V 1500mAh 10m

(Note: Battery life & charging time may vary based on usage, types of devices connected & wireless distance).

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low. Battery dead	Adjust source volume. Charge battery.
No sound	Volume in minimum position. The connected device is not in play mode. Input source incorrect.	Turn VOLUME knob to increase the volume. Play the music in the connected device and make sure the volume level is in high level. Press the MODE button to set the input source to the desired function.
Sound distortion	Volume level too high	Turn VOLUME knob to decrease the volume.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.

- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

	<p>Anc China ANCBS949R sound logic xt Bluetooth Speaker [pdf] Instruction Manual ANCBS949R sound logic xt Bluetooth Speaker, sound logic xt Bluetooth Speaker, xt Bluetooth Speaker</p>
---	---