

ANCOBER ACB-001 Wireless Bluetooth Speaker User Manual

Home » ANCOBER » ANCOBER ACB-001 Wireless Bluetooth Speaker User Manual

Contents

- 1 ANCOBER ACB-001 Wireless Bluetooth Speaker
- **2 Product Overview**
- 3 Packing content
- **4 Specifications**
- **5 Getting Started**
- **6 Features**
- **7 Product Overview**
- 8 Buttons and controls
- 9 LED Indicators
- 10 Pairing your device via Bluetooth
- 10.1 How to pair dual(TWS) ACB-001 speakers?
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts

ANCOBER

ANCOBER ACB-001 Wireless Bluetooth Speaker



Specifications

Model Name: ACB-001Bluetooth version: 5.3

· Waterproof: IPX4 certified waterproof

Range: 10m/33ftInput: DC 5VOutput: 15W

Battery: 3.7V/2000mAh Li-ionNet Weight: 0.75 lb (342.40g)

• Unit dimension: 7.28 x 2.76 x 3.14 inch

• Playtime: 8-12 hours (The volume at 100% – 50%)

• Charging time: Less than 4 hours

· Warranty: One-year

• Bluetooth name: ACB-001

Getting Started

- 1. Unbox the unit first.
- 2. Remove any packing from the product.
- 3. Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Features

- Wireless Bluetooth connectivity to iPad, iPod, Touch Android, Windows Phone, Blackberry, smartphones, tablets, computers, and more.
- Multi-Color Lights that beat to the beat of music.
- Play music through Bluetooth and Auxiliary.
- Play 3D stereo surround songs via 2-speaker pairing.
- Microphone to receive calls.

• Rechargeable built-in battery.

Product Overview

Buttons and Controls

| N o. | Buttons | Function | How to |
|---------|----------------------------------|---|--|
| 1 | Turn on/off | Power on or off the speaker | Press and hold |
| 2 | Increase the volume | Adjust the volume level up | Press |
| 3 | Decrease the volume | Adjust the volume level down | Press |
| 4 | Skip to the next track | Move to the next track in the playlist | Press |
| 5 | Skip to the previous tr ack | Move to the previous track in the playlist | Press |
| 6 | Play / Pause | Start or pause the playback | Press |
| 7 | Answer / Hang up the phone | Answer or end a phone call | Press |
| 8 | Change LED light mode | Switch between different LED light modes | Press |
| 9 | Turn on / off the LED li ght | Turn the LED light on or off | Press multiple times until the light turns off |
| 1 0 | Pairing dual speakers | Pair two speakers together for stereo sound | Press and hold any M button |
| 1 | LED indicator | Show the status of the Bluetooth connection a nd charging | N/A |
| 1 2 | Charge the speaker | Charge the speaker using the provided USB T ype C cable | Insert the charging cable |
| 1 3 | Audio auxiliary line inp ut port | Connect an external device using an AUX-in c able | N/A |
| 1 4 | Anti-slip rubber block | Prevent the speaker from slipping | N/A |
| 1 5 | LED Light | Illuminate with multi-color lights | N/A |

LED Indicators

• Bluetooth is not connected: Blue light fast flashing

• Bluetooth is connected and not playing music: Blue light hold on

• Bluetooth is connected and playing music: Blue light slow flashing

• Charging: Red light steady on

· Charged full: Red light off

Pairing your device via Bluetooth

- 1. Enable Bluetooth on your device and search for the speaker.
- 2. Select ACB-001 on the Bluetooth list.
- 3. Once paired, you can see the connected status on your device.

How to pair dual(TWS) ACB-001 speakers?

- 1. Turn on both speakers.
- 2. Press and hold the M button of either speaker until you hear a cue sound, which means the Bluetooth of the two speakers is connected to each other. (If it is not successful, repeat steps 1-2)
- 3. Open your device's Bluetooth and search for a model named ACB-001, then connect to it.

How do I de-interconnect Bluetooth between two speakers?

Press and hold the M button of either speaker until you hear a cue sound, which means the Bluetooth of the two speakers is de-interconnected from each other.

FAQ

Q: How long is the warranty?

• A: The warranty for the ANCOBER Wireless Bluetooth Speaker is one year.

Q: How long does the battery last?

• A: The battery can last for 8-12 hours of playback time, depending on the volume level.

Q: Is the speaker waterproof?

• A: Yes, the speaker is IPX4 certified waterproof.

Packing content

- ACB-001 Bluetooth Speaker X 1
- USB Type C Charge Cable x 1
- AUX-in Cable x 1
- User Manual x 1

Specifications

Model name: ACB-001Bluetooth version: 5.3

Waterproof: IPX4 certified waterproof

• Range: 10m/33ft

Input: DC 5VOutput: 15W

Battery: 3.7V/2000mAh Li-ionNet Weight: 0.75 lb (342.40g)

• Unit dimension: 7.28 x 2.76 x 3.14 inch

• **Playtime**: 8-12hours (100% volume – 50% volume)

• Charging time: Less than 4 hours

• Warranty: One-year

• Bluetooth name: ACB-001

Getting Started


· Unbox the unit first.

- Remove any packing from the product.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Features

- Wireless Bluetooth connectivity to iPad, iPod, Touch Android, Windows Phone, Blackberry, smartphones tablets, computers, and more.
- Multi-Color Lights and also can beat to the beat of music.
- You can play music through Bluetooth and Auxiliary.
- Play 3D stereo surround songs via 2-speaker pairing.
- Microphone to receive calls.
- · Rechargeable built-in battery.

Product Overview



Buttons and controls

| No. | Buttons | You want to | How to |
|-----|-----------------|----------------------------|-------------------|
| 1 | Ç | Turn on/off | Press and hold on |
| 2 | + | Increase the volume | Press |
| 3 | _ | Decrease the volume | Press |
| 4 | >> | Skip to the next track | Press |
| 5 | | Skip to the previous track | Press |
| | | Play / Pause | Press |

| 6 | | Answer / hang up the phone | Press |
|----|-----------------|---------------------------------|--|
| | Charles control | Change LED light mode | Press |
| 7 | M | Turn on / off the LED light | Press multiple times until the light off |
| | | Pairing dual speakers | Press and hold any M but ton |
| 8 | 0 | LED indicator | |
| 9 | 0 | Charge the speaker | Insert the charging cable |
| 10 | 0 | Audio auxiliary line input port | |
| 11 | | Anti-slip rubber block | |
| L | | LED Light | |

LED Indicators

- · Bluetooth is not connected: Blue light fast flashing
- Bluetooth is connected and does not play music: Blue light hold on
- Bluetooth is connected and plays music: Blue light slow flashing
- Charging: Red light steady on
- Charged full: Red light off

Pairing your device via Bluetooth

- 1. Enable Bluetooth on your device and search for the speaker.
- 2. Select ACB-001 on the Bluetooth list.
- 3. Once paired, you can see the connected status on your device.

How to pair dual(TWS) ACB-001 speakers?

- 1. Turn on the 2 speakers
- 2. Press and hold on to the "M" button of either speaker and you will hear a cue sound, which means the

Bluetooth of the two speakers are connected to each other. (If it is not successful, you need to repeat steps 1-2)

3. Open your device's Bluetooth and search for one model named: ACB-001, and connect it is ok.

How do I de-interconnect Bluetooth between two speakers?

• Press and hold on to the "M" button of either speaker and you will hear a cue sound, which means the Bluetooth of the two speakers de-interconnect each other.

Dear Valued Customer

- Thank you for choosing our product. Your satisfaction is the motivation for us to develop our little start-up in this highly competitive market.
- Whatever you need, we're here to help.
- Any concerns or problems, please feel free to contact us. we'll try our best to respond within 24 hours.

Documents / Resources



ANCOBER ACB-001 Wireless Bluetooth Speaker [pdf] User Manual

ACB-001 Wireless Bluetooth Speaker, ACB-001, Wireless Bluetooth Speaker, Bluetooth Speak er, Speaker

References

• User Manual

Manuals+.