Manuals+ — User Manuals Simplified.

Ancober ACB001 Wireless Bluetooth Speaker Instruction Manual

Ancober ACB001 Wireless Bluetooth Speaker Instruction Manual

Contents

Product Overview

Function control
non-slip rubber panel

LED Light Mode

Skip to the Next Song

Volume +

LED Indicator

Switch/Pause/Play

Volume -

Skip to Previous Song

How does the button work?

1. **Switch/Pause/Play Button:** Long press/Press once/Press once
2. **Skip to the Next Song:** Press once
3. **Skip to Previous Song:** Press once
4. **Volume:** Press once
5. **Volume:** Press once
6. **LED Light Mode:** Press once
7. **LED Indicator:**

a. The LED indicator light flashes fast when the speaker is turned on, and flashes slowly after the Bluetooth is connected.
b. The indicator light is red when the audio is charging, and goes off when charging is complete.

How to Pair 2 speakers?

Turn on both of Bluetooth speakers, press and hold the M button of either one of device, and when you hear a tip sound, the pairing is successful. If want to cancel the pairing of two devices, the operation is the same.

Ancober

Documents / Resources

Ancober ACB001 Wireless Bluetooth Speaker [pdf] Instruction Manual
71Kv, ACB001, E4l6L, ACB001 Wireless Bluetooth Speaker, Wireless Bluetooth Speaker, Bluetooth Speaker, Speaker

References

- **User Manual**