

Anderic RC-A1R Universal Roku Voice Remote Control



Anderic RC-A1R Universal Roku Voice Remote Control Instruction Manual

[Home](#) » [Anderic](#) » Anderic RC-A1R Universal Roku Voice Remote Control Instruction Manual 

Contents

- [1 Anderic RC-A1R Universal Roku Voice Remote Control](#)
- [2 PAIRING INSTRUCTIONS](#)
- [3 Are you still having trouble pairing](#)
- [4 Using The Mobile App](#)
- [5 Using your voice remote](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

ANDERIC

Anderic RC-A1R Universal Roku Voice Remote Control



This remote works with most Roku devices, including Roku Streaming Sticks, Roku Streaming Players, Roku-enabled TVs, and Roku sound bars. This remote replaces many remotes, including but not limited to the RC-AL2, RC-AL7, RC-EL1, RC-EL2, RC-FA1, RC-GZ1, RC-A1R, RC-ALIR, RC-FA5, and RC-81. However, the App Shortcut keys may vary.

PAIRING INSTRUCTIONS

ENTERING PAIRING MODE: Simple pairing (without using an existing remote):



1. Install two AAA batteries into the remote by removing the battery cover, inserting batteries, matching polarity, and replacing the battery cover.
2. The indicator light will flash to indicate that the remote has entered pairing mode. Suppose the indicator light does not flash; press and hold both the Pairing button for 5 seconds. When the indicator light begins flashing, release the key.
3. With your Roku unit powered on, your Roku should detect your remote, begin the pairing process, and display the following message on the screen.

Pairing via Resetting the Roku Device. Do the following:

Note: use the below instructions if the above doesn't work.

1. Power off your Roku by unplugging it from the power source.
2. Install batteries in the remote, then enter pairing mode by pressing and holding Pairing Button for 5 seconds until the indicator light flashes, releasing the key.
3. Return power to your Roku device while the remote is in pairing mode. Wait for the Roku to boot up and return to the home screen, then you should see the onscreen pairing dialogue.


Are you still having trouble pairing

Are you still having trouble pairing?

Software update notice

Before programming the new voice remote, please ensure your device's software is on the latest version. To check if your unit needs an update, follow the below steps using an already paired remote or via the Roku mobile app:


Software update:

1. Return to the main menu by pressing the  key.
2. Click "Settings."
3. Click "System."
4. Click "Software update."
5. Click "Check now."
6. If updates are required, your system will initiate an update.

Pairing your remote

Pairing your remote (by using an existing, already-paired remote/ mobile app):

Note: Follow the steps below if you already have a paired remote or if you are using the Roku mobile app as a remote.

1. Install two AAA batteries into the remote by removing the battery cover, inserting batteries, matching polarity, and replacing the battery cover.
2. Using your existing remote (or the built-in remote from the Roku mobile app), return to the home screen by clicking the  key. The home screen should appear on your TV.
3. Click "Settings" from the menu.
4. Click "Remotes & devices."
5. Click "Add devices."
6. Click "Remote," then "Continue."
7. Select the option on the left labeled "Below power button."



8. Then, follow the onscreen setup to complete the pairing.

Using The Mobile App

Use the Roku Mobile App:

- If the above steps do not work, download the Roku mobile app from your phone's app store.
- After you set up your Roku mobile app, using the built-in remote from the app, follow the instructions above for "Pairing your remote (by using an existing, already-paired remote/mobile app)."


Check the battery strength:

- Try using fresh, brand-new batteries and testing them with a meter if needed.

Using your voice remote

- **Push-to-talk voice:** To use voice, press and hold the voice (microphone icon) button while you speak.
- **TV Controls:** The Power and Volume keys (Vol+/Vol-, Mute) operate your TV.
- **Note:** The RCFA5 remote does not have the lost remote finder, headphone listening, or personal/programmable shortcut keys. If you require these features, please see the Roku Voice Remote Pro.
- For support, go to the following URL: support.roku.com/article/360011621473

Documents / Resources

| | |
|---|---|
|  | <p>Anderic RC-A1R Universal Roku Voice Remote Control [pdf] Instruction Manual RC-A1R Universal Roku Voice Remote Control, RC-A1R, Universal Roku Voice Remote Control , Roku Voice Remote Control, Voice Remote Control, Remote Control, Control</p> |
|---|---|

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.