



Angekis ASP-04 Wireless Speakerphone User Manual

[Home](#) » [Angekis](#) » Angekis ASP-04 Wireless Speakerphone User Manual 

Angekis®

User Manual
ASP-04 Wireless Speakerphone

Please read the user manual before using the product and keep it for future reference


Contents

- [1 Product Overview](#)
- [2 Component Instruction](#)
- [3 Packing list](#)
- [4 Assembling](#)
- [5 Start up](#)
- [6 Basic Features](#)
- [7 Attention to the best performance](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Product Overview

Thank you for choosing Angekis. The ASP-04 is a speakerphone based on 2.4GHz wireless communications and wireless charging technologies. With intelligent audio processing, echo cancellation, and other smart and intuitive features, this device is an excellent solution for your audio conferencing needs. With a 3-meter, 360-degree pickup range, it is suitable for small to medium-sized rooms.


Component Instruction



LED Indicator


1. Blue triangular Indicator: normal working status
2. Blue bottom right indicator: loudspeaker mute
3. Blue bottom left indicator: microphone mute
4. Blinking blue bottom left indicator: volume adjustment
5. Blinking orange bottom left indicator: low power



Packing list



Assembling

Application installation








3.5mm audio application installation	Wireless charging installation
	

Start up



The whole operation:

1. Connect wireless adapter to computer or laptop USB port
2. Turn on the wireless speaker power
3. Open instant messaging software on your computer and then you can enjoy a high-quality audio meeting. Be sure to select the audio device for the microphone and speaker for the ASP-04.

Speaker operation:

1. Turn on/off the
Long press  key to start, and again long press shutdown.
2. Loudspeaker mute
Press  to turn off the speaker. Press again to turn off the speaker.
3. Microphone mute
Press  to turn off the microphone. Press cancel to turn off the speaker again.
4. Vol-
Press  gradually to lower speaker volume or long-press  to lower speaker volume continuously.

5. Vol+

Press + gradually to increase speaker volume or long-press + to increase the speaker volume continuously.

6. Charging

Connect the power adapter to 220v and USB port to the main device

7. Audio alone output

Connect 3.5 mm headphones to the 3.5mm interface and press the loudspeaker button so that it can output audio separately. Wireless speaker operation:

2.4 G wireless adapter operation:

Connect wireless adapter to computer or laptop USB port. It supports Windows 8 / Windows 7 / Windows 10 / Windows XP and other systems, plug and play, no need to install extra drivers

Note: 1. The equipment cannot be compatible with other speakers at the same time 2. Ensure the 2.4ghz wireless adaptor is at least 20cm away from the speaker mic when in use.

Basic Features

1. Internet conference call:

After a successful connection, open your computer's communications software for real-time calling

2. Volume adjustment

Adjust to appropriate volume by "vol+" and "vol-" on the host

3. Microphone mute button

Mute the microphone on and off via the microphone mute button

4. Speaker mute button.

Mute the speaker on and off via the speaker mute button

5. External audio equipment

The ASP-04 can be used as an external loudspeaker device for computers to play the corresponding audio

6. LED indicator

The LED status indicator displays the working status of the host in real-time

7. Support headphones to play audio

Connecting to the 3.5mm audio interface will turn off the loudspeaker and sound will come from headphones only.

8. 2.4 G wireless communication

Both connections between computer and speaker are by 2.4 GHz wireless adapter

Attention to the best performance

1. To obtain the best performance, please read the operating instructions carefully and keep them for future reference.
2. Please install the product in a dry place with good ventilation, avoiding direct sunlight, vibration, wet and cold, and keep away from heat sources and dust.
3. Please keep the product far from the motor, transformer, and other electronic equipment to avoid disturbances.
4. The product shall not be exposed to large temperature variations or high humidity, in order to prevent condensation from occurring inside.
5. The following objects shall never be put on the product:

- 1) Hazardous components, since they will cause damage and discoloration to the product surface
 - 2) Burning objects(such as candles), since they may cause fire, damage to the product, and personal injury
 - 3) Containers holding liquid since the liquid will cause an electric shock to the user and damage to the product should they spill.
6. For heat dissipation, never cover the product with the objects like paper, table cloth, or curtains. The rise of the inner temperature of the product may cause fire, damage to the product, and personal injury.
 7. Never install the product in a place where external objects may drop or liquid may splash.
 8. When unplugging the USB cable, please hold the plug part and never pull the cable.
 9. Keep hands dry when using USB cables, as water may cause fire, electric shock, damage, short circuit, and open circuit.
 10. Never loosen screws of the product at will, which may cause poor sealing and influence the quality and effect.
 11. Never try to repair the product by yourself, if you have any problems, please contact your dealer.



Documents / Resources



[Angekis ASP-04 Wireless Speakerphone](#) [pdf] User Manual
ASP-04, Wireless Speakerphone, Speakerphone, ASP-04, Speaker