



ANGLEMOP Triangle Cleaning Mop User Manual

[Home](#) » [ANGLEMOP](#) » **ANGLEMOP Triangle Cleaning Mop User Manual** 

Contents

- [1 ANGLEMOP Triangle Cleaning Mop](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 General product information](#)
- [5 Product Features](#)
- [6 Cloth attachment guide](#)
- [7 Instructions for Automatic Squeezing](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

ANGLEMOP

ANGLEMOP Triangle Cleaning Mop



Product Information

This versatile mop is ideal for cleaning floors, windows, walls, corners, skirting boards, bathtubs, mirrors, glass, and ceilings.

Crafted from high-quality materials, it efficiently absorbs spills and captures dust, pet hair, and dirt.

Specifications

- Material: High-quality materials
- Usage: Floors, windows, walls, corners, skirting boards, bathtubs, mirrors, glass, ceilings
- Features: Absorbs spills, captures dust, pet hair, and dirt

Product Usage Instructions

Cloth Attachment Guide:

1. Turn the microfiber cloth white-side up.
2. Locate the hanging loop on the centre and fasten it to the plastic hook found on the bottom centre of the mop head.
3. Secure all corner loops on the mop cloth by attaching each loop to the pins located on the edges of the mop head limbs.
4. Attach the cloth before soaking it in water.

Instructions for Automatic Squeezing:

1. Place the bucket on the ground and insert the mop head into it.
2. Hold the handle on the mop rod and lift the mop head out of the bucket.
3. Straighten the mop head to a right angle with the mop rod and extend the rod upwards.
4. Dip the mop head into clean water to saturate it fully.

5. Move the mop rod up and down to activate automatic squeezing and commence cleaning.
6. After use, store the mop rod and mop head appropriately.

Cleaning and Maintenance:

Make sure to clean the cloth thoroughly after use. Do not wash the cloth with acidic solutions and avoid abrasive or sharp objects. If the cloth is no longer usable due to excessive staining, tearing, or general overuse, please contact your ANGLEMOP seller to order new mop cloths.

FAQ

1. Q: Can I use this mop on delicate surfaces like hardwood floors?


A: Yes, this mop is versatile and can be used on various surfaces including hardwood floors. Ensure to follow the cloth attachment guide to prevent scratching.

2. Q: How often should I replace the microfiber cloth?

A: It is recommended to replace the microfiber cloth when it is no longer effective in cleaning due to excessive wear or damage.

General product information

This versatile mop is not only ideal for floors but also for windows, walls, corners, skirting boards, bathtubs, mirrors, glass, and ceilings. Crafted from high-quality materials, it efficiently absorbs spills and captures dust, pet hair, and dirt.



1. Enables wet and dry cleaning
2. Telescopic handle
3. 360 degree rotation
4. No dead corners

Product Features

Featuring an adjustable design, the 360° rotating head enables access to all areas, while the straight-pull mechanism maintains the mop head and handle at a right angle, facilitating automatic water squeezing.



Cloth attachment guide



Turn the microfiber cloth white-side up and locate the hanging loop on the centre. Fasten the hanging loop to the plastic hook found on the bottom centre of the mop head (simply slide the hook into the loop opening). Then, one-by-one, secure all the corner loops on the mop cloth by attaching each loop to the pins located on the edges of the mop head limbs. Attach the cloth before soaking in water.

Instructions for Automatic Squeezing


1. Place the bucket on the ground and insert the mop head into it.
2. Hold the handle on the mop rod and lift the mop head out of the bucket.
3. Straighten the mop head to a right angle with the mop rod and extend the rod upwards.
4. Dip the mop head into clean water to saturate it fully.
5. Move the mop rod up and down to activate automatic squeezing and commence cleaning.
6. After use, store the mop rod and mop head appropriately.



Cleaning and maintenance

Make sure to clean the cloth thoroughly after use. Do not wash the cloth with acidic solutions and abrasive or sharp objects. If the cloth is no longer usable due to excessive staining, tearing or general overuse, please contact your ANGLEMOP seller to order new mop cloths.

Documents / Resources

	<p>ANGLEMOP Triangle Cleaning Mop [pdf] User Manual Triangle Cleaning Mop, Cleaning Mop, Mop</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.