

[Skip to content](#)

Manuals+

User Manuals Simplified.



Angler FB-G24 FastBox Octagonal Softbox Instructions

[Home](#) » [angler](#) » Angler FB-G24 FastBox Octagonal Softbox Instructions ☐

Angler FB-G24 FastBox Octagonal Softbox Instructions

Angler FB-G24 FastBox Octagonal Softbox

Contents

- [1 Product Instructions](#)
- [2 One Year Limited Warranty](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Product Instructions

- Align the vertical stitching on the grid to the metal rods of the FastBox, and press together the touch-fastener strips along the outer rim of the FastBox.

Product Instructions

- **Important!** To avoid light leaks, the grid must be completely sealed around the rim of the FastBox.

Product Instructions

One Year Limited Warranty

This Angler product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance.

EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Angler Customer Service Department to obtain a return merchandise


authorization (“RMA”) number, and return the defective product to Angler along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser’s own risk and expense.

Customer Support

For more information or to arrange service,
visit www.anglerlights.com or
call Customer Service at **212-594-2353**.

Product warranty provided by the Gradus Group. www.gradusgroup.com Angler is a registered trademark of the Gradus Group. © 2020 Gradus Group LLC. All Rights Reserved.

Company Logo



Documents / Resources

[Angler FB-G24 FastBox Octagonal Softbox](#) [pdf] Instructions
FB-G24, FastBox Octagonal Softbox

[Manuals+](#),