



Angler FB-PA2 FastBox Series Octagonal Softbox Instructions

[Home](#) » [angler](#) » Angler FB-PA2 FastBox Series Octagonal Softbox Instructions 

Contents

- [1 Angler FB-PA2 FastBox Series Octagonal Softbox](#)
- [2 One-Year Limited Warranty](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

ANGLER[®]

Angler FB-PA2 FastBox Series Octagonal Softbox



Thank you for choosing Angler.

The Angler FB-PA2 lets you attach the Profoto A2 monolight to your Angler FastBox. When the adapter is securely mounted, take advantage of the FastBox Series of accessories, like the 40° grid, diffusers, and color gels.

Attaching the Flash Adapter and Flash to the FastBox

- Line up the alignment dots. Insert the adapter, and rotate clockwise until it clicks in place.



- Align your flash with the adapter's magnets. Seat the flash into the adapter so the flash is secure.



- A safety lanyard is included to attach your flash to the FastBox. To attach the safety strap, cinch it around the flash head, and then clip it to the FastBox.



Removing the Flash and Flash Adapter

- Carefully pull your flash out from the adapter's magnets.
- Press the unlock button. Then rotate the adapter counterclockwise and remove it from the FastBox.



One-Year Limited Warranty

This Angler product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function. This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance.

EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state. To obtain warranty coverage, contact the Angler Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Angler along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense. For more information or to arrange service, visit www.anglerlights.com or call Customer Service at 212-594-2353. Product warranty provided by the Gradus Group. www.gradusgroup.com Angler is a registered trademark of the Gradus Group. © 2022 Gradus Group LLC. All Rights Reserved.

A Gradus Group Brand

- anglerlights.com

Documents / Resources

Thank you for choosing Angler.

The Angler FB-PA2 lets you attach the Proflex A2 monolight to your Angler FastBox. When the adapter is correctly mounted, take advantage of the FastBox. Series of accessories, like the A2 grid, diffuser, and color gels.

Attaching the Flash Adapter and Flash to the FastBox

Line up the alignment disk. Insert the adapter, and rotate clockwise until it clicks in place.

Align your flash with the adapter's magnets. Seat the flash into the adapter so the flash is secure.

A safety lanyard is included to attach your flash to the FastBox. To attach the safety strap, click it around the flash head, and then clip it to the FastBox.

Removing the Flash and Flash Adapter

Carefully peel your flash out from the adapter's magnets.

Press the unlock button. Then rotate the adapter counter-clockwise and remove it from the FastBox.

Angler FB-PA2 FastBox Series Octagonal Softbox [pdf] Instructions

FB-PA2 FastBox Series Octagonal Softbox, FB-PA2, FastBox Series Octagonal Softbox, Octagonal Softbox, Softbox

References

- [!\[\]\(2824aab9645d9fab95bae27ff6828dab_img.jpg\) Angler | Lighting Equipment & Accessories](#)
- [!\[\]\(0fbf3ad74a6c8dc44ba9ea17fc2aca5e_img.jpg\) Angler | Lighting Equipment & Accessories](#)
- [!\[\]\(c42d0234b47eca423823087b9f2f5716_img.jpg\) Gradus | Gradus Group](#)