



# Angry Miao CYBERBOARD Terminal Keyboard User Manual

[Home](#) » [Angry Miao](#) » Angry Miao CYBERBOARD Terminal Keyboard User Manual 📖

## Angry Miao CYBERBOARD Terminal Keyboard



## Contents

- [1 Specifications](#)
- [2 Tools Required](#)
- [3 Installation](#)
- [4 Shortcut keys](#)
  - [4.1 Media Keys](#)
  - [4.2 LED Control](#)
  - [4.3 Bluetooth connection](#)
- [5 How to edit lighting effects](#)
- [6 Anti-counterfeiting](#)
  - [6.1 Declaration](#)
- [7 After-sales service](#)
  - [7.1 Return & Refund Policy](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

## Specifications

Product	CYBERBOARD
Weight	2.5 ±0.1 kg (excluding switches or keycaps)
Typing Angle	10° incline
LED quantities	5*40 lamps, 200 Leds
Color choices	Cyber Grey, Industrial Yellow, Purple Haze, Vapor White, Jungle Green
Plate mounting style	Top Mount
Drive	No extra drivers, N-key rollover
Windows PC	Support DIY Web interface in Windows
Connections	Hot Swappable

Connections	Bluetooth 5.0 and USB switchable tap the bottom switch to switch mode (supports C to C, Bluetooth 5.0 only available on Windows 8.0+)
Capslock hint	The indicator light is located between the numbers 6 and 7
Battery status	Fn+F12, display power status When the power is less than 5%, power module will turn red until the power is off. (Press Fn+F11 to turn off the screen)
USB Port	USB3.0 TypeC supports C to C
Battery	Lithium battery 4000mAh *2
Qi wireless charge	Output power 5W. Wireless charging will turn on when the battery is less than 70%, and it will be turned off when fully charged."
LED colors	256 colors
Maximum power dissipation	2.5W

## Tools Required




3mm M2 ×  
16




3.5mm+2mm M2 ×  
8



5mm M3 ×  
18




M3 Hexagon Screwdriver x




M2 Hexagon Screwdriver x

## Installation


1. Remove the screws of the back




2. Note: please make sure open from the bottom to avoid damaging the cable




3. Remove the FPC cables and RF cables, and loosen the screws



4. Take out the PCB sets




5. Remove the screws (3mm M2) on the PCB




6. Remove the PCB






7. Install the stabilizers in the PCB




8. Assemble the PCB, silicone mute mount and plate in order

Note: please make sure to put on the front side (with logo) of the silicone mute mount and the plate





9. Install the switches

Note: Please install it carefully to prevent deforming the plate or crushing the PCB




10. Install the PCB to the upper cover, lock the screws and connect the cables

Note: Please make sure you connect to the right side.




# 11. Close the back cover

Note: Closing the the back cover in the wrong direction could damage the cables



# 12. Lock the screws from the back cover and complete the installation



## Shortcut keys

### Media Keys




Fn+F1	Mutes system sound
Fn+F2	Lowers system volume
Fn+F3	Increases system volume
Fn+F4	Back to previous song
Fn+F5	Goes to next song
Fn+F6	Play/Pause
Fn+R	Factory reset (Press and hold for 5 seconds)

#### **LED Control**

Fn+F12	Switch the LED effects
Fn+F10	On/off LED display
Fn+Up arrow ↑	Increase brightness
Fn+Down arrow ↓	Decrease brightness

#### **Bluetooth connection**



Fn+1	Switch to device 1 in Bluetooth mode, press and hold for 5 seconds until the LED  icon starts blinking. The icon will stop flashing if the device paired successfully, and the panel will resumes its previous display
Fn+2	Switch to device 1 in Bluetooth mode, press and hold for 5 seconds until the LED  icon starts blinking. The icon will stop flashing if the device paired successfully, and the panel will resumes its previous display
Fn+3	Switch to device 1 in Bluetooth mode, press and hold for 5 seconds until the LED  icon starts blinking. The icon will stop flashing if the device paired successfully, and the panel will resumes its previous display
Switching the device	Press Fn+1/2/3 to switch between different connected devices. 5 seconds after the icon appears, and the panel will resumes its previous display
Standby during Bluetooth mode	After 15 minutes of standby, the LED panel will automatically turn off while the keyboard will keep the connection. Press any key to wake up

## How to edit lighting effects

1. Enter [diy.angrymiao.com](http://diy.angrymiao.com) to edit lighting effects and keycap layouts.
2. After finishing editing, generate the config file and download it.
3. Download the Angry Miao loader (windows program) from [diy.angrymiao.com](http://diy.angrymiao.com). And keep the CYBERBOARD connected to the computer via USB.
4. Double-click to open the Angry Miao loader, select your config file and import (you can directly use the config file shared bothers).
5. Wait patiently until it's successfully configured.

## Anti-counterfeiting

### Declaration

In order to protect your rights and shopping experience, please register for anti-counterfeiting as soon as your CYBERBOARD arrives.

Anti-counterfeiting Registration

CYBERBOARD is devoted to providing users with high-quality products. We will provide anti-counterfeiting registration services for CYBERBOARD products starting July 3, 2020. All products purchased from official channels can be registered for anti-counterfeiting.

Please note that all the CYBERBOARD products that you purchased from official channels can be registered at <https://verify.angrymiao.com> by entering the security code on the back of the product. Each anti-counterfeiting code is unique and can only verify the corresponding item.

If you find that the CYBERBOARD you purchased cannot be registered or the registration fails, please discriminate the authenticity of the product carefully.

## After-sales service

### Return & Refund Policy


**Our policy lasts 72 hours. If the time is due, unfortunately we can't offer you a refund or exchange.**

**There are certain situations we can't offer you a refund or exchange.**

- 48 hours have gone by since you received the item.
  - Any item not in its original condition, is damaged or missing parts for reasons not due to our error.
  - Dislike due to personal preferences.
1. If you need to refund or exchange, please click Contact Us on our website and leave your message. We will contact you within 3 working days.
  2. Please contact us first if you want a refund or exchange. We refuse to deal with self returned products.
  3. To be eligible for a return, your item must be unused and in the same condition that you received it. It must also be in the original packaging. Any missing parts will delay the refund or cause partial refunds.
  4. You will be refunded after we receive the returned product and check it. Once your return is received and inspected, we will send you an email to notify you that we have received your returned item. Then your refund will be processed, and a credit will automatically be applied to your credit card or original method of payment, within 5-7 business days.
  5. If there is insufficient stock of exchanging products, we will inform you about the specific treatment.










## Documents / Resources

	<a href="#">Angry Miao CYBERBOARD Terminal Keyboard</a> [pdf] User Manual CYBERBOARD Terminal Keyboard, Terminal Keyboard, CYBERBOARD Keyboard, Keyboard, CYBERBOARD
---	---

## References

-  [AngryMiao](#)

-  [AngryMiao](#)
-  [Angry Miao](#)
-  [Angry Miao](#)
-  [Angry Miao](#)
-  [Angry Miao](#)
-  [Angry Miao](#)
-  [Angry Miao](#)

Manuals+.