

**anko**  
**43351282**  
**3 In 1**  
**Keyboard**  
**Set**



## anko 43351282 3 In 1 Keyboard Set Instruction Manual

[Home](#) » [Anko](#) » anko 43351282 3 In 1 Keyboard Set Instruction Manual 

### Contents

- [1 anko 43351282 3 In 1 Keyboard Set](#)
- [2 Safety Instruction](#)
- [3 Features](#)
- [4 Multimedia Hotkeys Functions](#)
- [5 Product Overview](#)
- [6 User guide](#)
- [7 Keyboard connect](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

# anko

### anko 43351282 3 In 1 Keyboard Set



### Safety Instruction

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

- Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- Use this device solely for its intended purpose
- For indoor use only.
- Keep the appliance away from all hot surfaces and naked flames.
- Always put the appliance on a level, stable, clean, dry surface. Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity, and drops or jets of water.
- Do not immerse the appliance in water or other liquids.
- Do not open the housing under any circumstances.
- Do not introduce any objects into the interior of the housing.

## Features


- 2.4GHz wireless technology
- Working distance up to 10 m (without any obstructions)
- Compatible with Windows XP/ Win 7/8/10,
- 3 in 1 Keyboard Set
- K:43-455-287 | T:70-035-940
- Model No.:43351282

## Multimedia Hotkeys Functions

FN+F1	Media	FN+F2	Volume Down
FN+F3	Volume Up	FN+F4	Mute
FN+F5	Previous Track	FN+F6	Next Track
FN+F7	Play/Pause	FN+F8	Stop
FN+F9	Homepage	FN+F10	Mailbox
FN+F11	My computer	FN+F12	Favourite

Some hotkey functions may not work because of the different devices' system or application compatibility.

## Product Overview



## User guide

1. Remove the battery compartment cover of the keyboard and insert a 1x 1.5V AA battery. Please pay attention to the polarity mammogram printed inside the battery compartment of keyboard This wireless combo uses one USB receiver, remove the USB receiver from its compartment Inside the keyboard.
2. Remove the battery compartment cover of the mouse and insert a 1x 1.5V AA battery. Please pay attention to the polarity diagram printed inside the battery compartment of the mouse.
  - **Caution!** The danger of explosion if the batteries are incorrectly replaced When the battery indicator light flicker, please change the battery in time.
3. Replace the battery compartment cover again, making sure it is closed firmly.
4. Plug the USB receiver into a free USB port on the computer
5. The mouse and keyboard will connect automatically and can be used immediately.

**Notes on batteries:** Only uses top-quality batteries. Cheap batteries could leak and damage the device as a result if the batteries leak, remove them with a cloth and dispose of them accordingly. Ensure that leaking battery acid does not come into contact with skin and eyes. If you do get battery acid in your ayes, flush them thoroughly with lots of water and consult a physician immediately! If battery acid comes into contact with your skin, wash the

affected area with lots of water and soap the device is not to be used for an extended period, then the batteries should be removed, as the device could become damaged should they leak. If the device functions weaken, replace all batteries. Batteries do not belong in household waste! Expired batteries must be disposed of in an environmentally friendly way and according to the applicable legal regulations. Batteries are very dangerous if swallowed. Please keep the battery and the device components away from children at all times. If a battery is swallowed, seek medical attention immediately.

- Batteries must not be recharged or activated with other means, dismantled, thrown into fire, or short-circuited.
- Remove the batteries before disposing of the device.

## Keyboard connect


### ESC+Q

- When the keyboard does not match the receiver, please insert the keyboard battery first, then.
- Press "ESC" and Q keys at the same time, until the upright corner battery indicator light turns
- Plug the LA5B receiver into the computer.
- The keyboard will successfully connect to the computer if the indicator light turns off.

## Mouse connect

If the mouse does not respond, you can recode by following steps: Press the left and middle keys at the same time and do not let go, then install a battery to the mouse, and finally plug the USB receiver into the computer, at this stage you can lose the left and middle key and the mouse starts to work. Please note this step is only for the keyboard and mouse which do not match the receiver. Successfully plug the receiver into the computer, and the keyboard and mouse can directly connect to the computer this step can not be used in other brands of receiver and keyboard mouse.

## Documents / Resources

	<p><a href="#">Anko 43351282 3 In 1 Keyboard Set</a> [pdf] Instruction Manual 43351282 3 In 1 Keyboard Set, 43351282, 3 In 1 Keyboard Set, Keyboard Set, Set</p>
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.