

anko 43456277 Bluetooth Wireless Keyboard Instruction **Manual**

Home » Anko » anko 43456277 Bluetooth Wireless Keyboard Instruction Manual



Anko 43456277 Bluetooth Wireless Keyboard



Packing list: Bluetooth keyboard*1, USB Charging Cable*1, Instruction Manual*1

Contents

- 1 Safety Instructions
- 2 Features
- 3 Product model specification
- 4 Bluetooth keyboard Indicator

Introduce

- 5 Bluetooth keyboard connection steps
- 6 Keyboard shortcut function

description

- 7 Charging
- 8 Attention
- 9 Trouble shooting
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

Safety Instructions

Please read the instruction manual before using this device and follow all the safety instruction to avoid damage caused by improper use.

Keep the instruction manual for future reference.

Should this device be given to a third party, then this instruction manual must also be handed over. Use this device solely for its intended purpose.

Keep the appliance away from all hot surfaces and naked flames.

Always put the appliance on a level, stable, clean, dry surface.

Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity and drops or jets of water.

Do not immerse the appliance in water or in other liquids.

Do not open the housing under any circumstances.

Do not introduce any objects into the interior of the housing.

Features

Ultra-thin & portable design Working distance up to 10 metres Comfortable and Quiet Typing Keys Play time up to 60 hours

Compatible for 3 systems: Windows / IOS / Android

Product model specification

1. Bluetooth Interface Standard

2. Operating Distance Available: 10 meters

3. Operating Voltage: 5V, 100mA (Max)

4. Charging Time: 1.5 – 2 hours

5. Lithium Battery Capacity: 200mAh

Bluetooth keyboard Indicator Introduce

A: Caps Lock indicator: It will light up when the keyboard is in uppercase input.

BT: Switching power and Bluetooth connection indicator: Turn the power switch to the ON position, it will

flash for 3 seconds to enter the Bluetooth pairing mode, and will be off after connected. **Low battery indicator:** It will flash when the battery is low and please start to charge.

Charging indicator: The indicator will be red while charging, and it will be green after fully charged.

Micro USB charging interface Switching power and Bluetooth connection indicator: Turn the power switch to the ON position, it will flash for 3 seconds to enter the Bluetooth pairing mode, and will be off after connected.

Low battery indicator: It will flash when the battery is low and please start to charge.

Charging indicator: The indicator will be red while charging, and it will be green after fully charged.

Micro USB charging interface

Bluetooth keyboard connection steps

- 1. After turning the power switch to the ON position, the power indicator light will be on for 3 seconds. Press Fn + C to enter the code matching mode, and the Bluetooth indicator light will start to flash.
 - Then the Bluetooth keyboard will automatically enter the pairing mode.
- 2. Open and unlock your tablet and click on the "Settings" icon.
- 3. In the settings menu, click on the 'Bluetooth' menu.
- 4. Turn on the Bluetooth switch and the tablet will automatically search for Bluetooth keyboard devices.
- 5. Discover the Bluetooth keyboard device: anko43456277, and click on it, the Bluetooth keyboard will be automatically connected
- 6. After the Bluetooth connection is successful, the pairing indicator is off, and "Connected" will appear in the list of Bluetooth devices.

Keyboard shortcut function description

| | Back To Home page | Q | search | IOS | Fn+E |
|-------------|----------------------|--|-------------|--------------|-----------------|
| • | Mute Key | ◀) | Volume- | ■))) | Volume+ |
| Connect | Fn+C | Win | Fn+W | Andriod | Fn+Q |
| Fn | Function key | -\\\\\\-\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\ | Bright ness | -;¢- | Brightness+ |
| <u></u> | Open input key board | | Screen shot | (11) | Select language |
| I 44 | Previous track | ►II | Play/pause | ►►I | Next track |

NOTE:

- 1. Press Fn and Q, W or E keys to shift between Android, Windows or iOS system after connected successfully. Otherwise the keyboard's function key will be invalid. Q –Android, W Windows, E IOS
- 2. If you have used Bluetooth to connect several equipment, the keyboard will work for the latest device connected, When the device is found, the system will re-connect automatically.
- 3. Due to keyboard under different system, some function of shortcut key is not realised.

Charging

When the battery is low, the battery indicator will keep flashing, and please charge the keyboard

- 1. As the product is built-in non-removable and rechargeable battery, please use the provided charging cable to charge.
- 2. The charging indicator will be red all the time during charging and will be green after full charged.

Attention

- 1. In order to prolong the battery life, it is suggested to close keyboard when it will not use for long time.
- 2. In order to get longer battery life, it is suggested to charge before the keyboard power light flashes, and the charging time must be better more than 2 hours.
- 3. The keyboard will be automatically sleep mold when there is no operation within 15 minutes and all indicators will be turned off.

Pressing any key for 3 seconds, the keyboard will be woke up and automatically connected to Bluetooth to work

Trouble shooting

Make sure the power switch is turned on.

Ensure the keyboard is in operable distance.

Make sure the battery has power.

Ensure the device's Bluetooth was turned on.

Ensure the wireless keyboard was found in the tablet Bluetooth device.

Ensure the wireless keyboard is paired successfully.



Documents / Resources



anko 43456277 Bluetooth Wireless Keyboard [pdf] Instruction Manual 43456277, 43456277, 43456277, 43456277 Bluetooth Wireless Keyboard, 43456277, Bluetooth Wireless Keyboard, Wireless Keyboard, Keyboard

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.