



## anko B08F5243S9 Web Cam With Privacy Screen Instruction Manual

[Home](#) » [Anko](#) » anko B08F5243S9 Web Cam With Privacy Screen Instruction Manual

# anko

WebCam With Privacy Screen  
Keycode:43026647  
Instruction Manual



## Contents [ [hide](#) ]

### 1 Parts

### 2 SETTING UP YOUR WEBCAM

#### 2.1 Place your webcam

#### 2.2 Connect the webcam

#### 2.3 Use the webcam

### 3 Documents / Resources

#### 3.1 References

### 4 Related Posts

## Parts

1. Activity light
2. HD 1080p lens
3. Power light
4. Privacy covers
5. Microphone
6. Flexible clip/base

### Packaging includes:

Webcam with 1.5m USB cable x 1

Tripod stand x1


Manual X1

## SETTING UP YOUR WEBCAM

### Place your webcam

A: Grasp the webcam as shown and open the flexible clip/base with the other hand. Mount the webcam, making sure the foot on the flexible clip/base is flush with the back of your monitor


B: Align the bottom of the webcam with the screw on the tripod stand, mount them tightly, unfold the tripod and place it on a flat surface.



### Connect the webcam

Connect the webcam to a computer USB port, then the power light will turn red. The Windows® UVC or Mac

drivers will be loaded automatically. Driver installation may take a few moments.



### **Use the webcam**

The webcam does not ship with video calling software. To make a video call, use your video calling application. When video calling working, the activity light will turn green and turn off when the calling ends.

### **12 Month Warranty**

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alterations, accident, misuse, abuse, or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at [Kmart.com.au](https://www.kmart.com.au) for any difficulties with your product.

Warranty claims and claims for expenses incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

### **Documents / Resources**

onko

Web Cam With Privacy Screen  
Model: B08F5243S9  
Instruction Manual



Parts

1. Audio light
2. 1080P lens
3. Power light
4. Privacy screen
5. Microphone
6. Flexible display

[onko B08F5243S9 Web Cam With Privacy Screen](#) [pdf] Instruction Manual  
B08F5243S9, Web Cam With Privacy Screen

## References

- [Kmart.com.au](#)