



anko Full Mechanical Gaming Keyboard Instruction Manual

[Home](#) » [Anko](#) » anko Full Mechanical Gaming Keyboard Instruction Manual 

Contents

- [1 Full Mechanical Gaming Keyboard](#)
- [2 Function overview:](#)
 - [2.1 26 anti-ghosting keys](#)
 - [2.2 Multimedia functions](#)
- [3 How to use this keyboard:](#)
 - [3.1 Function Operation](#)
- [4 Specifications:](#)
- [5 12 month warranty](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

anko

Full Mechanical Gaming Keyboard



Function overview:

26 anti-ghosting keys

Q, W, E, R, T, A, S, D, F, G, Z, X, C, V, B, M, TAB, Caps Lock, Shift_L, Ctrl_L, Alt_L, Space Bar, ↑, ↓, ←, →



Multimedia functions

- F1 Media
- F2 Volume –
- F3 Volume +
- F4 Mute
- F5 Stop
- F6 Previous track
- F7 Play/Pause
- F8 Next Track
- F9 Email
- F10 Web/Home
- F11 Full Screen
- F12 Calculator

How to use this keyboard:

Function Operation

LED Mode Adjustment Cycle through the 12 modes by pressing button

Increase LED Brightness Press Fn + ↑ (4 levels)

Decrease LED Brightness Press Fn + ↓ (4 levels)

Increase LED Mode Speed Press Fn + → (3 levels)

Decrease LED Mode Speed Press Fn + ← (3 levels)

Lock Windows Key and App Keys Press Fn + Win_ L (an LED light will illuminate to indicate the current state)

Implement Multimedia Functions Press Fn + [F1 ~ F12]

Safety instructions:

- Keep the keyboard away from sharp objects that could damage it.
- Do not put heavy objects on the keyboard.
- Do not apply force to the keyboard.
- To clean the keyboard, gently wipe it using a cotton cloth.
- Make sure the keyboard is turned off before cleaning. Do not use liquid cleanser.

Specifications:

Model No: 42852322

Charging voltage: 5V d.c. 350mA

Compatible with OS: Windows XP, Vista, Win7, Win8, Win10A, Android, Linux, Mac & Mac

Key type: 104 dual colour injected keys US layout

Keyboard type: Full mechanical

Materials: ABS

Port type: USB

Switch: Blue colour

Dimensions: 444mm W x 155mm H x 38.5mm D

Weight: 815g ±20g

Cable length: 1.5m

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the

warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect. Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense

incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.


WARNING:

- Do not dispose of unit in fire or water.

- Never attempt to disassemble and reassemble.
- Waste electrical products should not be disposed of with household waste, please recycle where facilities exist.
- Check with your local authority for recycle advice
- Keep your device and all accessories out of the reach of children and animals
- Small parts may cause choking or serious injury if swallowed.
- Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C).
- Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device.
- Do not allow your device to get wet—liquids can cause serious damage.
- Do not handle your device with wet hands.



Documents / Resources

	<p>anko Full Mechanical Gaming Keyboard [pdf] Instruction Manual Full Mechanical Gaming Keyboard</p>
---	--

References

-  [kmart.com.au](https://www.kmart.com.au)