



Home » Anko » anko Motion Sensor LED Light Bar Instruction Manual 🤼



Contents [hide]

- 1 Anko Motion Sensor LED Light Bar
- 2 Product Usage Instructions
- 3 Product Description
- 4 Packing Included
- 5 Safety Instructions
- 6 Specifications
- 7 Assembly Instructions
- 8 Using the Appliance
- 9 Cleaning & Maintenance
- 10 Battery and light bar disposal
- 11 Trouble Shooting
- 12 FAQ
- 13 Documents / Resources
 - 13.1 References



Anko Motion Sensor LED Light Bar



Product Specifications

Model: 40CM MOTION SENSOR LED LIGHT BAR

• **SKU**: 43543212

Technical Reference: 70963472 SLR-24234

• Power Source: Lithium battery

• Features: LED Lamp, Infrared motion sensor, charging port, on/off button, Function

button

Product Usage Instructions

Cleaning Instructions

- 1. Turn off the light bar before cleaning.
- 2. Do not immerse the appliance in water.
- 3. Clean the light bar surface with a dry cloth.
- 4. Do not use any lubricant, detergent, polishing agents, alcohol, steel wool, abrasive cleansers, chemicals, or corrosive liquids on the light bar.

Battery and Light Bar Disposal

This light bar contains a lithium battery.

To dispose of the light bar containing batteries:

- 1. Do not dispose of the light bar with batteries in normal household waste.
- 2. Hand it over to an official recycling point for proper disposal.

Assembly Instructions


- 1. Unpack the contents included in the package: 1 motion sensor light, 2 plastic pads, a Type-C USB charging cable, and a User Manual.
- 2. Place the plastic pads on a suitable surface to mount the light bar securely.
- 3. Connect the Type-C USB charging cable to the charging port of the light bar.
- 4. Press the On/Off button to activate the light bar.
- 5. Use the function button to control additional features of the light bar.

Important Note

To ensure proper operation of this light bar, please read this instruction manual carefully before using the light bar and save it for further reference.

Product Description

- 1. LED Lamp
- 2. Infrared motion sensor
- 3. Charging port
- 4. On/Off button
- 5. Function button
- 6. Plastics pad
- 7. Type-C USB cable



Packing Included

- 1 pcs motion sensor light
- 2 pieces of plastic pads
- Type-C USB charging cable
- User Manual

Safety Instructions

- To ensure proper operation of this light bar, please read this instruction manual carefully before you use the light bar and save it for further reference.
- **WARNING:** Check the light bar before you use it. Do not use the light bar if it has any cracks, gaps, or other damage.
- Do not attempt to repair, disassemble, or modify the light bar by yourself to avoid accidents.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life, the whole luminaire shall be replaced.
- Do not stare into the LED beam.
- This product is not suitable for household room illumination. Only used as a decorative light.

- The product is intended to be used in moderate climates only. Do not use in tropical or very humid climates.
- Children must not use this product without adult supervision.
- Do not charge the product for a long time. Plug off the charging cable after fully charged
- **CAUTION:** This light bar has a lithium battery. Do not place or store the light bar for long periods in a hot or humid environment. If you do not intend to use the light bar for a long time, store the light bar after it is fully charged.
- Do not use while charging. (The charging indicator light is on during charging, which interferes with the infrared motion sensor and cannot work properly.)
- This light bar contains a battery and LED lights that are non-replaceable.
- Ensure the charging power used is compatible with a 5V DC SELV IA, 5W rating.

Specifications

• Charging Voltage / Current: 5V === / 1000mA Max. 5W

• Type of Battery: Li-polymer 3.7 V 650mAh

• Ta: 25 C

Assembly Instructions

- Before adhering strip lights, clean the surface of the area you will be placing the lights on, and keep it smooth & dry. It is recommended to apply your strip lights on smooth, stable surfaces.
 - It should not be placed on rough, textured, or painted wall surfaces or any surfaces that can bend or move.
- 2. Remove the protective film from the plastic pad. Stick the plastic pad to the cabinet surface, and press it to make sure it sticks firmly. You can detach the LED light bar when recharging.
- 3. Only charge the lamp with the supplied USB cable.

Using the Appliance

For a better user experience, please read the instructions below carefully:

o This appliance needs to be charged if the light is not bright enough. Please use a

- 5V DC SELV IA 5W adaptor(not included) to charge.
- The charging indicator light will be red while charging. After being fully charged, it will turn green.
- There are two buttons on the side of the product: an on/ off button and a function button.
- On/Off button: press 1st time to activate the constant light mode.
- The light will always be lighting in this mode.
- Press the 2nd button twice, and the light flashes three times to start the night motion sensor mode. The sensor can only detect movement when the environment in a lowlight environment.
- Press the 3rd times, the light flashes two times to start the routine motion sensor mode. The sensor can detect movement always and will be lit, whether in day or night.
- Press the 4th time to turn off the light.
- Function button: short press to adjust the colour temperature.
- There are three colours on this product: daylight, cool & warm light.
- Long-press the adjust the light brightness.
- Auto-triggered by an infrared motion sensor when movement.

Cleaning & Maintenance

- 1. Turn the light Bar off before you start cleaning it.
- 2. Do not immerse the appliance in water. Clean the light Bar surface with a dry cloth
- 3. Do not use any lubricant, detergent, polishing agents, alcohol, steel wool, abrasive cleansers, chemicals, or corrosive liquids on this light Bar.

Battery and light bar disposal

 This light bar has a lithium battery. Batteries contain substances harmful to our environment, please do not dispose of the light bar containing batteries with the normal household waste, instead hand it over to an official recycling point.

Trouble Shooting

Problem	Possible Cause	Solution	
LED Light is not bright enough or it does not turn on	The battery is running low or is out of power	Charge the light bar as guided	

FAQ

- Q: Can I use detergent to clean the light bar?
 - A: No, it is advised not to use any detergent or corrosive liquids on the light bar surface as it may damage the product.
- Q: How should I dispose of the light bar with batteries?
 - A: Please do not dispose of the light bar containing batteries in normal household waste. Hand it over to an official recycling point for proper disposal to protect the environment.

Documents / Resources



anko Motion Sensor LED Light Bar [pdf] Instruction Manual 43543212, 70963472, SLR-24234, Motion Sensor LED Light Bar, Sensor LED Light Bar, LED Light Bar, Light Bar

References

- User Manual
- Anko
- ◆ 43543212, 70963472, Anko, LED Light Bar, LIGHT BAR, Motion Sensor LED Light Bar, Sensor LED Light Bar, SLR-24234

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.