



## anslut 014511 Remote Power Switch Instruction Manual

[Home](#) » [anslut](#) » anslut 014511 Remote Power Switch Instruction Manual 

### anslut 014511 Remote Power Switch Instruction Manual






#### Contents

- [1 SAFETY INSTRUCTIONS](#)
- [2 SYMBOLS](#)
- [3 TECHNICAL DATA](#)
- [4 HOW TO USE](#)
- [5 TURN ON/OFF THE LIGHT](#)
- [6 TROUBLESHOOTING](#)
- [7 EU DECLARATION OF CONFORMITY](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

## SAFETY INSTRUCTIONS

- Do not place two receivers too close to each other. The gap between two receivers should be at least 1 metre.
- Do not overload the receiver.
- Do not use the receiver near flammable liquids, solvent, paint or other similar products.

## SYMBOLS

	Read the instructions.
	Approved in accordance with the relevant directives.
	Recycle end-of-life product in accordance with local regulations.

## TECHNICAL DATA

Rated voltage	230 V -j 50 Hz
Max load	2300 W
Safety class	IP44
Protection rating	I
Frequency	433.92 MHz
Range Approx.	25 m (clear view)
Battery remote control	3V CR2032


## HOW TO USE

### SYNCHRONISATION BETWEEN TRANSMITTER AND RECEIVER


1. Remove the small plastic tab from the battery on the remote control.
2. Connect the receiver to a power point. The LED indicator flashes on/off for 15 seconds or until the

synchronisation is completed.





3. Press one of the  buttons on the remote control within 15 seconds to connect the remote control to the receiver (learn mode closes automatically if no button is pressed). The LED indicator flashes three times as confirmation.
4. Connect the light to the receiver. Make sure that the switch on the light is in the ON position.

### Remove synchronisation

1. If the receiver is connected to a power point, unplug it. Unplug the light.
2. Connect the receiver to a power point. The LED indicator flashes for 15 seconds, or until removal is completed.
3. Press one of the  buttons on the remote control within 15 seconds to delete the learned code (learn mode closes automatically if no button is pressed). The LED indicator flashes three times as confirmation.


### TURN ON/OFF THE LIGHT



1. Press the  button to switch on the light.
2. Press the  button to switch off the light.

### TROUBLESHOOTING

#### THE LIGHT DOES NOT GO ON

- **The receiver LED is on**
  - Check light source.
  - Make sure that the switch on the light is in the ON position.
- **The receiver LED is off**
  - Check power source to receiver.
  - Try pressing the button  on the remote control again.
- **It still does not work**
  - Check the battery in the remote control.
  - Try synchronising the receiver with the remote control again.

### Care for Environment



Recycle discarded product in accordance with local regulations.

### EU DECLARATION OF CONFORMITY

Item number: 014511

Jula AB, Box 363, SE-532 24 SKARA, SWEDEN

This declaration of conformity is issued under the sole responsibility of the manufacturer  
**RECEIVER REMOTE: IP44**

Conforms to the following directives, regulations and standards

Directive/Regulation	Harmonised standard
	IEC 60884-2-5:2017. NEK 502:2016, SS 4280834:2013+R1+T1
RED 2014/53/EU	IEC 61058-1:2018. EN 61058-1-1:2016
RoHS 2011/65/EU + 2015/863	50581:2012


This product was CE marked in year

Skara 2020-13-23

**Fredrik Bohman**  
**BUSINESS AREA MANAGER**



## Documents / Resources

	<a href="#">anslut 014511 Remote Power Switch</a> [pdf] Instruction Manual 014511, Remote Power Switch
---	---