



## anslut 016210 Work Lamp Instruction Manual

[Home](#) » [anslut](#) » anslut 016210 Work Lamp Instruction Manual 



**WORK LAMP**  
Item no. 016210



## Contents

- [1 OPERATING INSTRUCTIONS](#)
- [2 SAFETY INSTRUCTIONS](#)
- [3 SYMBOLS](#)
- [4 TECHNICAL DATA](#)
- [5 DESCRIPTION](#)
- [6 USE](#)
- [7 MAINTENANCE](#)
- [8 STORAGE](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)

## OPERATING INSTRUCTIONS



Important! Read the user instructions carefully before use. Save them for future reference.

(Translation of the original instructions)

Care for the environment!

Must not be discarded with household waste! This product contains electrical or electronic components that should be recycled. Leave the product for recycling at the designated station e.g. the local authority's recycling station.

Jula reserves the right to make changes. In the event of problems, please contact our customer service.


[www.jula.com](http://www.jula.com)



For the latest version of operating instructions, see [www.jula.com](http://www.jula.com)

2021-05-21

© Jula AB






## SAFETY INSTRUCTIONS

- Do not look directly into the work lamp when it is switched on. Never point the beam at the eyes of people or animals.
- Keep out of the reach of children.
- The product can be used indoors and outdoors, but must not be immersed in water or any other liquid.
- Do not charge the product outdoors.
- The switch must be in the off position when charging, otherwise, the product can be damaged.
- Do not cover the product when in use.
- Always unplug the charger and allow the product to cool before cleaning, or maintenance, and to reduce the risk of electric shock.
- Do not attempt to replace the integrated battery.
- The light source is not replaceable. Discard the product if the light source stops working.
- Do not use the product if the glass front is cracked or damaged. The product must be discarded if the glass front is cracked or damaged.

- Do not open or dismantle the product. The product does not have any parts that can be repaired by the user.
- Charge the battery as soon as possible after it has been discharged for the best functionality and life span.
- Do not touch the product until it has cooled.
- Keep the product at a safe distance from flammable materials and/or flammable surfaces.
- Make sure there is adequate ventilation to prevent overheating.

## SYMBOLS

	Approved in accordance with the relevant directives.
	Do not use the product if the glass front is cracked or damaged.
	Recycle discarded products as electrical waste.

## TECHNICAL DATA

Output	9 W
Battery	3.7 V Li-Ion
Luminous flux	700 lm
Colour temperature	4000 K
Diffusion angle	120°
Safety class	II
Protection rating	IP54
Battery capacity	2000 mAh
Battery life	2 h
Charging time	4 h
Ambient temperature	-5 – 40°C
Charging current, USB port	5 VDC, 1 A

## DESCRIPTION

1. Carry handle

2. Charging connector
3. Controls
4. Power switch

FIG. 1

## USE

- The battery must be fully charged before using the product for the first time.
- Charge the battery immediately when it becomes discharged.
- To avoid the battery becoming completely discharged, recharge it every three months even when the product is not in use.


## MAINTENANCE

Wipe the product with a dry, soft cloth when necessary.

## STORAGE

- Store the product out of the reach of children, in a stable and safe position, cool and dry. Avoid very hot or low temperatures.
- Protect the product from direct sunlight. If possible, store the product in the dark.
- Do not store the product in a plastic bag, this can cause the accumulation of moisture and damage the product.

## Documents / Resources

	<p><a href="#">anslut 016210 Work Lamp</a> [pdf] Instruction Manual 016210, Work Lamp, 016210 Work Lamp</p>
---	---

## References

-  [Jula – products for home and garden](#)