



anslut 016735 Advent Candlestick Instruction Manual

[Home](#) » [anslut](#) » anslut 016735 Advent Candlestick Instruction Manual 

Contents

- [1 anslut 016735 Advent Candlestick](#)
- [2 SAFETY INSTRUCTIONS](#)
- [3 TECHNICAL DATA](#)
- [4 USE](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



anslut 016735 Advent Candlestick



SAFETY INSTRUCTIONS

- Only intended for indoor use.
- For decorative lighting use only.
- The product is not intended for general lighting.
- Do not connect the product to the mains power supply while the product is still in the pack.
- The power cord on this product is not replaceable if damaged discard the complete product.
- Do not expose the power cord or conductors to mechanical loads. Do not hang objects on the product.
- Choose a suitable place to put the product where it is not causing an obstruction or a hazard.
- Do not expose the product to water, moisture or heat, and do not use in very humid conditions.
- Do not expose the product to direct heat, or use in the vicinity of naked flames, or submerge in water.
- This is not a toy. Be careful if using the product near children.
- Recycle the product at the end of its useful life in accordance with local regulations.

WARNING: Do not use the product if the light sources are damaged or missing – risk of electric shock.

Symbols



- Safety class II.



- For indoor use only.



- Approved in accordance with the relevant directives.



- Recycle discarded products in accordance with local regulations

TECHNICAL DATA

- **Rated voltage** 230 V ~ 50 Hz/22 V
- **Output** 11 x 3 W
- **Light source** 3 W/22 V
- **Socket** E10
- **Safety class** II

USE

1. Remove the product from the packaging.
2. Screw the light sources into all of the holders.
3. Place the product in the required location.
4. Plug the plug into a power point.

WARNING! Do not connect the product to the mains power supply while the product is still in the pack.

Care for the environment!

Must not be discarded with household waste! This product contains electrical or electronic components that should be recycled. Leave the product for recycling at the designated station e.g. the local authority's recycling station. Julia reserves the right to make changes. In the event of problems, please contact our customer service.

www.jula.com.

Documents / Resources

	anslut 016735 Advent Candlestick [pdf] Instruction Manual 016734, 016735, 016735 Advent Candlestick, 016735, Advent Candlestick, Candlestick
---	---

References

- [Jula – “products for home and garden](#)
- [Jula – ingenting kan stoppe deg!](#)
- [Jula – Teraz nic Cię nie powstrzyma!](#)
- [Jula – inget kan stoppa dig nu!](#)