

anslut 018814 LED Head Lamp Instruction Manual

Home » anslut o18814 LED Head Lamp Instruction Manual



Contents

- 1 anslut 018814 LED Head Lamp
- **2 SAFETY INSTRUCTIONS**
- 3 SYMBOLS
- **4 TECHNICAL DATA**
- **5 DESCRIPTION**
- **6 Function modes**
- 7 USE
- **8 FUNCTION SELECTOR**
- 9 CHARGING
- **10 BATTERY INDICATOR**
- 11 FOCUSING
- **12 CLEANING AND**

MAINTENANCE

- 13 Documents / Resources
- **14 Related Posts**



anslut 018814 LED Head Lamp



SAFETY INSTRUCTIONS


Follow the safety instructions below to reduce the risk of personal injury.

- Do not look at the light source or point it at people or animals risk of blinding and permanent eye damage (retina).
- Keep children under supervision to make sure they do not play with the product.
- The product contains a lithium-polymer battery, which if handled incorrectly can be set on fire and result in personal injury.
- Do not expose the product to heat, mechanical stress or anything else it is not intended for.

WARNING!

IMPORTANT: The product emits optic radiation that can result in a risk of personal injury. Do not look at the light source when it is switched on. Risk of eye damage.

SYMBOLS



TECHNICAL DATA

• Battery: Lithium-polymer battery, 3.7 V 2000 mAh

LED: CREE XPLSwitch: Tactile

· Beam focusing: Focus ring

· Front lens: Lens

• Size: 70.5 x 51.4 x 42.5 mm

• Charger in: In 100-240 V 50/60 Hz

Charger out: 5 V 1 A

• Charging time: 4–6 h (depending on battery charge status)

• Watertightness: IPX3

• Weight: 135g

DESCRIPTION

- 1. Power switch/output selector
- 2. Function selector
- 3. USB port for charging
- 4. Battery indicator
- 5. Focus ring

Function modes

Luminous flux		High	Medium	Low	Save	Max
		380	270 lm	170	90	600
		lm		lm	lm	lm
Burn-time		2h	8h	14h	25h	1.5h
Cast length	Flood- light	29 m	19 m	14 m	9 m	43 m
	Spot- light	100			30	
		m	74 m	46 m	m	147 m

Supplied parts: head lamp, forehead and crown strap, charger cable, helmet fastener.

USE

OUTPUT SELECTOR

Save mode – Low – Medium – High – Max.

• Press for 0.5 seconds to switch on/off. Press for 4 seconds for Max.

FUNCTION SELECTOR

Press for 0.5 seconds for morse code SOS, tap to show battery charge status (shown for 5 seconds).

CHARGING

- 1. Put the USB charger cable in the charging port (mini-USB) on the back of the product.
- 2. Connect the other end of the USB charger cable to a USB charger (sold separately), a computer USB port or the equivalent. The charge status is shown on the battery indicator.

NOTE:

The battery is only partially charged on delivery. The battery must be fully charged with the supplied USB charger cable before using for the first time.

BATTERY INDICATOR

1. Press the button to activate the battery indicator. The battery charge status is shown for about 5 seconds when the indicator is activated.

Charging status: The blue indicator on the front of the luminaire shows the current state of charge of the battery.

FOCUSING

The dispersion and cast length of the beam can be adjusted with the focus ring.

1. Turn the focus ring outwards to concentrate the beam for spot mode, turn inwards to disperse the beam for floodlight mode.

CLEANING AND MAINTENANCE

Clean the product with a dry, soft and lintless cloth. Do not use solvent, alcohol or other chemicals.

Documents / Resources



Manuals+,