



anslut 022491 Battery Powered Table Fan User Manual

[Home](#) » [anslut](#) » anslut 022491 Battery Powered Table Fan User Manual 

anslut 022491 Battery Powered Table
Fan User Manual



022491



BATTERY-POWERED TABLE FAN

BATTERY-POWERED TABLE FAN OPERATING INSTRUCTIONS

Original instructions



Jula AB reserves the right to make changes to the product. Jula AB claims copyright on this documentation. It is not allowed to modify or alter this documentation in any way and the manual shall be printed and used as it is in relation to the product. For the latest version of operating instructions, refer to the Jula website.

WWW.JULA.COM


© JULA AB 2022-11-02

JULA AB
BOX 363, 532 24 SKARA, SWEDEN

1



2



Contents

1 SAFETY

INSTRUCTIONS

2 TECHNICAL DATA

3 USE

4 MAINTENANCE

5 Documents / Resources

5.1 References

6 Related Posts

SAFETY INSTRUCTIONS







- Intended for indoor use.
- This product can be used by children from eight years and upwards and by persons with physical, sensorial or mental disabilities, or persons who lack experience or knowledge, if they are supervised or receive instructions concerning the safe use of the product and understand the risks involved with its use. Do not allow children to play with the product.
- The product must only be used for its intended purpose and in accordance with these instructions.
- Do not cover the product, this can result in overheating or fire.
- Place the product standing upright on a smooth, level and stable surface.
- When using the product it must always stand upright – it must never be used on its side.
- Pull out the plug from the power point when the product is not in use. Do not pull the power cord to pull out the plug.
- Only use the supplied removable plug.
- Do not use the plug if the pins are damaged.
- Leave a free space of at least 30 cm round the product to ensure safe and correct functionality.
- Check that the product can oscillate without colliding with, or being obstructed by anything in the near vicinity.
- Never poke any objects into the grille on the product. It is especially important to explain this to children to make sure they understand the risks.
- Do not use the product if the power cord or plug are damaged, if the product has tipped over, or if it does not seem to be working properly.
- A damaged power cord must be replaced by an authorised service centre, or other qualified personnel, to ensure safe use.
- Do not use the product outdoors.
- Do not use the product near a bath, shower or swimming pool.
- Do not expose the product to direct sunlight.
- Do not use the product near flammable liquids or gas.
- Switch off the product before cleaning.
- Never leave the product unattended when switched on.
- Repairs must only be carried out by an authorised service centre.
- If the product stops working properly, switch it off with the switch on the control panel and contact the retailer.
- The battery is not replaceable.
- The battery must be removed before the product is handed in for recycling.
- Switch off the product and pull out the plug before removing the battery
- Recycle used batteries in accordance with local regulations.

- Do not allow children to use, clean or maintain the product without supervision.
- Check that the rated voltage for the product corresponds to the mains supply voltage.

WARNING!

Never use the product without the guard in place. Do not remove the guard when in use or when cleaning.

SYMBOLS

	Read the instructions.
	Safety class II.
	Approved in accordance with the relevant directives.
	Only use the supplied removable plug.
	Recycle discarded product in accordance with local regulations.
 Li-ion	

TECHNICAL DATA

Rated voltage	5 VDC
Input power	10 W

USE




1. Start/switch off the product by pressing the power switch  on the base.
2. Set the required fan speed (position 1–4) by pressing the fan icon  on the base. A green status light shows the set fan speed.
3. The battery status light  flashes red when the battery is becoming discharged. Charge the product battery with the supplied USB cable. The status light goes red during charging. The status light goes green when the battery is fully charged.

FIG. 1

4. The fan can be angled for the required direction of the airflow.

FIG. 2

MAINTENANCE



The product should be cleaned every month. Clean the fan with a soft, damp cloth. Make sure that no water or other liquid gets into the fan.

NOTE:

Do not use petrol, solvent or detergent that can damage the plastic parts.

022491			
Description	Symbol	Value	Unit
Maximum fan flow rate	F	3.96	m ³ /min
Fan power input	P	1.1	W
Service value	S _V	3.6	(m ³ /min) W
Standby power consumption	P _{SB}	0.6	W
Sound power level	L _{WA}	52.6	dB(A)
Maximum flow speed	C	3.09	m/s
Annual power consumption	kWh/a	1.02	kWh/a
Operating value standard: IEC 60879:2019			
Contact: www.jula.com			

www.jula.com

  <p>BATTERY-POWERED TABLE FAN</p> <p>022491</p>	<p>anslut 022491 Battery Powered Table Fan [pdf] User Manual</p> <p>022491 Battery Powered Table Fan, 022491, Battery Powered Table Fan, Powered Table Fan, T able Fan</p>
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [Jula](#) “products for home and garden