



anslut 011422 Voltage Tester Instruction Manual

[Home](#) » [anslut](#) » anslut 011422 Voltage Tester Instruction Manual 

Contents

- [1 anslut 011422 Voltage Tester](#)
- [2 SAFETY INSTRUCTIONS](#)
- [3 SYMBOLS](#)
- [4 TECHNICAL DATA](#)
- [5 USE](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



anslut 011422 Voltage Tester



SAFETY INSTRUCTIONS

WARNING

- Check before use that the glow lamp is working.
- It must only be used for the voltages and purposes specified by the manufacturer.

SYMBOLS



- Read the instructions.



- Approved in accordance with the relevant directives.

TECHNICAL DATA

- Voltage 6-24 V
- Cable length 1m

USE

VOLTAGE TESTING

Fasten the contact clip to the chassis (earth) and put the measuring tip on the wire or terminal to be voltage tested. The glow lamp lights up if there is voltage.

LAMP TESTING

Fasten the contact clip on the battery's positive terminal and put the measuring tip on the contact plate on the

lamp socket. Must not be used on household mains (230 V).

Documents / Resources