

ANTEC NOVA PWM PC Fans Instruction Manual




Contents [[hide](#)]


- 1 CONTENTS
- 2 FAN INTRODUCTION
- 3 FAN INSTALLATION
- 4 FAN CONNECTION
- 5 Motherboard
- 6 CONTROLLER
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts

CONTENTS

- 120MM FAN




- SPEED CONTROLLER




***Single pack:** included 1 controller

***Three packs:** included 2 controllers


- FAN SCREW



- RADIATOR SCREW



FAN INTRODUCTION




AIR-IN


AIR-OUT

FAN INSTALLATION


- FRONT (Interior)




- FRONT (Exterior)




- TOP



- REAR




- POWER SUPPLY SHROUD (PC case long screws needed)




FAN CONNECTION

A. PWM 4-pin female header



B. PWM 4-pin male header




Motherboard

- Daisy chain the fans to make fans work in sync.
- Connect the 4-pin connector to the controller cable, then connect the controller cable to the 4-pin header on the motherboard.

CONTROLLER

- 3-phase PWM speed controller allows users to adjust fan speed range:



*If connecting the fan directly to the motherboard (without controller), the RPM range is set to be 400 sim (3200 plus/minus 10)% .



When starting the fan, keep your hands away from the fan to avoid injury due to the high-speed rotating blades.

www.Antec.com

All rights reserved. Specifications are subject to change without prior notice. Actual products and accessories may differ from illustrations. Omissions and printing errors excepted. Content of delivery might differ in different countries or areas. Some trademarks may be claimed as the property of others.

©1986-2024 Antec Inc. All rights reserved.

Antec[®]

Documents / Resources



[ANTEC NOVA PWM PC Fans \[pdf\]](#) Instruction Manual

NOVA PWM PC Fans, NOVA, PWM PC Fans, PC Fans, Fans

References

- [User Manual](#)

Related Posts



[Antec VORTEX 240 Instruction Manual](#)

VORTEX 240 Instruction Manual ACCESSORIES INTEL
PLATFORM INSTALLATION AMD PLATFORM
INSTALLATION INSTALL THE PUMPHEAD & FAN

RADIATOR INSTALLATION...



[Asus E15213 Notebook PC Instruction Manual](#)

Asus E15213 Notebook PC Instruction Manual -
Optimized PDF Asus E15213 Notebook PC Instruction
Manual - Original PDF



[Asus E15836 Notebook PC Instruction Manual](#)

Asus E15836 Notebook PC Instruction Manual -
Optimized PDF Asus E15836 Notebook PC Instruction
Manual - Original PDF



[ANTEC P20CE Mid-Tower PC Case Installation Guide](#)

P20CE Mid-Tower PC Case Installation Guide Case
Overview REMOVE SIDE PANEL MOTHERBOARD
INSTALLATION VGA/ PCI-EXPRESS CARD

INSTALLATIONPOWER SUPPLY...



[Antec VORTEX 240 Instruction Manual](#)

VORTEX 240 Instruction Manual ACCESSORIES INTEL
PLATFORM INSTALLATION AMD PLATFORM
INSTALLATION INSTALL THE PUMPHEAD & FAN

RADIATOR INSTALLATION...



[Asus E15213 Notebook PC Instruction Manual](#)

Asus E15213 Notebook PC Instruction Manual -
Optimized PDF Asus E15213 Notebook PC Instruction
Manual - Original PDF



[Asus E15836 Notebook PC Instruction Manual](#)

Asus E15836 Notebook PC Instruction Manual -
Optimized PDF Asus E15836 Notebook PC Instruction
Manual - Original PDF



[ANTEC P20CE Mid-Tower PC Case Installation Guide](#)

P20CE Mid-Tower PC Case Installation Guide Case
Overview REMOVE SIDE PANEL MOTHERBOARD
INSTALLATION VGA/ PCI-EXPRESS CARD

INSTALLATIONPOWER SUPPLY...

📌 Antec, Fans, Nova, NOVA PWM PC Fans, PC Fans, PWM PC

📁 Antec Fans

—Previous Post

[Antec Flux SE PC Case User Guide](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.