

APEX ULTIMA



Apex Ultima on the App Instruction Manual

[Home](#) » [Apex](#) » Apex Ultima on the App Instruction Manual 

Contents

- 1 Apex Ultima on the App
- 2 Driver sign in
- 3 Connect to Vehicle
- 4 Vehicle or Trailer
- 5 Change Duty Status
- 6 Personal Use
- 7 Yard Move
- 8 DVIR
- 9 Review & Certify
- 10 Co-Driver Login
- 11 Roadside Inspection
- 12 Data Transfer
- 13 Telematics Web Services
- 14 Telematics Email
- 15 Local USB2
- 16 Transfer Bluetooth
- 17 Data Transfer
- 18 Edit Request
- 19 Malfunctions Event
- 20 Diagnostic Event
- 21 Specifications:
- 22 Product Usage Instructions
 - 22.1 Driver Sign In
 - 22.2 Connect to Vehicle
- 23 Frequently Asked Questions (FAQ)
 - 23.1 Q: How do I change my duty status?
 - 23.2 Q: How do I perform a DVIR?
- 24 Documents / Resources
 - 24.1 References
- 25 Related Posts

APEX ULTIMA



INSTRUCTION MANUAL


Driver sign in

1. Open the Apex 1. ELD application.
2. Enter your username and password.
3. Press the "Login" button.




Connect to Vehicle

1. Locate the diagnostic port.
2. Attach the wire to the diagnostic port.
3. Connect the other end of the wire to the device.
4. Press the "Connect" signal button in the top right corner.
5. If no device is found, press the "Scan" button.
6. Select the available device.
7. The ELD will connect with the app, and the signal button should turn green.




Vehicle or Trailer

1. Press the vehicle icon next to your name.
2. Tap on "Vehicle Name" and select a vehicle.
3. Tap on "Trailer Name" and select a trailer.
4. Press the "Save" button.




Change Duty Status

1. Press the "Status" button.
2. Select your current duty status.
3. The odometer will be automatically populated.
4. The location will also be automatically populated.
5. Press the "Save" button.



Personal Use

1. Press the "Status" button.
2. Select the "Personal Use" checkbox under duty status.
3. Enter a note.
4. Press the "Save" button.




Yard Move

1. Press the "Status" button.
2. Select the "Yard Move" checkbox under duty status.
3. Enter a note.
4. Press the "Save" button.




DVIR

1. Press the "DVIR" button at the bottom.
2. Select the form and tap "Inspect."
3. Select all checkboxes, then press "Finish."
4. Choose the vehicle condition.
5. Add your signature and complete the DVIR
6. Click the "Save" button to finalize the DVIR.



Review & Certify


1. Press the “Logs” button at the bottom.
2. The current day’s logs will be displayed.
3. Select a date to view previous logs.
4. Tap “Show All” to view all logs.
5. Press the “Certify” button in the top right corner.
6. Verify your information and click “Agree” to certify.



Co-Driver Login


1. Open the left-hand menu.
2. Tap on "Co-driver Login."
3. Enter the username and password.
4. Press the "Login" button.
5. Open the left-hand menu again.
6. Tap on "Switch Co-driver."
7. Select "View" or "Make Driver."

8. Enter the password and log in.



Roadside Inspection

1. Open the left-hand menu.
2. Tap on "FMCSA."
3. Press "Start Review" button.
4. Hand over the device to the inspector.




Data Transfer

Telematics

- Wireless Web services
- Email

Local


- USB2
- Bluetooth,



Telematics Web Services


1. Navigate to Roadside Inspection from the left menu.
2. Click "Transfer" button on the Roadside Inspection screen.
3. Enter your comment in the comment box that appears.
4. Click on "Transfer" button.

5. A success message will confirm the transfer.




Telematics Email

1. Go to Roadside Inspection from the left menu.
2. On the Roadside Inspection screen, click "Email" button.
3. Enter your comment in the comment box that appears.
4. Click on "Transfer" button.
5. A success message will confirm the transfer.




Local USB2

1. Connect the USB2 to the ELD device.
2. Select Roadside Inspection from the left menu.
3. On the Roadside Inspection screen, click "USB:."
4. Enter your comment in the comment box.
5. Click on "Transfer" button.
6. A success message will confirm the transfer.




Transfer Bluetooth

1. Connect the ELD to a Bluetooth device.
2. Go to Roadside Inspection in the left menu.
3. On the Roadside Inspection screen, click Transfer.
4. Enter your comment in the comment box.
5. Click on "Transfer" button.
6. A success message will confirm the transfer.




Data Transfer

1. Open the left-hand menu.
2. Tap on "Roadside Inspection."
3. Select "Email" or "Data Transfer."
4. Enter a comment and press "Transfer."



Edit Request

1. Open the left-hand menu.
2. Tap on "Requests."
3. Choose to either accept or reject the request.
4. Enter a note and press "Save."



Malfunctions Event

1. The 'M' icon will flash at the top.
2. Tap the 'M' icon at the top.
3. A list of events will be displayed.
4. Select an event to view its details.



Diagnostic Event

1. The 'D' icon will flash at the top.
2. Tap the 'D' icon at the top.
3. A list of events will appear.
4. Select an event to view the details.



Specifications:

- Product Name: Apex Ultima
- Version: v1.0
- Connectivity: Bluetooth, USB2

Product Usage Instructions

Driver Sign In

1. Open the Apex ELD application.
2. Enter your username and password.
3. Press the Login button.

Connect to Vehicle

1. Locate the diagnostic port.
 2. Attach the wire to the diagnostic port.
 3. Connect the other end of the wire to the device.
 4. Press the Connect signal button in the top right corner.
 5. If no device is found, press the Scan button.
 6. Select the available device.
 7. The ELD will connect with the app, and the signal button should turn green.
-

Frequently Asked Questions (FAQ)


Q: How do I change my duty status?

A: To change your duty status, press the Status button, select your current duty status, and press the Save button.

Q: How do I perform a DVIR?

A: Press the DVIR button at the bottom, select the form and tap Inspect, select all checkboxes, choose the vehicle condition, add your signature, and click Save to finalize the DVIR.

Documents / Resources



[Apex Ultima on the App](#) [pdf] Instruction Manual
Ultima on the App, App

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.