

APNX C1 PC Case Installation Guide

Home » APNX » APNX C1 PC Case Installation Guide 12

Contents

- 1 APNX C1 PC Case
- 2 FAQs
- 3 Accessory & Front I/O Cable
- 4 INSTALLATION AND USING INSTRUCTIONS
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**




APNX C1 PC Case



FAQs

- Q: What are the compatible motherboard brands for this product?
 - **A:** The product is compatible with M/B ASUS, MSI, and GIGABYTE motherboards with XWD support.
- Q: How many SSDs and HDDs can be installed?
 - **A:** The product supports installation of up to 2.5" SSDs and 3.5" HDDs.
- Q: Can I control the lighting effects of the fans?
 - A: Yes, the product includes an RGB Fan Hub for controlling the lighting effects of the fans.


Accessory & Front I/O Cable




(Please refer to the motherboard's manual for further instructions).

INSTALLATION AND USING INSTRUCTIONS










































































3 120/140mm







1 120mm
























































5 120/240/360mm














Connection Set Up User Guide

For ASUS Aura Sync, MSI Mystic Light Sync, and GIGABYTE RGB Fusion Motherboards

- 1. Connect (A) to the motherboard's PWM socket
- 2. Connect (B) to the motherboard's Addressable RGB socket
 - For Non-Addressable RGB Motherboards
 - Connect (A) to the motherboard's PWM socket


Connect the 2-pin reset switch connector (D) with your hub.

Connect (C) to the PSU's SATA connector


- Use the RGB fan connectors (E) to connect the Addressable
- RGB fans with your hub.



1 120mm







- Hold the LED control button for 3 sec to switch between the motherboard and button control
- Hold the LED control button for 6 secs to turn off the LED and press it once to turn it back on

Note:

- Specifications may vary depending on your region Contact your local retailer for more information.
- To learn more about how to connect your ARGB, please visit the product page at APNX.com.

Documents / Resources



APNX C1 PC Case [pdf] Installation Guide C1, C1 PC Case, PC Case, Case

References

- APNX APNX | Build Your Story
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.