

2BDKES1 Apple Find My Network Instruction Manual

Home » Apple » 2BDKES1 Apple Find My Network Instruction Manual





Contents

- 1 2BDKES1 Apple Find My Network
- 2 Check For Updates
- 3 Power On
- 4 Add Your item Locator
- **5 Function Introduction**
- 6 How to replace the Battery:
- 7 Important tips: .
- **8 FCC Statement**
- 9 Documents / Resources
 - 9.1 References

2BDKES1 Apple Find My Network

The Apple® Find My* network provides an easy, secure way to locate compatible personal tems using the "and My app an your IPhone® iPad® Mac® or the tind Items app on Apple Watch®

To use the Apple Find My app to locate this item, the latest version of iOS% iPadOS*® or MacOS" is recommended. The Find Items app on Apple watch requires the latest version of watch®

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the praduct manufacturer to meet Apple Find My network praduct specifications and requirements. Apple is not responsible for the operation of tris device are use of this product or its compliance with safety and regulatory standards.

Getting Started

Check For Updates

To use the Apple Find My app to locate your Intern Locater, the latest version of iOS, iPad OS, or macOS is recommended.

Power On

 $Press\ your\ locator's\ function\ button\ once\ ta\ turn\ on\ --it\ should\ beep\ once\ indicating\ it\ is\ powered\ on.$



Add Your item Locator

3.1 Start the APP

Open Find My APP an your supported iPhone are iPad.

3.2 Connect your item Locator

Step]. Select the "Items" tab then lap the "Add Item" tab. +symbol (Figure 1)



Step2. Tan "Other Supported items".



Step3. Make sure your Item Locator is clos2 to your phone. wait... until you see "Shalita" then tap "Connect". Follow the pop-up to fill name and select ariemnap: ther top "Continue". There 'sill he 2 request te add your ten Locator te your IG, then tap "Continue" Tap "Finish" ance your tem Locator will be set up.



Function Introduction




Locate your Item

«Find tern Locator

Tao "Play Sound" to make your item Locator beep when it 1s Nest by,

Find you Hart Locater's locator

Your Item Locator's last proven location vill appear on the map as emoji you Cr90se during set up, tap "Directions" to navigate to tre last known location.



Find Item When Out of Range!


Enable the "Notify When Left Behind" taggle, you will receive '3 Notification when you leave your item Locator bound and it 'no longer it range of you 'device Enable the "Notify when Found" toggle, when your tem location is seen by another Fired My enabled device, you will Rece ve a notification ot its updated location.

- **Note:** " Notify When Found" can only he activated when your Item Locater is aunt of Ange.



When Your Item is Lost

- «When Your Item is Lost Under "Lost Mode", tap the "Enable" tab, a screen detailing Lost Mode will pop up, tab "Continue". You can enter your phone number or email addressand tap "Next" You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode"
- « Note: When "Lost Mode" is enabled, "Notification When Found" is automatically enabled.
- «Note: When "Lost Mode" is enabled, your Item Locator is locked and cannot be paired to a new' device.



Remove your Item Locator "Ensure "Lost Mode" is disabled, tap "Remove Item" lab, a summary will open, lap "Remove" to confirm. Reset your item Locator + After successfully removing the Item Locator from the APP press the Item Locator's function button four times rapidly, and then hold it a fifth time until you hear a ringing chime, the Item Locator is now reset and ready to pair to a new device.

How to replace the Battery:

• Use your fingernails at the small gap on the side of your Item Locater to carefully open the case.

- Replace the battery with a new CR2032 battery 3V. (Positive pole upward).
- · Carefully close the Item Locator.



Unwanted Tracking Detection:

If your iPhone detects that an unknown Item ocator is traveling with you, it will send you a notification. A sound will start playing so you will be able to find it. These alerts are only activated when an Item Locator is not connected to its owsner's phone, so your partner's Item Locator will not trigger a sound if they are with you.

Button function

1. Power on (Findmy function is on).

Press the function button once to turn it on. it should a ringring chime indicating it is powered on.

If the product is not paired, it will be closed within 10 minutes.

You need to trigger the find my function again to continue pairing.

- 2. Power off (Findmy function is off).
 - Hold the function button for three seconds, then release it.. you will hear two beeps indicating it is powered off.
- 3. Enable learn more information query.
 - Press the function button two times rapidly and you will hear a confirmation sound, This operation will be displayed on the find my app to guide the person who gets the device to obtain the device information, such as the owner's contact information (if the item is set to the lost mode on the app), and the serial number of the device.
- 4. Restore factory settings (reset the device locally and restore it to pairing status)
 - Press the function button four times rapidly and then hold it fifth lime until you hear a ringring chime.
 - A reset operation is required to enable the device to enter the pairing State again (synchronization of Findmy also requires simultaneous unbinding) and rebind the new Apple Id account. Function button



Important tips: .

- 1. when pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended:
- 2. Change the phone's network, such as switching between WiFi and mobile. The first pairing may takes a long time, please wait patiently.

- 3. Reset your item.
- 4. Repair with Findmy APP
- 5. When "Lost Mode" is enable, DO NOT REMOVE ITEM in the APP. Your Ilem Locator will be locked and cannol be paired to a new device.
- 6. The battery usage time varies depending on personal usage habits. Frequent use of the call function can accelerate battery consumption.

Regulatory Safety Information

Warning: The battery must be kept out of the reach of children. Due to chemical burns and potential esophageal perforation, swallowing may cause serious injury or death. If the child accidentally swallows the button battery, please call the rescue phone immediately and seek medical advice in ime.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation hetween the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.



Documents / Resources



Apple 2BDKES1 Apple Find My Network [pdf] Instruction Manual

2BDKES1 Apple Find My Network, 2BDKES1, Apple Find My Network, Find My Network, My Network, Network

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.