

Apple MMMQ3 Magic Mouse Instruction Manual

Home » Apple » Apple MMMQ3 Magic Mouse Instruction Manual

Contents

- 1 Apple MMMQ3 Magic Mouse
- 2 Update your software
- 3 Customize your Magic

Mouse

- 4 Recharge the battery
- **5 More information**
- 6 FAQ
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**



Apple MMMQ3 Magic Mouse



Welcome to your Magic Mouse

Your Magic Mouse has a rechargeable battery and uses Bluetooth® technology to connect wirelessly to your Mac.


This guide shows you how to use your Magic Mouse, including pairing, customization, and recharging the battery.

Update your software

To use your Magic Mouse and its full range of features, update your Mac to the latest version of macOS.

To check for updates to macOS, choose Apple menu > > System Settings > General > Software Update (or Apple menu > System Preferences > Software Update).

Set up your Magic Mouse



To pair your mouse with your Mac, use the USB-C Charge Cable that came with your mouse. Plug one end of the cable into the USB-C port on the bottom of your mouse. Plug the other end into a USB-C port on your Mac. Slide the on/off switch to on (so green is visible).

Your mouse will pair automatically with your Mac.

After the mouse is paired, disconnect the cable to use your mouse wirelessly.

Customize your Magic Mouse

Your Magic Mouse has a Multi-Touch surface you can use to click, tap, slide, or swipe.

To customize your mouse:

- 1. Choose Apple menu System Settings (or System Preferences), then click Mouse.
- 2. Click Point & Click to choose from the following options:
 - Tracking speed: Drag the slider to adjust how quickly the pointer moves when you move the Magic Mouse.
 - Natural scrolling: Turn on this option to move the contents of a window in the same direction as your fingers.
 - Secondary click: Choose the side of the mouse to click to secondary (or Control) click items on your screen.
 - Smart zoom: Turn on this option to double-tap with one finger to zoom in or out.

- 3. 3. Click More Gestures to choose from these options:
 - Swipe between pages: Choose the gesture to use to move between pages in a document.
 - Swipe between full-screen applications: Turn on this option to swipe left or right with two fingers to move between apps in full screen.

Mission Control: Turn on this option to double-tap with two fingers to enter Mission Control.

4. Click Advanced to turn on pointer acceleration. When this option is on, the pointer moves faster for fast mouse movements and more precisely for slow mouse movements.

Recharge the battery

Use the USB-C Charge Cable that came with your mouse. Plug one end of the cable into the USB-C port on the bottom of your mouse, and the other end into a USB-C port on your Mac or a USB-C power adapter.

To check the battery status, choose Apple menu System Settings (or System Preferences), then click Mouse. The battery level is shown at the top of the window (or in the lower-left corner). Note: When you aren't using your Magic Mouse,

it goes to sleep to conserve battery power. If you won't be using your mouse for an extended period, turn it off to conserve even more power.

Rename your Magic Mouse

Your Mac gives your Magic Mouse a default name the first time you pair it. You can rename it in Bluetooth settings.

To rename your mouse:

- 1. Choose Apple menu System Settings (or System Preferences), then click Bluetooth.
- 2. Control-click the mouse, then choose Rename.

Remove a pairing

After you pair your Magic Mouse with a Mac, you can pair it again with a different Mac. To do this, remove the existing pairing and then pair the mouse again.

To remove a pairing:

- 1. Choose Apple menu System Settings (or System Preferences), then click Bluetooth.
- 2. Control-click the mouse, then choose Forget (or Remove).

Clean your Magic Mouse

To clean the outside of your mouse, use a lint-free cloth. Don't get moisture in any openings or use aerosol sprays, solvents, or abrasives.

Ergonomics

When using your Magic Mouse, it's important to find a comfortable posture, change your position often, and take frequent breaks.

For information about ergonomics, health, and safety, visit the ergonomics website at apple.com/about/ergonomics

Battery

Your Magic Mouse contains no user-serviceable parts. Don't attempt to open or disassemble your Magic Mouse, remove, crush, or puncture the battery in your Magic Mouse, or expose it to high temperatures or liquids. Disassembling your Magic Mouse may damage it or may cause injury to you.

The lithium-ion battery in your Magic Mouse should be serviced or recycled by Apple or an authorized service provider, and disposed of separately from household waste. For information about Apple lithium-ion batteries, go to apple.com/batteries

More information

For more information about using your mouse, search for "mouse" in the macOS User Guide at support.apple.com/guide/mac-help

For support, go to apple.com/support

Class 1 Laser Information

The Magic Mouse is classified as a Class 1 Laser product per IEC60825-1 Ed. 3. This device complies with 21 CFR 1040.10 and 1040.11, except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.

Caution: This device contains one or more lasers. Use other than as described in the user guide, repair, or disassembly may cause damage, which could result in hazardous exposure to infrared laser emissions that are not visible. This equipment should be serviced by Apple or an authorized service provider.

CLASS 1 CONSUMER LASER PRODUCT EN 50689:2021

© 2024 Apple Inc. All rights reserved. Apple, the Apple logo, Mac, macOS, Magic Mouse, and Mission Control are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Multi-Touch is a trademark of Apple Inc.


The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Apple is under license.

FAQ

Q: How do I know when my Magic Mouse is fully charged?

A: You can check the battery level in Apple menu > System Settings > Mouse. The battery level is displayed at the top of the window or in the lower-left corner.

Documents / Resources



References

•	<u>Apple</u>
•	Site Map - Apple
•	Batteries - Apple
•	Apple (Česká republika)
•	Ergonomics - Apple Support
•	Baterie - Apple (CZ)
•	Ergonomics - Apple Support
•	Apple (Polska)
•	Ergonomics - Apple Support
	Baterie - Annie (PI.)

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.