

Apps Keep Tracking ELD App User Manual


[Home](#) » [APPs](#) » Apps Keep Tracking ELD App User Manual 

Contents

- 1 Apps Keep Tracking ELD App
- 2 Product Information
- 3 Product Usage Instructions
- 4 Getting Started
- 5 Managing HOS
- 6 Other Features
- 7 Frequently asked questions
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



Apps Keep Tracking ELD App



Product Information

The product is called “Keep Tracking Driver Manual” and it is an electronic logging device (ELD) used for tracking and recording a driver’s duty status. It is compliant with FMCSA rules and regulations.

Product Usage Instructions

Getting Started:

To install the ELD device (PT-40/ IOSiX), follow these steps:

1. Connect the ELD device to the diagnostics port of your vehicle using the appropriate connector provided with the device.

To install the Keep Tracking ELD App, follow these steps:

1. Search for “Keep Tracking ELD” on Google Play or scan the QR code on the back of the manual.
2. Use the login credentials received via email or from your motor carrier to log in to the app. If you haven’t received these credentials, please contact your motor carrier.
3. If prompted, allow the app to use location in the background.

Managing HOS:

To record your Hours of Service (HOS), follow these steps:

1. From the Dashboard of the app, tap on the duty status you intend to switch to.
2. If you start driving, the device and application will automatically detect it and switch your status to drive.

Certifying HOS:

To certify your HOS, follow these steps:

1. Click the Certify button at the bottom of your screen to navigate to the certification page.
2. Select the days you would like to certify from the pending list.
3. Click the CERTIFY button located below the list.

Viewing HOS:

To view your HOS history, follow these steps:

1. From the dashboard, click the Logs button at the bottom of the screen.
2. To switch to previous days, swipe the graph left or right.
3. To view your available hours, click on the violation markers at the top of your screen.
4. The time elapsed since the last duty status can be viewed below the VIN Number.

eRODS Transfer:

To create an eRODS Transfer, follow these steps:

1. Click the Reports button at the bottom of your screen.
2. Select the appropriate transfer method (Web/Email).

3. Fill the comment field with the code provided by the officer conducting the inspection.

Other Features:

The application has additional features:

1. Violation Tracking & Warnings: The app automatically detects HOS violations and warns the user through notifications and popups on the dashboard. If you are in violation, the appropriate status icons will flash, and you will be warned when switching to another duty status.
2. Malfunction Reporting: If an ELD malfunction occurs, the motor carrier must take appropriate actions to correct, repair, replace, or service the malfunctioning ELD within eight days. During this time, the driver must maintain a paper record of duty status (RODS) until the ELD is back in service.

Frequently Asked Questions:

When creating an eRODS transfer, you should select the appropriate transfer method (Web/Email).

Getting Started

Installing the ELD Device

In order to install the ELD device (PT-40/ IOSiX) simply connect it to the diagnostics port of your vehicle using the appropriate connector provided with the device.

Installing the Keep Tracking ELD App

In order to install the app simply search Keep Tracking ELD on Google Play or scan the QR code on the back of the manual.

To start using the app, use the login credentials received via email or from your motor carrier. If you did not receive these login credentials, please contact your motor carrier.


If prompted, please allow the app to use location in the background.

Managing HOS

Recording HOS


From the Dashboard of the app tap on the duty status you intend to switch to.

If you start driving the device and application will detect this and automatically switch your status to drive.




Certifying HOS

In order to certify your HOS, navigate to the certification page by clicking the Certify button at the bottom of your screen. Afterwards select the days you would like to certify from the pending list, then click the CERTIFY button located below the list.



Viewing HOS

Your HOS history can be viewed from the dashboard by clicking the Logs button at the bottom of the screen. In order to switch to previous days just swipe the graph left or right. Your available hours can be viewed by clicking on the violation markers at the top of your screen. The time elapsed since the last duty status can be viewed below the VIN Number.



eRODS Transfer

In order to create an eRODS Transfer click the Reports button at the bottom of your screen. Select the appropriate transfer method (Web/Email) and fill the comment field with the code provided by the officer conducting the inspection.

≡

Reports

↺

✱

US-8

|

DRIVER NAME
COMPANY NAME

Scanning...
12:39

Roadside Inspection

WEB

EMAIL

Date Time : 12:39

Event Comments

SEND

Dashboard

Logs

Certify


Reports

Other Features

Violation Tracking & Warnings

The application will automatically detect HOS violations ahead of time and warn the user as such through a notification and popup on the dashboard.

If the user is in violation the appropriate status icons will be flashing, and the user will be warned of the active violation(s) when switching to another duty status.



Malfunction Reporting

If an ELD malfunction occurs, the driver must:

1. Note the malfunction of the ELD device and provide a written notice of the malfunction to the motor carrier within 24 hours;
2. Reconstruct the record of duty status (RODS) for the current 24-hour period and the previous 7 consecutive days, and record the RODS on graph-grid paper logs, or electronic logging software that comply with 49 CFR 395.8, unless the driver already has the records or retrieves them from the ELD; and
3. Continue to manually prepare RODS in accordance with 49 CFR 395.8, until the ELD is serviced and back in compliance. The recording of driver's hours of service on paper log, or electronic logging software, cannot continue for more than 8 days after the malfunction; a driver that continues to record his or her hours of service

on paper log, or logging software beyond 8 days risks being placed out of service.

If an ELD malfunction occurs, the motor carrier must:

1. Correct, repair, replace, or service the malfunctioning ELD within eight days of discovering the condition or a driver's notification to the motor carrier, whichever occurs first; and
2. Require the driver to maintain paper record of duty status (RODS) until the ELD is back in service.

Frequently asked questions

What transfer method should I select when creating an eRODS transfer?

Choose the transfer method as advised by the officer conducting the inspection.

The indicator icons are flashing red.

If the indicator icons are flashing red this means that the application is unable to connect to the ELD device.

Please ensure that the device is connected properly and running, and that you are within range of the device. If this does not resolve the issue, please follow the Malfunction Reporting instructions.


For any other questions please contact our support team.

Phone: +1 317 820 8044

Email: admin@keep-trackin.com

Web: <https://keep-trackin.com>

Documents / Resources

 Keep Tracking Driver Manual	Apps Keep Tracking ELD App [pdf] User Manual PT-40, IOSiX, Keep Tracking ELD App, Keep Tracking ELD, App
--	---

References

- trackin.com
- [Keep Trackin -- Keep Tracking](#)
- [Nationwide Technologies](#)