



Apps MY Audits App User Guide

[Home](#) » [APPs](#) » Apps MY Audits App User Guide 

Contents

- 1 Apps MY Audits App
- 2 Product Information
- 3 Product Usage Instructions
- 4 User guide
- 5 Activating the 70mai Dash Cam Lite
- 6 Product Overview
- 7 Installation
- 8 Accessory
- 9 Safety precautions
- 10 Package contents
- 11 Regulatory compliance information
- 12 EU declaration of conformity
- 13 FCC
- 14 Documents / Resources



Apps MY Audits App



Product Information

The product is a software application that allows users to download and complete audits. It provides a systematic process for conducting audits and recording findings. The application also allows users to add actions and images, sign audits for confirmation, and upload completed audits.

Product Usage Instructions

1. Open the software application.
2. Click on "Download Audits" to retrieve available audits.
3. Type your name in the search box to find your audits.
4. Click anywhere in the section of the first available audit.
5. You will be prompted to confirm if you want to download the audit. Verify that it is the correct audit and click "Okay" to proceed. If it is not the correct audit, click "Cancel".
6. Another prompt will ask if you want to run the audit. Select "No" at this stage.
7. Continue by downloading all of your audits.
8. Once you have downloaded all of your audits, click on the three lines menu icon.
9. Select "Run Audits" from the menu options.
10. Click on the audit you want to run anywhere in the section.
11. Click on "Run Audit" to begin the audit process.
12. Click "Next" to proceed.
13. You will see a list of items that need to be checked. Locate the first item (e.g., Fire Extinguisher E1) at its specified location and verify if it is in place. Click on the appropriate response (e.g., "Passed" if it is there or "Failed" if it is not).
14. Answer the question(s) provided for each item, following the specific instructions given.
15. After completing all the items, click "Next".
16. If you have found something of concern, you can add an action. Click on "Add Action" and provide the necessary details.
17. If applicable, you can add an image to illustrate the issue. Click on "Add Image" and choose to use a photo from the camera or take a new photo.
18. Once you have completed all the steps, click "Save Action".


19. To confirm the completion of the audit, click on “Add Signature”. Then, click “Save”.
20. After completing all the above steps, you can upload the audit by clicking on “Complete”. Note that all questions in the Criteria screen must be answered before uploading.
21. If you need to make any changes to the audit, click “Edit this Response”. This will take you back to the previous screens.
22. Once everything is correct and completed, click “Upload” to submit the audit.
23. After uploading, a successful response will be displayed. Click “Okay” to acknowledge it.
24. To select and perform the next audit, repeat the process from step 10.
25. Continue completing audits until all of them are finished.
26. If you log out of the application, any downloaded audits will be deleted, and you will need to download them again in the next week.
27. If you stay logged in, you can directly access the “Run Audits” option next time, and instructions from step 10 will apply.



View the User Guide for product functions and FAQs.

Scan the code to view the product functions, FAQs, and tutorial videos. <https://fdashcam.70mai.com/support>

Product Support



United States

1-877-746-6088

Canada (English)

1-888-507-9088

Mon-Fri 9am-6pm PST

<https://dashcam.70mai.com/support>

help@70mai.com



WhatsApp Online



E-Mail Service

Please read this manual carefully before using the product and keep it in a safe place.

Thank you for choosing the 70mai Dash Cam Lite

The 70mai Dash Cam Lite is equipped with a professional video recording chip and image sensor for capturing high-quality videos.

User guide

Please scan the QR code below to get the online user guide. Please use the product according to the instructions in the user guide.



Activating the 70mai Dash Cam Lite




The 70mai Dash Cam Lite must be activated using the 70mai app. To download and install the app, search for “70mai” in Google Play Store (Android) or App Store (iOS).

Or you can download the app by scanning the QR code below:



Please select “Add Device” in the 70mai app and complete the activation according to the prompts.

Product Overview




Installation

Please install the product following the method below.


1. Install the electrostatic sticker

Clean your windshield and put the electrostatic sticker on the recommended area as shown in the figure below. Make sure you remove air bubbles between the sticker and the glass.



2. Install the bracket


Lock the bracket to the Dash Cam, as shown in the figure below. You will hear a snap when it is in place.



3. Stick the camera mount to the windshield

Remove the protective cover from the mount and stick the mount's base to the center of the electrostatic sticker. Make sure your Dash Cam body is parallel to the ground.


Press the mount to attach it to the electrostatic sticker tightly.



4. Connect USB cable to the cigarette lighter receptacle

Align the cable with the top edge of the windshield and fasten it along the passenger's side and the glovebox as shown below.

Connect the cable to the car charger and insert the car charger into the cigarette lighter receptacle.



Note: The cigarette lighter receptacle might be positioned differently in your car. The picture is provided for reference only

5. Adjust the Dash Cam angle

Turn on the Dash Cam and adjust the camera angle up and down against the preview screen to ensure that the camera is facing the front.

Accessory

This device can be used together with 70mai GPS Mount Holder (sold separately). Please scan the QR code below to get the online user guide.



Safety precautions

Please read all precautions and instructions carefully before using this product to ensure proper and safe usage.

- This product records videos outside of moving vehicles. It can't protect drivers and passengers from any accidents. We shall not take any responsibility if the user gets involved in any traffic accident and/or bear any loss due to product failure, information loss, or product operation.
- Due to differences in vehicle type, driving preferences, the environment, and other differences, parts of the product or the whole product may not work normally in some circumstances. The device may not record normally due to loss of power source, abnormal temperatures and/or humidity, collisions, damage to the TF card, and other reasons. We do not guarantee that all the recorded videos will be saved completely in any given situation. The images recorded by this product are for reference only.
- Install the product correctly. Do not block the driver's vision. Do not obstruct the air bag. Keep the product at least 20cm away from the driver and passengers. Incorrect installation of the product may cause product failure and injury.
- Please use the car charger and USB cable that comes with this device to avoid compatibility issues. 70mai is not responsible for any loss caused by the use of non- standard car chargers and USB cables.
- The memory card is not included in the package. You will need to buy it by yourself.
- Use a TF card with storage capacity between 16GB and 64GB, and reading and writing speed not lower than Class10. Format the TF card before using it.
- Do not insert or pull out the TF card when the product is working to avoid damaging the TF card.
- TF card may be damaged after repetitive use. Replace TF cards in time to maintain proper recording. We shall not bear any responsibility caused by failed TF cards.
- This device is equipped with a built-in battery that is not removable. Do not disassemble the device yourself. The battery (battery pack or assembled battery) shall not be exposed to overheating environments such as sunlight, fire, or the like. If the battery is replaced improperly, there is a danger of explosion, so that it can only be replaced with a battery of the same or equivalent type.
- The device should not be exposed to water droplets or water splashes. Keep the device dry to avoid battery failure.
- If the battery is deformed, swelling, or leaking, stop using the product immediately and contact customer service.
- Do not shake or press the product. Strong impact or shaking may cause irreparable damage to the product.
- Do not clean this product by chemical solvents or cleansers.
- Keep this product away from strong magnetic fields to avoid damage.
- Do not use this product in temperatures higher than 60 or 10c
- Please note that the housing's temperature rises when the device is running.

- Use this product within the scope of the law.

Specifications

- Model: Midrive D08
- Image sensor: SONY IMX307
- Resolution: 1920×1080
- Camera: FOV 130°
- Wireless connection: Wi-Fi IEEE 802.11 b/g/n/ 2.4GHz
- G-sensor: Acceleration sensor
- Expandable memory: MicroSD card with capacity of 16-64GB and read/write speed of Class10 and above
- Supported OS: Android5.0/iOS11.0 and above
- Power supply: Car cigarette lighter
- Battery type: Li-polymer battery
- Battery capacity: 500mAh
- Input: 5V 1.5A
- Dimensions: 82 × 58.2 × 40.5mm

Package contents

1. 70mai Dash Cam Lite ×1
2. USB cable ×1
3. Car charger ×1
4. Electrostatic sticker ×1
5. Heat-resistant adhesive ×1
6. Mounting bracket ×1
7. User manual ×1

Regulatory compliance information

WEEE information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as the terms and conditions of such collection points.

EU declaration of conformity



The manufacturer hereby, declares that this equipment is in compliance with the applicable Directives and European Norms, and amendments. The full text of the EU Declaration of Conformity is available at the following internet address: <https://help.70mai.asia/1193.html>



Hereby, 70mai Co., Ltd. declares that the radio equipment type Midrive D08 is in compliance with Radio Equipment Regulations 2017. The full text of the UKCA declaration of conformity is available at the following internet address: <https://help.70mai.asia/2145.html>

Cautions

- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.
- This device is equipped with a built-in battery that cannot be removed or replaced. Do not disassemble or modify the battery by yourself.
- Replacement of a battery with an incorrect type can defeat a safeguard (for example, in the case of some lithium battery types).

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
FCC ID: 2AOK9-MIDRIVED08


Scatola	Manuale	Borsa	Neto
PAP 20	PAP 22	CPE 7	PAP 21+PS 6
Carta	Carta	Plastica	Carta , Plastica

Service: help@70mai.com

For further information, please go to www.70mai.com Manufacturer: 70mai Co., Ltd.

Address: Room 2220, Building 2, No. 588 Zixing Road, Minhang District, Shanghai, China

Documents / Resources

	Apps MY Audits App [pdf] User Guide MY Audits App, App
---	---