

Apps SPARK App Instruction Manual

[Home](#) » [APPs](#) » Apps SPARK App Instruction Manual 

Contents


1 Apps SPARK App

2 Installation & Connection

3 Documents / Resources




Apps SPARK App



Installation & Connection

Install the SPARK App

- For Android phones and tablets download the SPARK App from Google Play Store. For iPhones and iPads download the SPARK App from the App Store.



- Open the SPARK App.

Login to the SPARK App and select a vehicle

Read the login details from your email. If you don't have login details yet, or you've forgotten them, contact your Carrier administrator.


- Enter your login details and tap LOG IN, you will be prompted to the Terms and Conditions page.
- Read the Terms and Conditions and tap AGREE
- Select your vehicle from the list, or search for one.
- Tap ACCEPT, you will be prompted to the Settings page where you can review and edit settings details.
- Tap SAVE

Connect your mobile device to the SPARK device


Dashboard View

After successfully login & vehicle selection, the Dashboard page is open.


- Use Tap to Connect bar to connect to your vehicle. The device will attempt to connect to selected vehicle ELD via Bluetooth.




- ELD bar will change from red to orange: Pairing



- An icon (M) will appear in connection bar upon successful connection.



Documents / Resources

	<p>Apps SPARK App [pdf] Instruction Manual BA9212320, SPARK App, App</p>
---	--