



# APsystems EMA App User Manual

[Home](#) » [APsystems](#) » Apsystems EMA App User Manual 

## Contents

- 1 Apsystems EMA App
- 2 Product Usage Instructions
- 3 Introduction
- 4 APP Download
- 5 System Configuration
- 6 Data Monitor
- 7 App Setting
- 8 Documents / Resources
  - 8.1 References
- 9 Related Posts



**APsystems EMA App**



## Specifications

- **Product:** EMA APP (PV Version)
- **Version:** V8.7.0
- **Developer:** APsystems EMEA
- **Contact:** Phone: +31 (0)85 3018499, Email: [info.emea@APsystems.com](mailto:info.emea@APsystems.com)
- **Operating Systems Supported:** iOS 10.0 and onwards, Android 7.0 and onwards

## Product Usage Instructions

### APP Download

- **Method 1:** Search for the EMA APP in the APP Store or Google Play.
- **Method 2:** Scan the provided QR code to download the app.

### Register/Login/Reset Password

1. Click on **Register** in the app to start the registration process.
2. **Complete three steps:** Account Information, ECU Information, and Inverter Information.
3. **For Account** Information, enter the required details and agree to relevant terms.
4. **For ECU** Information, provide the necessary details either by scanning a code or manual entry.
5. **For Inverter** Information, enter the inverter details as prompted.
6. Click OK to complete each section and then click Complete Registration to finish.

### Login

If you have already registered, login by entering your account name and password on the login page.

## Reset Password

1. Click on Forgot Password.
2. Enter your account name and email.
3. Get the verification code and follow the instructions to reset your password.

## FAQ

### Q: What can I do with the EMA APP?

- **A:** The EMA APP allows users to track the real-time performance of their photovoltaic system, view output data by day, month, and year, calculate energy savings, and environmental benefits, and manage system configuration.

## Introduction

- EMA APP is designed for APsystems microinverters system owners and DIY users.
- It allows users to track the real-time performance of the photovoltaic system, see the system output by day, month, and year, and calculate energy savings and environmental benefits. It also allows system commission and configuration.

## APP Download

- **Method 1:** Search “EMA APP” in “APP Store” or “Google Play”
- **Method 2:** Scan the QR code to download.



## NOTE


- iOS 10.0 and onwards
- Android 7.0 and onwards

## Register/Login/Reset Password

### Register


- If you don't have an EMA account yet, you can register through the EMA APP.
- Click Register” to enter the registration navigation page.

- A register is divided into the following three steps: Step1: Account Information (Required)
- **Step2:** ECU Information (Required)
- **Step3:** Inverter Information (Required)



## Account Information

- Click “Account Info”,
- Enter the necessary information according to the prompts on the page and tick the relevant agreements,
- Click “OK” to complete.




## Company Code

- Contact your installer to get the company code. Installer can log in to EMA Manager or EMA web portal, and get the company code on the “Setting” page.


## ECU Information

- Click “ECU”,
- Enter the corresponding ECU information according to the page prompts (the ECU entry method is divided into “scan code entry” and “manual entry”),
- Click “OK” to complete.




## Inverter Information

- Click “Inverter” to enter,
- Enter the corresponding inverter information according to the page prompts (the entry method of the inverter is divided into “scan code entry” and “manual entry”),
- Click “OK” to complete.




- Click “Complete Registration” to complete.



## Login


- If you have already registered an EMA account, enter your account name and password on the login page and click to log in.



## Reset Password

- If you forget your EMA account login password, you can reset your account password through the password retrieval process.

- Click “Forgot Password”,
- Enter your account name and email, click to get the verification code, then consult your email to retrieve the verification code, and return to the APP to verify the information,
- Enter the new password and click “Finish” to complete.




## System Configuration

### ECU Initialization

- After the account registration is completed, you can initialize the ECU.
- When configuring the ECU, you need to switch the mobile phone network to the ECU hotspot.
- The default password for the ECU hotspot is 88888888.


### Link Inverters

- Click “ECU Initialization” to enter,
- Correct the inverter number, click the “Bind” button, and send the inverter UID to the ECU.
- The ECU will automatically complete the network binding with the inverter. This process takes some time.
- If you skip account registration and proceed directly to ECU initialization, you need to enter the inverter information.




## Network Configuration

- Select the Internet Wi-Fi that can be connected in the ECU work area and enter the Wi-Fi password or choose wired network configuration,
- Click “OK” to complete the network configuration.



## ECU Setting






## Data Monitor

### Remote Monitor

- Remote monitoring requires logging in to an EMA account.

### Home

- “Home” displays the real-time operating status and system benefits;




## Module

- Module” displays the system module level operating status;



## Data

- Data” displays the current operating status and historical power generation of the system.



## Local Monitor

- You need to switch the mobile phone network to the ECU hotspot and click “Local Access” on the login page.

- The default password for the ECU hotspot is 88888888.


## ECU

- ECU” displays the real-time operating status of the system and the system’s environmental benefits;



## Inverter


- Inverter” displays the device level power generation data, the progress of the network between the device and the ECU, and the alarm information of the device.



## App Setting


### Language

You can switch the language on the “Login” page and the “Setting” page.




## Night Mode

The App interface can be switched to night mode.



- **APsystems EMEA**
- **Karspeldreef 8, 1101 CJ Amsterdam**
- **Phone: +31 (0)85 3018499 Email: [info.emea@APsystems.com](mailto:info.emea@APsystems.com)**
- **[emea.APsystems.com](http://emea.APsystems.com)**
- **APsystems France 22 avenue Lionel Terray 69330 Jonage France**
- **Phone: 031-10-2582670**
- **Email: [info.emea@APsystems.com](mailto:info.emea@APsystems.com)**
- **[emea.APsystems.com](http://emea.APsystems.com)**
- **© All Rights Reserved**

## Documents / Resources

	<a href="#">APsystems APsystems EMA App</a> [pdf] User Manual APsystems EMA App, EMA App
---	---

## References

- [🏠 Home - APsystems EMEA](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.