



## apuro DM067-A Ice Cream Maker Instruction Manual

[Home](#) » [apuro](#) » apuro DM067-A Ice Cream Maker Instruction Manual 

### Contents

- [1 apuro DM067-A Ice Cream Maker](#)
- [2 Safety Tips](#)
- [3 Installation](#)
- [4 Using Your Ice Cream Maker](#)
- [5 Cleaning, Care & Maintenance](#)
- [6 Troubleshooting](#)
- [7 Technical Specifications](#)
- [8 Electrical Wiring](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)



apuro DM067-A Ice Cream Maker



## Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - Fire Precautions
  - IEE Wiring Regulations
  - Building Regulations
- Warning: Fill with potable water only.
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT immerse the appliance in water.
- DO NOT use the appliance outside. Intended for Household use only.
- DO NOT attempt to mix items that this machine is not designed for. This can damage the machine.
- DO NOT bypass the safety interlocks.
- DO NOT place hands near the rotating attachments when in use. This can result in injury.
- Never leave the appliance unattended when in use.
- Always switch off and disconnect the power supply to the unit before cleaning.
- This appliance must only be used in accordance with these instructions and by persons competent to do so.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a Apuro agent or a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- Apuro recommends that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.

**Caution Risk of Fire:** Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

**Warning:**

- Keep all ventilation openings clear of obstruction. Unit should not be boxed in without adequate ventilation.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are the type recommended by the manufacturer.

**Pack Contents**

The following is included:

- Ice Cream Maker
- Measuring Cup
- Scoop
- Instruction manual

Apuro prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.


Should you find any damage as a result of transit, please contact your Apuro dealer immediately.

**Installation**

**Note:** If the unit has not been stored or moved in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.

1. Remove the appliance from the packaging and remove the protective film from all surfaces.
2. Maintain a distance of 20cm (7 inches) between the appliance and walls or other objects for ventilation. Do not block ventilation grills. NEVER LOCATE NEXT TO OR NEAR A HEAT SOURCE.

**Getting to know your ice cream maker**



### **Before First Use**


Before use, thoroughly wash all parts that will come into contact with the ice cream (including the removable bowl, blender blade, transparent lid, refill lid, measuring cup and scoop).

### **Using Your Ice Cream Maker**


Place the removable bowl, with ingredients, into the machine.

**For fastest results ingredients should be pre-chilled.**

- Fix blender blade to machine ensuring that the blade connects well with the motor axis (fig.1).
- Fit the transparent lid onto the machine and lock into place.



- Turn the timer to the desired time setting. The blender blade will start to turn. After a short delay the compressor will start and the bowl will start to chill. The LED display shows the temperature (fig.2).
- When the machine is running you can increase/decrease the operating time by turning the timer.
- You can stop the machine at any time by turning the timer anticlockwise to the "0" position.



- When produce becomes frozen, blade will stop turning. Switch off the machine immediately to protect blade motor.
- To avoid overflow and waste, please make sure that the ingredients do not exceed 60% of the capacity of the removable bowl (ice cream expands when being formed).

## **Cleaning, Care & Maintenance**

- Unplug the appliance and wait for it to completely cool down before cleaning.
- Wipe over the outside surface of the unit with a dampened cloth and polish with a soft dry cloth.
- Wipe any excess food from the power cord.
- Wash the removable bowl and accessories in warm soapy water and wipe dry.

### **Storage Of Ice Cream |**

Transfer finished ice cream into another container using a plastic scoop or a wooden spoon and store in freezer. Do not use a metal scoop to avoid scratching the inside of the removable bowl.

## **Ice Cream Recipe**

Vanilla Ice Cream

Makes approx 10 x 120ml servings Ingredients

- 240ml of Whole Milk
- 150g of Granulated Sugar
- 480ml of Double Cream
- ½ teaspoon pure vanilla extract (to taste)

In a bowl, use a hand mixer or a whisk to combine the milk and sugar until the sugar is dissolved. Stir in the cream and vanilla to taste. Turn machine on, pour mix into freezer bowl and mix until thickened.

## **Troubleshooting**

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check unit is plugged in correctly and switched on
	Plug and lead are damaged	Call Apuro agent or qualified Technician
	Fuse in the plug has blown	Replace the plug fuse
	Power supply	Check power supply
	Internal wiring fault	Call Apuro agent or qualified Technician
Ice cream too soft	Timer setting too short	Increase timer setting
Ice cream too hard	Timer setting too long	Reduce timer setting
Timer has not reached 0 but the machine has stopped and the ice cream is hard	The ice cream has frozen solid stopping the blade from turning. The motor protection system has engaged to stop the motor overheating	Allow the unit to cool before attempting to restart
The blade is not turning	Blade not fitted to motor axis correctly	Ensure the removable bowl is fitted correctly and that the blade has a good connection to the motor axis

## Technical Specifications

Model	Voltage	Power	Current	Capacity (Litres)	Dimensions H x W x D mm	Weight (kg)
<b>DM067-A</b>	220-240V~ 50Hz	150W	0.7A	1.5	245 x 402 x 348	10.9

## Electrical Wiring

The plug is to be connected to a suitable mains socket.  
This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.


Apuro parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

Apuro products have been approved to carry the following symbol:

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Apuro. Every effort is made to ensure all details are correct at the time of going to press, however, Apuro reserve the right to change specifications without notice.



## Documents / Resources

 <p>Model: DM067-A</p>	<p><a href="#">apuro DM067-A Ice Cream Maker</a> [pdf] Instruction Manual DM067-A Ice Cream Maker, DM067-A, Ice Cream Maker</p>
---	---