



AQFORM Multitrack High Surface System Installation Guide

[Home](#) » [AQFORM](#) » AQFORM Multitrack High Surface System Installation Guide 

AQFORM Multitrack High Surface System Installation Guide



Contents

1

INSTALLATION
INSTRUCTION

2

Documents / Resources


2.1

References



3

Related Posts

INSTALLATION INSTRUCTION



REQUIRED



straight microtrack line requirement


screw




end cup



power supply






mounting element




power supply dimensions

DRIVER	60W	100W	200W
L [mm]	163	300	390
M [mm]	43	30	30
H [mm]	32	17	23






3.





4.


5. optional element




6. optional element



7.




8.



9.


mechanical connection




electrical connection

„L” – connection

1




2




straight – connection


1




2



on / off (+ optional DALI)





Double circuit on / off




DALI example

(for double on/off circuit connection – replace DALI by 2nd 48V power line)





Documents / Resources

	AQFORM Multitrack High Surface System [pdf] Installation Guide Multitrack High Surface System, High Surface System, Surface System, System
---	---

References

- [User Manual](#)