



# aranet AR-PROBASE12 Base Station Data Logger User Guide

[Home](#) » [Aranet](#) » aranet AR-PROBASE12 Base Station Data Logger User Guide 

## Contents


- 1 Aranet AR-PROBASE12 Base Station Data Logger
- 2 CHECK THE CONTENTS OF THE BOX ATTACH THE DEVICE TO THE MOUNT CONNECT POWER TO THE DEVICE TURN THE DEVICE ON CONNECT TO THE DEVICE CONFIGURE THE DEVICE
- 3 ADDITIONAL RESOURCES
- 4 Documents / Resources
  - 4.1 References
- 5 Related Posts

# Aranet


**Aranet AR-PROBASE12 Base Station Data Logger**




**CHECK THE CONTENTS OF THE BOX**




**ATTACH THE DEVICE TO THE MOUNT**



**CONNECT POWER TO THE DEVICE**



**TURN THE DEVICE ON**



## CONNECT TO THE DEVICE

1

WiFi SSID "Aranet-\*\*\*\*\*"

2

<http://192.168.206.100>

3

Login

Username  
root

Password  
\*\*\*\*\*






☒ Remember me LOGIN

**THE DEFAULT ADMINISTRATOR LOGIN**

Username: **root**

Password: **changeme**


## CONFIGURE THE DEVICE

-  Change your password, modify and add users in the Users setting section.
-  Set the device time in the System > Time setting section.
-  Scan the availability of the radio channel in the Sensors > Radio setting section.
-  Pair your sensors by pressing the Add sensor button in the Sensors > Sensors setting section.  
<https://aranet.com/product/aranet-pro/>
-  Enter the Notifications setting section, to configure your e-mail notifications.

## ADDITIONAL RESOURCES




- Please refer to the Aranet PRO User Guide for detailed instructions <https://aranet.com/product/aranet-pro/#documentation>
- To view Terms&Conditions visit <https://aranet.com/terms-and-conditions/>
- To view Returns&Guarantees or fill RMA form visit <https://aranet.com/rma/>
- To find out more about Aranet products visit <https://forum.aranet.com/>

## Documents / Resources



[aranet AR-PROBASE12 Base Station Data Logger](#) [pdf] User Guide  
AR-PROBASE12 Base Station Data Logger, AR-PROBASE12, Base Station Data Logger

## References

-  [Aranet PRO base station - Aranet](#)
-  [Aranet PRO base station - Aranet](#)
-  [Home](#)