



ArduCam B0333 2MP IMX462 Pivariety Low Light Camera Module for Raspberry Pi User Guide

[Home](#) » [ArduCam](#) » ArduCam B0333 2MP IMX462 Pivariety Low Light Camera Module for Raspberry Pi User Guide 

*ArduCam B0333 2MP IMX462 Pivariety Low Light Camera
Module for Raspberry Pi User Guide*



Pivariety Low Light Camera Module for Raspberry Pi



2MP IMX462

(SKU: B0333)

QUICK START GUIDE

Contents

- [1 INTRODUCTION](#)
- [2 SPECIFICATION](#)
- [3 SOFTWARE](#)
- [4 TROUBLESHOOT](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

INTRODUCTION

• About ArduCam

ArduCam has been a professional designer and manufacturer of SPI, MIPI, DVP and USB cameras since 2012. We also offer customized turnkey design and manufacturing solution services for customers who want their products to be unique.

• About Pivariety Camera

ArduCam Pivariety is a Raspberry Pi camera solution to take the advantage of using its hardware ISP functions. Using ArduCam Pivariety camera modules, users can get better performance and a wider variety of camera, lens options. For a long time, Raspberry Pi users are limited to use the closed-source official

supported camera driver and camera modules (V1/V2/HQ).

Now ArduCam made it possible to provide well-turned ISP for Pivariety camera modules with Auto Exposure, Auto White Balance, Auto Gain Control, Lens Shading Correction, etc. This series of cameras use the libcamera framework, they can't be supported by Rasp still, and the way to access the camera is libcamera SDK(for C++)/libcamera-still/ libcamera-vid/Streamer. If you want to know more about other models of Pivariety Camera, please visit: <https://www.arducam.com/docs/cameras-for-raspberrypi/pivariety/>

SPECIFICATION

Image Sensor	2MP IMX462
Max. Resolution	1920H×1080V
Pixel Size	2.9um x 2.9um
Optical Format	1/2.8"
Lens Spec	Mount: M16
	Focal length: 4mm±5%
	F.NO: 0.95±5%
	FOV: 92.23deg (H)
Minimum Illumination	0.01Lux
IR Sensitivity	Integral IR filter, visible light only
Frame Rate	Adjustable, 5-60fps@1080P
Sensor Output Format	RAW10
ISP Output Format	Output image format of JPG, YUV420, RAW, DNG; output video format of MJPEG, H.264
Interface Type	2-Lane MIPI
Board Size	38mm×38mm

SOFTWARE

1. Driver Installation

```
wget -O install_pivariety_pkgs.sh https://github.com/ ArduCam/Arducam-Pivariety-V4L2-Driver/releases/download/install_script/install_pivariety_pkgs.sh
chimed +x install_pivariety_pkgs.sh
./install_pivariety_pkgs.sh -p kernel driver press y to reboot
```

NOTE: The kernel driver installation only supported by the latest version 5.10. For other kernel versions, please

go to our Doc page: <https://www.arducam.com/docs/cameras-for-raspberry-pi/pivariety/how-to-install-kernel-driver-for-pivarietycamera/#2-how-to-build-raspberry-pi-kernel-driverfor-arducam-pivariety-camera>

You can also visit this doc page to refer to the hardware connection:

<https://www.arducam.com/docs/cameras-for-raspberry-pi/pivariety/2mp-imx462pivariety-low-light-camera-module/>

2. Test the Driver and Camera

After you've finished the hardware assembly and driver installation, you can test whether the camera is detected and working.

- View the Status of Driver and Camera

```
dmesg | grep ArduCam
```

It will display arducam-pivariety if driver installed successfully and firmware version if the camera can be detected. The display should be probe failed if the camera can't be detected, you might have to check the ribbon connection, then reboot the Raspberry Pi.

- View the Video Node

The Pivariety camera modules are emulated as the standard video device under /dev/video* node, so you can use the ls command for listing the contents in the /dev folder.

```
ls /dev/video* -
```

Since the camera module is V4L2 compliant, you can use the V4L2 controls to list the supported color space, resolutions, and frame rates. `v4l2-ctl --list-formats-ext`.

NOTE: Although V4L2 interface is supported, only RAW format images can be obtained, without ISP support.

3. Official Libcamera App Installation

```
./install_pivariety_pkgs.sh -p libcamera_dev
```

```
./install_pivariety_pkgs.sh -p libcamera_apps
```

4. Capture Image and Record Video

- Capture image

For example, preview for 5s and save the image named test.jpg

```
libcamera-still -t 5000 -o test.jpg
```

- Record video

For example, record a H.264 10s video with the frame size 1920W × 1080H

```
libcamera-vid -t 10000 --width 1920 --height 1080 -o test.h264
```

NOTE: H.264 format only supports 1920×1080 and below resolution.

- Plugin streamer installation

Install streamer sudo apt update

sudo apt install -y gstreamer1.0-tools

Preview

gst-launch-1.0 libcamerasrc ! 'video/xraw,width=1920,height=1080' ! videoconvert ! autovideosink

TROUBLESHOOT

1. Cannot Allocate Memory

[3:45:35.833744413] [6019] INFO RPI raspberrypi.cpp:611 Sensor: / base/soc/i2c0mux/i2c@1/arducam@0c - Selected mode: 5344x4012-pRAA [3:45:35.948442507] [6019] ERROR V4L2 v4l2_videodevice.cpp:1126 /dev/video14[17:cap]: Unable to request 4 buffers: Cannot allocate memory [3:45:35.948551358] [6019] ERROR RPI raspberrypi.cpp:808 Failed to allocate buffers ERROR: *** failed to start camera ***

Edit /boot/cmdline.txt and add cma=400M at the end More details:

<https://lists.libcamera.org/pipermail/libcamera-devel/2020-December/015838.html>

2. The Image Displays Color Dots

Add code `--denoise cdn_off` at the end of command `./libcamera-still -t 5000 -o test.jpg --denoise cdn_off` More details: <https://github.com/raspberrypi/libcameraapps/issues/19>

3. Failed to Install the Driver

Please check the kernel version, we only provide the driver for the latest official kernel version image when this Pivariety camera released.

Note: If you want to compile the kernel driver by yourself, please refer to Doc page:

<https://www.arducam.com/docs/cameras-for-raspberry-pi/pivariety/how-to-installkernel-driver-for-pivariety-camera/>

4. Failed to import fd 18

terminate called after throwing an instance of 'std::runtime_error' what(): failed to import fd 18 Aborted

If you find the same error, you may make the wrong selection about the graphics driver. Please follow ArduCam Doc page to select the correct graphics driver.

5. Switch to the native camera (raspistill etc.)

Edit the file of /boot/config.txt, make `dtoverlay=ArduCam` change to `#dtoverlay=ArduCam` After the modification is completed, you need to reboot the Raspberry Pi. `sudo reboot`

CONTACT US

If you need our help or want to customize other models of Pi cameras, feel free to contact us.

Email: support@arducam.com

Website: www.arducam.com









Skype: Arducam

Documents / Resources



[ArduCam B0333 2MP IMX462 Pivariety Low Light Camera Module for Raspberry Pi](#) [pdf] User Guide
B0333, 2MP IMX462, Pivariety Low Light Camera Module for Raspberry Pi

References

-  [Simplifying embedded vision for all. - Arducam](#)
-  [Cameras for Raspberry Pi - Arducam](#)
-  [Redirecting...](#)
-  [GitHub: Let's build from here · GitHub](#)
-  [Color dot problem · Issue #19 · raspberrypi/libcamera-apps · GitHub](#)
-  [Index of /pipermail](#)
-  [Simplifying embedded vision for all. - Arducam](#)
-  [Arducam Wiki](#)

Manuals+.