



Arducam B0432 Pico4ML Pro TinyML Dev Kit Installation Guide

[Home](#) » [ArduCam](#) » Arducam B0432 Pico4ML Pro TinyML Dev Kit Installation Guide 

Contents


- [1 Arducam B0432 Pico4ML Pro TinyML Dev Kit](#)
- [2 Connecting](#)
- [3 Package Contents](#)
- [4 Installation](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



Arducam B0432 Pico4ML Pro TinyML Dev Kit




Connecting




Note: No Mega SPI cameras are included in this package.

Pico4ML-Pro can also work as a multiple SPI camera adapter. Up to 4 Arducam Mega SPI cameras can be connected to the Pico4ML-Pro simultaneously.

Package Contents




Installation



- For more tech data and a detailed user guide, please visit <https://www.arducam.com/pico4ml-quickstart/>

Documents / Resources

	ArduCam B0432 Pico4ML Pro TinyML Dev Kit [pdf] Installation Guide B0432, B0432 Pico4ML Pro TinyML Dev Kit, Pico4ML Pro TinyML Dev Kit, Pro TinyML Dev Kit, TinyML Dev Kit, Dev Kit
	ArduCam B0432 Pico4ML-Pro TinyML Dev Kit [pdf] User Guide B0432, B0432 Pico4ML-Pro TinyML Dev Kit, Pico4ML-Pro TinyML Dev Kit, TinyML Dev Kit, Dev Kit, Kit