



ARGON OS-214EX Entry Level Desktop Printer Installation Guide

[Home](#) » [ARGON](#) » ARGON OS-214EX Entry Level Desktop Printer Installation Guide 

Contents

- [1 ARGON OS-214EX Entry Level Desktop Printer](#)
- [2 Overview](#)
- [3 -D-](#)
- [4 Loading Ribbon](#)
- [5 Loading Media](#)
- [6 Cutter Mode](#)
- [7 FCC](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)


ARGON

ARGON OS-214EX Entry Level Desktop Printer




Overview

-A-




1. Top Cover
2. Power indicator
3. Ready Indicator
4. Feed Button
5. Power Switch

-B-




1. Ethernet
2. Serial Port (RS232-C)
3. USB Type A
4. USB Type B
5. Power Jack

-C




1. Ribbon Pick-up Holder
2. Media Hanger
3. Release Levers




1. Ribbon Supply Holder
2. Platen Roller
3. Thermal Print Head


Loading Ribbon



Loading Media



Cutter Mode




FCC

The user is cautioned that any changes or modifications not recommended by Argox Information Co. Ltd. could result in the loss of the user's authority to operate the equipment. To ensure compliance, the users must use accessories and peripherals approved by Argox Information Co. Ltd.

Supplemental Information: This device complies with the requirement of FCC Part 15 Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources



[ARGOX OS-214EX Entry Level Desktop Printer](#) [pdf] Installation Guide
OS-214EX, OS-200, Entry Level Desktop Printer, OS-214EX Entry Level Desktop Printer