



AW-16402 Spring-Wire Guide with Arrow Advancer Instruction Manual

[Home](#) » [Arrow](#) » [AW-16402 Spring-Wire Guide with Arrow Advancer Instruction Manual](#) 

ARROW[®]

Spring-Wire Guide with Arrow Advancer
Instruction Manual

Contents

- [1 AW-16402 Spring-Wire Guide with Arrow Advancer](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

AW-16402 Spring-Wire Guide with Arrow Advancer



REF.018 inch dia. spring-wire guide
68 cm spring-wire guide

1:Spring-WireGuide: .018"(0.46 mm)dia. x 26-3/4"(68cm)(Straight Soft Tip on One End – "J" Tip on Other) with Arrow Advancer



LOT



	<p>EU Authorized Representative and Importer:</p>
	<p>Teleflex Medical IDA Business and Technology Park Dublin Road, Athlone Co. Westmeath, Ireland</p>
	<p>Arrow International LLC A subsidiary of Teleflex Incorporated 3015 Carrington Mill Blvd. Morrisville, NC 27560 USA</p>

Rx-only Warning: Read all package insert warnings, precautions, and instructions prior to use. Failure to do so may result in severe patient injury or death. www.teleflex.com/IFU
Not made with natural rubber latex. Fluid path components are non-pyrogenic.

Teleflex®

www.teleflex.com

LBL060630 R01 (2021-06)

Documents / Resources

	<p>ARROW AW-16402 Spring-Wire Guide with Arrow Advancer [pdf] Instruction Manual AW-16402 Spring-Wire Guide with Arrow Advancer, AW-16402, Spring-Wire Guide with Arrow Advancer, Arrow Advancer, Advancer</p>
--	--