



# ASAKUKI Essential Oil Diffuser with Remote Control User Guide

[Home](#) » [ASAKUKI](#) » ASAKUKI Essential Oil Diffuser with Remote Control User Guide 

## ASAKUKI Essential Oil Diffuser with Remote Control User Guide



## Contents

- 1 Accessories
- 2 Using Steps
- 3 Remote Control Guide
- 4 Button Control
- 5 Maintenance & Notice
- 6 4 DIY Essential Oil Blends
- 7 Specifications
- 8 ASAKUKI Be With You Any Time!
- 9 Documents / Resources
  - 9.1 References
- 10 Related Posts

## Accessories

This manual book applies to all same model diffusers with different colors.



Pure White



White Wood



Light Wood



Cherry Wood



Dark Wood


- Diffuser 1



- User Guide \*1



- Remote Control 1



- AC Power Adapter \*1



### Notice:

The remote control and AC power cord are included in the water tank.



### Using Steps

Connect the power



Add water and essential oils in the tank



Press 'LIGHT' to adjust the LED light

Long press 'MIST' to adjust the mist amount Short press 'MIST' to set timer

Use the remote to control it



**Remote Control Guide**



### **ON/OFF**

**One press:** Turn on the mist and set at 1 hour misting time

**Two press:** Turn off the mist and light



### **Intermittent**

Press to set to intermittent mist mode. It will mist for 10 seconds and stop 10 seconds then start to mist 10 seconds again.



### **Continuous**

Press to set at continuous misting mode



### **Timing**

**One press:** Set at 3 hours misting time

**Two press:** Set at 6 hours misting time

**Three press:** Set at continuous on working

**Four press:** Set at 1 hour misting time



### **Big/Small**

Press the button, one beep for small mist and two beeps for big mist



### **Light(no beep voice when press)**

**One press:** Turn on the light and color will cycle

Next presses will fix each color at dim or bright mode

**Long press about 3 seconds:** Turn off the light

## **Button Control**

### **LIGHT Button**

After power is connected, press the 'LIGHT' button once to turn on the light, the LED light color will cycle from dim to bright gradually.

Continue pressing will fix the color at a bright or dim status.

Long press about 3 seconds to turn off the light



## MIST Button

Short press the 'MIST' button once to turn on the mist and it will be set at one hour misting time. Continue pressing to set mist time at 3 hours / 6 hours/ continuous on and turn off.

Long press the 'MIST' button about 3 seconds to adjust the mist density. One beep for weak mist and two beeps for strong mist.



## Maintenance & Notice

### Clean & Maintenance

**Please clean the diffuser per week as follows:**

- Unplug the diffuser and pour out the remaining water from 'DRAIN SIDE'.
- Add 2-3 drops of vinegar to 100ML warm water (up to 70C).
- Leave diffuser for 5 minutes and gently shake and pour out water.
- Wipe the diffuser with a dry soft cloth.
- If the diffuser will not be used for a long time, please keep it clean and dry.



### Notice

- Pour out the water inside the tank from the drainage outlet. When filling water, do not exceed the max line marked on water tank.
- Please power off diffuser first before adding water.

- Diffuser will beep two times and turn off automatically when water used up.
- Please use pure natural essential oils.
- If the diffuser is leaking for any reason, please unplug the unit and pour out remaining water. Shake diffuser gently to drain water inside, then dry for more than 24 hours.

Please refer to the table below in the event of the product operating abnormally	
Will not switch on/off	<ul style="list-style-type: none"> <li>• Is there enough water in the tank? Please add water to the tank.</li> <li>• Is the power cord connected properly?</li> </ul> <p>Please disconnect, check cables and reconnect carefully.</p>
No mist or abnormal mist	<ul style="list-style-type: none"> <li>• Not enough water or too much water? Please add suitable amount of water in the tank, water must never be filled over max line.</li> <li>• Dirt on the ultrasonic plate? Please refer the maintenance instructions remove and re-install correctly.</li> <li>• Dirt or dust in the air intake on the underside of the base? There is a fan on the underside of the base that is required to blow the mist out. If it gets clogged with dust or dirt, it will prevent mist from coming out.</li> </ul>
Water leakage from product	<ul style="list-style-type: none"> <li>• Cover not set on the base properly? Remove the cover and set it back on the base right above the buttons.</li> <li>• Low temperature or high humidity? Under these conditions, the mist may condense quickly into water droplets.</li> </ul>



72h Clean the water tank every 3 days

- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
- Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the oil diffuser down. If the oil diffuser output volume cannot be turned down, use the oil diffuser intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.




- Unplug the appliance during filling and cleaning.
- Never leave water in the reservoir when the appliance is not in use.
- Empty and clean the oil diffuser before storage. Clean the oil diffuser before next use.



**Warning:** Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

#### 4 DIY Essential Oil Blends



#### Specifications



Dimensions	Approx (W)165 x (H)196m
Weight(Excluding Adapter)	Approx 435g
Power:Input/Output	AC100-240V 50/60Hz DC24V 500mA
Length Of Cord	Approx 150cm
Power	Approx 10W
Working Mode	1H/3H/CH/ON
Tank Capacity	400ml
LED Colors	7 Bright, 7 Dim
Materials	PP/ABS/PC
Accessories	AC Adapter, Remote Control and Manual
Working Frequency	2,4MHz

## ASAKUKI Be With You Any Time!

Dear valuable customer, Thanks for choosing ASAKUKI.

**ASAKUKI** originated from Japan, we focus on designed and creative household items for a better life. The word 'ASAKUKI' comes from the Japanese pronunciation (air in the morning') whose products relate to healthy family life.

Utilizing our experience and success in the industry, ASAKUKI has created a customized and unique project management team, designed to fulfill our customers' requirements with the highest quality household items based on innovation, excellence, and comfort, using the latest technology. Together with a 100% satisfaction guarantee, we want to let you know that if you need any assistance, please feel free to contact our customer support team by simply email us via Amazon message. We guarantee a positive solution within 24 hours.

Wish a better and happier life!

Best Regards

**ASAKUKI**

**Brand:** ASAKUKI Product

**Name:** Essential Oil Diffuser

**Model Number:** 100-DF016

**Power Input/Output:** DC24V; 500mA 12W

**WEEE-Reg.-Nr:** DE: DE 41980660 FR: FR031399\_05UERI

**Manufacture:** Chongqing ChuangHong DianZi ShangWu YouXian Gongsi

**Address:** 1 zhuang 11-3,jin kai da dao 1228 hao, bei bu xin qu, Chongqing, 401120, China



**UK Responsible Person:** APEX CE SPECIALISTS LIMITED

**Address:** 89 Princess Street, Manchester, M1 4HT, UK

**Contact:** Wells

**Tel:** +441616371080

E-mail: [info@apex-ce.com](mailto:info@apex-ce.com)

## WARNING




### KEEP OUT OF REACH OF CHILDREN

Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.



---

## Documents / Resources

	<a href="#">ASAKUKI Essential Oil Diffuser with Remote Control</a> [pdf] User Guide Essential Oil Diffuser with Remote Control, Oil Diffuser with Remote Control, Diffuser with Remote Control, Remote Control, Control
---	--

## References

- [User Manual](#)