

ASHLEY L430844 Tenslow Table Lamp Instruction Manual

Home » Ashley » ASHLEY L430844 Tenslow Table Lamp Instruction Manual



ASHLEY L430844 Tenslow Table Lamp



Contents

- 1 IMPORTANT SAFETY
- 2 Installation and Instructions for use
- **3 Customer Service**
- 4 Documents / Resources

IMPORTANT SAFETY

NOTICE: READ CAREFULLY BEFORE BEGINNING ASSEMBLY!

- Always use proper tools.
- Follow the assembly steps in order. Do not skip any steps.
- Be sure to check all packing materials carefully for small parts may have come loose inside the carton during shipment. If parts are missing, contact the retailer from which you purchased the product to obtain any missing parts.

DO NOT USE SUBSTITUTE PARTS.


- Periodically check to ensure that all connectors (bolts, screws, etc.) are tight.
- Keep the instructions for future reference.
- Some assembly may involve attaching glass or mirrors. Be very careful handling the glass or mirrors, as severe injury may result if the glass or mirror breaks. Never handle large pieces of glass or mirrors by yourself.
- When assembling products that have electric cords (lamps, light, etc.), always (1) make sure the electrical cord is unplugged before assembly and (2) be careful not to twist the electrical cord during assembly.
- When assembling shelves or entertainment centers, do not stand on lower shelves in order to assemble upper shelves—use a step ladder.
- Do not stand on tables, including but not limited to, end tables, coffee tables, and dinner tables, as tables are not to support the weight of a person.
- Where assembly instructions state that the assembly requires two or more people, do not attempt by yourself
 as there is a risk of injury.

NOTE: ASHLEY FURNITURE INDUSTRIES, LLC DISCLAIMS ANY LIABILITY FOR DAMAGES OR INJURIES WHICH MAY OCCUR DUE TO FAILURE TO PROPERLY FOLLOW ASSEMBLY INSTRUCTIONS, PROPERLY ASSEMBLE THE PRODUCT, OR PROPERLY USE THE PRODUCT.

NOTE: YOUR UNIT MAY LOOK DIFFERENT IN APPEARANCE FROM THE ONE SHOWN IN THE ILLUSTRATIONS ON THIS INSTRUCTION SHEET.

Installation and Instructions for use

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.



Customer Service

RTAParts@ashleyfurniture.com www.ashleyfurniture.parts





Documents / Resources



<u>ASHLEY L430844 Tenslow Table Lamp</u> [pdf] Instruction Manual L431584, L430844, L430844 Tenslow Table Lamp, Tenslow Table Lamp, Table Lamp, Lamp

Manuals+,