

 **ASHLEY**
T5779-3 Collezza
End Table



Ashley T5779-3 Collezza End Table Installation Guide

[Home](#) » [Ashley](#) » Ashley T5779-3 Collezza End Table Installation Guide 

Contents

- [1 Ashley T5779-3 Collezza End Table](#)
- [2 Product Usage Instructions](#)
- [3 parts](#)
- [4 Assembly Instruction](#)
- [5 CONTACT](#)
- [6 FAQ](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



Ashley T5779-3 Collezza End Table



Product Usage Instructions

- Identify all parts and hardware included in the package.
- Refer to the instruction manual for step-by-step assembly guidelines.
- Use the provided tools for assembly to ensure proper fit and stability.
- Double-check all connections and tighten screws to secure the furniture.
- Once assembled, place the furniture in the desired location. Avoid placing heavy objects on unstable surfaces.
- Clean the furniture regularly with a damp cloth and mild detergent.
- Inspect the furniture periodically for any loose fittings or damage.
- Tighten screws if necessary. Avoid exposure to direct sunlight or moisture to prevent damage to the material.

IMPORTANT SAFETY NOTICE: READ CAREFULLY BEFORE BEGINNING ASSEMBLY!

- Always use proper tools.
- Follow the assembly steps in order.
- Do not skip any steps.
 - Be sure to check all packing materials carefully, for small parts may have come loose inside the carton during shipment. If parts are missing, contact the retailer from which you purchased the product to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
 - Periodically check to ensure that all connectors (bolts, screws, etc.) are tight.
 - Keep the instructions for future reference.
 - Some assembly may involve attaching glass or mirrors.
 - Be very careful handling the glass or mirrors, as severe injury may result if the glass or mirror breaks. Never handle large pieces of glass or mirrors by yourself.
 - When assembling products that have electrical cords (lamps, lights, motors, power strips, etc.), always (1) make sure the electrical cord is unplugged before assembling, (2) be careful not to twist or pinch the electrical cord during and after assembly, and (3) DO NOT USE AN EXTENSION CORD WITH THIS PRODUCT

Note: During charging, the device and the charger could heat up; this is normal. If the battery gets hotter than usual, the device may stop charging.











WARNING: Remove all metal objects like coins and keys from the charging surface and remove any metal objects attached to your mobile phone before placing the device on the charging surface. Some mobile devices or cases may attract metal objects.

- When assembling shelves or entertainment centers, do not stand on lower shelves to order to assemble upper shelves- use a step ladder.
- On not sit or stand on tables.
- Do not sit or stand on tables, including but not limited to, end tables, cocktail tables, and dining tables, as tables are not engineered or designed to support the weight of a person.
- Where assembly instructions state that the assembly requires two or more people, do not attempt it by yourself, as there is a risk of injury.

NOTE: ASHLEY FURNITURE INDUSTRIES, LLC DISCLAIMS ANY LIABILITY FOR DAMAGES OR INJURIES WHICH MAY OCCUR DUE TO FAILURE TO PROPERLY FOLLOW ASSEMBLY INSTRUCTIONS, PROPERLY ASSEMBLE THE PRODUCT, OR PROPERLY USE THE PRODUCT.

NOTE: YOUR UNIT MAY LOOK DIFFERENT IN APPEARANCE FROM THE ONE SHOWN IN THE ILLUSTRATIONS ON THIS INSTRUCTION SHEET.


parts

<p>Ax1</p> 		<p>Bx2</p> 	<p>Cx2</p> 
		<p>Dx1</p> 	<p>Ex12</p>  <p>1/4"X2"</p>
<p>Fx1</p>  <p>5/32"</p>	<p>Gx2</p>  <p>1/4"X3-1/10"</p>	<p>Hx2</p>  <p>1/4"</p>	<p>Jx2</p>  <p>1/4"</p>
<p>Kx1</p>  <p>1/4"</p>			


NOTE: UNIT SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE. DO NOT TIGHTEN ANY BOLTS UNTIL ALL BOLTS HAVE BEEN STARTED!

Assembly Instruction



NOTE: HARDWARE ARE STORED UNDER TABLE





NOTE: ASSEMBLY INSTRUCTION FOR MULTIPLE UNITS, THE PARTS/LABEL INDEX ARE SEPARATED FOR DIFFERENT UNITS





①







②



③

Hx2  1/4"	Jx2  1/4"
--	---





CONTACT

- RTAParts@ashleyfurniture.com
- www.ashleyfurniture.parts
- 1-844-966-0809

FAQ

- **Q:** My unit looks different from the illustrations provided. Is this normal?
- **A:** Yes, variations in appearance may occur due to design updates or manufacturing changes. As long as all parts are present and fit together correctly, it is normal for the unit to look slightly different.
- **Q:** How do I contact customer support for assistance?
- **A:** For any product-related inquiries or assistance, please contact our customer support team at 1- [844-966-0809](tel:8449660809) or email us at parts@ashleyfurniture.com.

Documents / Resources

	<p>Ashley T5779-3 Collezza End Table [pdf] Installation Guide T5779-3, T5779-3 Collezza End Table, T5779-3, Collezza End Table, End Table, Table</p>
---	--

References

- [User Manual](#)

[Manuals](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.