

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Baby Einstein](#) /
- › [Baby Einstein Electronic Me Reader Jr. 8 Sound Book Library Instruction Manual](#)

Baby Einstein Me Reader Jr.

Baby Einstein Electronic Me Reader Jr. 8 Sound Book Library Instruction Manual

Brand: Baby Einstein | Model: Me Reader Jr.

INTRODUCTION

The Baby Einstein Electronic Me Reader Jr. 8 Sound Book Library offers an interactive reading experience for young children. This set includes eight illustrated board books featuring beloved Baby Einstein animals, packaged with an electronic Me Reader Jr. module. The module reads each book aloud, allowing children to choose a book, press matching buttons, and hear the story along with sounds. This hands-on interaction engages young readers, helps build vocabulary by connecting words with pictures, and stimulates imagination through multisensory reading experiences. Following along in the book while listening to the narration supports early independent reading skills.

 baby einstein.



8 Board Books and Electronic Reader

Image: The Baby Einstein Electronic Me Reader Jr. 8 Sound Book Library, featuring the electronic reader and a collection of eight board books.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Electronic Me Reader Jr. Module
- 8 x Illustrated Board Books
- 3 x AAA Batteries (pre-installed or included for initial use)



Image: The Me Reader Jr. electronic module, showing its buttons for book and page selection.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the Me Reader Jr. module.
2. Using a Phillips head screwdriver, loosen the screw and remove the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and tighten the screw.

Note: Always use new batteries of the same type. Do not mix old and new batteries or different types of batteries. Remove batteries if the device will not be used for an extended period.

Power On/Off

The Me Reader Jr. module typically has an ON/OFF switch located on the back or side. Slide the switch to the "ON" position to activate the device. Slide it to "OFF" when not in use to conserve battery life.

OPERATING INSTRUCTIONS

Follow these steps to enjoy your Me Reader Jr. experience:

1. **Select a Book:** Identify the book you wish to read from the library. Each book has a corresponding button on the Me Reader Jr. module. Press the button that matches your chosen book.
2. **Choose a Page:** Open the selected book to the desired page. Each page will have a small icon or number. Find the matching icon or number button on the Me Reader Jr. module and press it.
3. **Listen to the Story:** The module will read the text on the selected page aloud. Some pages may also include sound effects or music.
4. **Interactive Elements:** Look for special icons within the book pages. Pressing the corresponding button on the module may trigger additional sounds or phrases related to the image.

For a visual guide on how to use the Me Reader Jr. system, please watch the video below:

Your browser does not support the video tag.

Video: Demonstration of the Me Reader system, showing how to select books and pages to hear stories and sounds.

MAINTENANCE

Cleaning

- Wipe the Me Reader Jr. module with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- The board books can be wiped clean with a slightly damp cloth if necessary. Ensure books are completely dry before closing or storing.

Storage

Store the Me Reader Jr. module and books in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the module is turned off when not in use to prevent battery drain.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound or device not turning on.	Batteries are low, incorrectly installed, or device is off.	<ul style="list-style-type: none"> o Ensure the ON/OFF switch is in the "ON" position. o Check battery polarity and ensure they are securely installed. o Replace with fresh AAA batteries.
Incorrect story or sound plays.	Wrong book or page button pressed.	<ul style="list-style-type: none"> o Verify that the selected book button matches the physical book. o Ensure the selected page button corresponds to the open page in the book.
Sound is distorted or too low.	Low batteries or speaker obstruction.	<ul style="list-style-type: none"> o Replace batteries. o Ensure the speaker area on the module is clear of debris.

SPECIFICATIONS

Publisher: Phoenix International Publications, Inc.

Publication Date: July 7, 2020

Language: English

Print Length: 80 pages (total for 8 books)

ISBN-10: 1503752585

ISBN-13: 978-1503752580

Item Weight: 2.1 pounds

Reading Age: 2 - 3 years

Dimensions: 7.95 x 2.6 x 11.02 inches (packaging/overall product)

Power Source: 3 x AAA Batteries

WARRANTY AND SUPPORT

This product is covered by the manufacturer's standard warranty. For specific warranty details, product support, or to inquire about replacement parts, please contact Phoenix International Publications, Inc. customer service.

Contact information can typically be found on the product packaging or their official website.

Please retain your purchase receipt as proof of purchase for warranty claims.